

Development of the Laser-Induced Incandescence Method for the Reliable Characterization of Diesel Particulate Emissions

William D. Bachalo
Artium Technologies, Inc.*
Sunnyvale, CA

Greg J. Smallwood and David R. Snelling
National Research Council
Ottawa, Canada

Peter O. Witze
Sandia National Laboratories
Livermore, CA

* Supported by NASA John Glenn Research Center

Development of the Laser-Induced Incandescence Method for the Reliable Characterization of Diesel Particulate Emissions

Outline

- **Introduction**
- **Theory**
- **Results**
 - diesel engine
 - direct injection gasoline automobile
 - transient measurements
- **Summary**



Sandia
National
Laboratories



Diesel Particulates

- Concern about urban air quality/health:
 - further reductions in diesel PM regulations
 - 1988 - 0.6 g/bhp-hr, 2000 - 0.1 g/bhp-hr, 2007 – 0.01 g/bhp-hr
 - extension to other vehicle/engine types
- Diesel engines are producing ***lower quantities of PM at smaller sizes***, nearing the sensitivity and reproducibility limits of the gravimetric technique




Sandia
National
Laboratories



Artium
Technologies Inc.

Transmission Electron Microscope (TEM) Images of Soot



Morphology

- nearly-spherical primary particles 20 – 50 nm in diameter
- cluster into chain-like aggregates
- SOF absorbed onto the surface of the primary particles



Sandia
National
Laboratories



Artium
Technologies Inc.

LII Soot Monitoring Instrument

Sealed Enclosure

Sampling Hood



Sandia CRF

NRC-CNRC Canada


Artium Technologies, Inc.

cooperating to


Develop, Evaluate, and
Commercialize

Laser-Induced
Incandescence (LII)

Systems for Online Exhaust
Particulate Material (PM)
Monitoring



Other
Mobile PM Sources



Laser-Induced Incandescence (LII) Features

- **In situ and Nonintrusive**
- **Spatially resolved**
- **Time resolved**
- **Large dynamic range**
- **Signal is proportional to particulate volume fraction**



Sandia
National
Laboratories




Artium
Technologies Inc.

Laser-Induced Incandescence (LII)

- We have demonstrated

- the repeatability of LII measurements is far better than the repeatability of the standard gravimetric filter technique
- LII measurements show good correlation with the filter mass measurements over a wide range of operating conditions and particulate levels



- Wider measurement range (10^6) and a much lower detection limit (ppt) make LII a potential standard instrument for PM measurements
- LII has a significant time advantage in collection and processing of data



Sandia
National
Laboratories



Laser-Induced Incandescence (LII) Concept


- **LII experimental approach:**
 - pulsed focused laser beam – Nd:YAG, 20 ns pulse
 - laser light produces rapid heating of PM to incandescence temperature
 - carbonaceous PM radiates incandescence as it cools to ambient temperature
 - incandescence signal is collected to determine PM concentration
- **LII theory**
 - a state-of-the-art numerical model of nanoscale (time and space) heat transfer to and from the particles



Sandia
National
Laboratories



LII Signals at two wavelengths



Particulate Concentration

- Measure incandescence, I_{λ} , at two wavelengths and solve for temperature, T

$$\frac{I_{\lambda_1}}{I_{\lambda_2}} = \frac{\lambda_2^6}{\lambda_1^6} \frac{\left(e^{\frac{hc}{k\lambda_2 T}} - 1\right)}{\left(e^{\frac{hc}{k\lambda_1 T}} - 1\right)} \frac{E(m)_{\lambda_1}}{E(m)_{\lambda_2}}$$

- Use the temperature to determine the radiation from a single primary particle of diameter d_p

$$P_p(\lambda) = \frac{8\pi^3 c^2 h}{\lambda^6 \left(e^{\frac{hc}{k\lambda T}} - 1\right)} d_p^3 E(m)$$

Particulate Concentration

- Number of primary particles, N_p , is then determined from the ratio of the experimental intensity to P_p
- Particulate volume fraction (PVF) is


$$PVF = \frac{p}{6} \cdot \frac{d_p^3}{V} \cdot N_p$$



Sandia
National
Laboratories



Temperature Decay Rate Related to Particle Size



Sandia
National
Laboratories




Artium
Technologies Inc.

Primary Particulate Size

- **Conduction phase**

–The temperature differential between the particle surface and the ambient gas decays steadily in an exponential manner


$$\Delta T = A \cdot e^{-\Delta t / t}$$



- The primary particle diameter may be inferred (*McCoy and Cha, 1974*)

$$d_p = \frac{12 k_g a}{G I_{MFP} c_p r_p t}$$

Soot Primary Particle Size at Two Combustion Conditions




Sandia
National
Laboratories



Artium
Technologies Inc.

Conventional LII Calibration



Sandia
National
Laboratories

LII Calibration Using Absolute Light Intensity


- Single point calibration is made in a known source at a known temperature, which results in an absolute sensitivity (in $\text{W}/\text{m}^3 \cdot \text{ster}$) for the detection system
- Must account for losses through optical components (lenses, filters, fibers, windows, etc.) and the gain characteristics of the photodetectors
- Method can be automated and invisible to the user




Sandia
National
Laboratories



Absolute Intensity Calibration Concept



LII Apparatus Schematic (Diesel)




Sandia
National
Laboratories




Artium
Technologies Inc.


Laser Sheet and Sample Volume




- Each fluence level will heat particles to a different temperature
- Ideal is a top-hat profile



Photograph of the Compact LII System and the Test Cell



Sample Cell




Sandia
National
Laboratories



Artium
Technologies Inc.


AVL 8-Mode Steady-State Simulation




- Engine speed 600 to 1900 rpm
- Load 0 to 95%

$$BSE = \frac{\sum (Emission Rate)_i \times WF_i}{\sum (Brake Power)_i \times WF_i}$$


Diesel Particulate Concentration



Calibration




Mode-by-Mode




Comparison


AVL 8 – mode steady-state simulation

Sandia
National
Laboratories


Diesel Particulate Concentration



Calibration




Mode-by-Mode






Comparison

AVL 8-mode steady-state simulation




Sandia
National
Laboratories

Diesel Particulate Concentration




AVL 8 – mode steady-state simulation



Sandia
National
Laboratories

Diesel Summary: LII vs. Gravimetric



Particulate Concentration: Discussion

- Gravimetric sampling includes an organic fraction that does not contribute to the signal measured by LII
- Repeatability of our gravimetric data is poor compared to LII method
- The density of the particulates is required to convert the mass determined by the gravimetric filter method to a volume fraction for comparison with LII, and density used is for dry soot
- LII measurements could have been made in the exhaust manifold with 5 to 10 times higher signal levels




Sandia
National
Laboratories



Artium
Technologies Inc.

Throttle Transient 1200 rpm - LII (30 nm SMPS)




Sandia
National
Laboratories




Throttle Transient 1200 rpm- LII (90nm SMPS)

Sandia CRF Light Duty Diesel

Sandia
National
Laboratories**Artium**
Technologies Inc.

Throttle Transient 1200 rpm - LII (150 nm SMPS)


Sandia CRF Light Duty Diesel



Sandia
National
Laboratories



EGR Transient (1500 RPM, throttle @ 25% max)




Sandia
National
Laboratories




Artium
Technologies Inc.

Tailpipe Particulates Measurements (DISI)



Tailpipe Particulates Measurements




Sandia
National
Laboratories



Artium
Technologies Inc.

EPA LA4 Cold Start Cycle




Sandia
National
Laboratories



Artium
Technologies Inc.

EPA LA4 Hot Start Cycle




Sandia
National
Laboratories



Artium
Technologies Inc.

HWFET Cycle

Highway Fuel Economy Tests




Sandia
National
Laboratories




Artium
Technologies Inc.

Comparison of particulate levels determined by LII (top) and ELPI (bottom) for hot start LA-4 transient cycle



Detail illustrating relative temporal response and sensitivity of LII and ELPI.



Sandia
National
Laboratories



Artium
Technologies Inc.

Summary

- LII is a potential method for online monitoring of particulate emissions
- Practical calibration method for measuring soot/particle concentration successfully developed
- LII method has been shown to have a high dynamic range and sensitivity
- Can operate at very low concentrations – post-particulate filter trap
- Measurements can be made without dilution



Sandia
National
Laboratories



Summary (continued)

- Method has very high precision (repeatability)
- Comparisons to Gravimetric methods show the potential accuracy of the LII method
- LII data comparisons to the SMPS and ELPI demonstrate the superior time response and capability in measuring transient particle emissions
- LII combined with other methods may best fulfill future monitoring requirements



Sandia
National
Laboratories

