

RCO-2011-002

Title: Neutron Operational and Protection Quantity Conversion  
Coefficients Under ICRP-26, ICRP-60, and ICRP-103

Authors: K.G. Veinot, N.E. Hertel

Date: Feb. 6-9, 2011

Prepared by Babcock & Wilcox Technical Services Y-12, LLC  
Management & Operating Contractor for the Y-12 National Security  
Complex under Contract No. DE-AC05-00OR22800 with the U.S.  
Department of Energy National Nuclear Security Administration

Unclassified

# Legal Stuff

- **DISCLAIMER**

- This work of authorship and those incorporated herein were prepared by Contractor as accounts of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency thereof, nor Contractor, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, use made, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency or Contractor thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency or Contractor thereof.

- **COPYRIGHT NOTICE**

- This document has been authored by a contractor/subcontractor of the U.S. Government under contract DE-AC05-00OR-22800. Accordingly, the U.S. Government retains a paid-up, nonexclusive, irrevocable, worldwide license to publish or reproduce the published form of this contribution, prepare derivative works, distribute copies to the public, and perform publicly and display publicly, or allow others to do so, for U. S. Government purposes.

# Neutron Operational and Protection Quantity Conversion Coefficients Under ICRP-26, ICRP-60, and ICRP-103


K.G. Veinot

Y-12 National Security Complex

# Evolution of Recommendations

- Three major revisions to ICRP recommendations
- 1977 – ICRP-26
- 1991 – ICRP-60
- 2007 – ICRP-103
- All are risk-based approaches
- All use organ/tissue risk factors

# System of Radiation Protection



# ICRP-26

- “Dose Equivalent” – organs/tissues
- Organ/Tissue weighting factors ( $w_T$ )
- Effective Dose Equivalent ( $H_E$ )
- Dose modifier = quality factor ( $Q$ )
- $Q$  based on LET in water ( $\text{keV}/\mu\text{m}$ )
- $Q$  based on spectrum in organ/tissue
- Mathematical phantom
- Remainder organs
- Non-additive

# ICRP-60

- “Equivalent Dose” – organs/tissues
- Organ/Tissue weighting factors ( $w_T$ )
- Effective Dose ( $E$ )
- Dose modifier = radiation weighting factor ( $w_R$ )
- $w_R$  based on spectrum incident on phantom
- Mathematical phantom
- Remainder organs
- Non-additive

# ICRP-26 and ICRP-60 Protection Quantity Calculations

- ICRP-26 Effective Dose Equivalent,  $H_E$

$$H_T = \frac{\int \int Q(L) D_L dL dm}{m}$$

$$H_E = \sum_T w_T H_T$$

- ICRP-60 Effective Dose,  $E$

$$E = w_R * \sum_T D_T * w_T$$


( $w_R$  based on spectrum incident on phantom.  
Single value for all organs)



# ICRP-103

- “Equivalent Dose” – organs/tissues
- Organ/Tissue weighting factors ( $w_T$ )
- Effective Dose ( $E$ )
- Dose modifier = radiation weighting factor ( $w_R$ )
- $w_R$  based on spectrum incident on phantom
- Voxel phantom (male and female) (ICRP-110)
- Remainder organs, but specified
- Sex averaging

# ICRP-103 Protection Quantity Calculations




# Calculations


- Monte Carlo
- Various geometries (AP, PA, LLAT, RLAT, ISO, ROT)
- Absorbed dose in organs
- Modifier (QF or  $w_R$ )
- Remainder organs
- Weighted sum

# Phantom Models

- Through ICRP-60 mathematical models used. ICRP-103 uses volumized pixel (voxel) phantoms developed from high-res scans.



# Protection Quantity DCFs




# Operational Quantities

- Defined by ICRU
- Intended to be measurable (and calculable)
- Based on simple phantom designs
- Based on standard (but unattainable conditions)
- Should conservatively approximate protection quantities

# Personal Dose Equivalent



- Monitoring for individuals
  - Defined in the body – multi-valued quantity
  - Usually the trunk = 30 cm X 30 cm X 15
- ICRU Slab



# Ambient Dose Equivalent

- Area monitoring
- Defined in the ICRU sphere (15 cm radius)
- Instrument calibrations

Aligned  
and  
expanded  
field







# ICRP/ICRU DCFs

- ICRP-74
- ICRP revising ICRP-74 now (to include ICRP-103)
- Includes ICRP-103 DCFs
- ICRU to update operational quantities
- No changes to  $Q(L)$ -L, so QF same
- Higher energies


# Quality and Radiation Weighting Factors




# ICRP-26 and ICRP-60 $H^*(10)$



# Protection/Operational Quantity DCFs



# Conservative Approximation?



# How Different are the New Dose Conversion Coefficients?

- **Photons**
  - The differences of effective dose conversion coefficients are lower than 10%.
- **Neutrons**
  - Generally lower (up to a factor of 2) than ICRU 57 / ICRP 74 due to the reduced  $w_R$  differences
- **Protons**
  - Generally lower than ICRU 57 / ICRP 74 due to the reduced  $w_R$
- **For some geometries greater differences are observed due to increased value of  $w_T$  for the breast**
- More data available at higher energies

# ICRP-26 Vs. ICRP-60 Source DCFs

	$^{252}\text{Cf}$	$\text{D}_2\text{O}$ $^{252}\text{Cf}$	Am-Be	Am-B	Poly. Mod. $^{252}\text{Cf}$	Pu-F	Pu-Be
ICRP-26 $H^*(10)$ (pSv-cm <sup>2</sup> )	333	93	373	378	218	333	291
ICRP-60 $H^*(10)$ (pSv-cm <sup>2</sup> )	380	107	394	410	242	384	317
Rem Ball Response ICRP-26 Cal. (counts)	333	133	334	384	220	311	272
Rem Ball Response ICRP-60 Cal. (counts)	380	152	381	438	251	355	310

Data from HPJ Vol. 95, suppl. 2 August 2008

# Conclusions

- Quality factors same in ICRP-60 and ICRP-103 (operational quantities don't change)
- $Q(L)$ -L differs from ICRP-26 to ICRP-60 (DOE impact)
- Protection quantities are generally lower
- Data to higher energies