

LA-UR-12-24066

Approved for public release; distribution is unlimited.

Title: Response of High-Tc Superconductor Metamaterials to High Intensity THz Radiation

Author(s): Grady, Nathaniel
Perkins Jr., Bradford G.
Hwang, Harold Y.
Brandt, Nate
Torchinsky, Darius
Singh, Ranjan
Yan, Li
Jia, Quanxi
Trugman, Stuart A.
Taylor, Antoinette J.
Nelson, Keith A.
Chen, Hou-Tong

Intended for: SPIE Optics+Photonics, 2012-08-12/2012-08-16 (San Diego, California, United States)



Disclaimer:

Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by the Los Alamos National Security, LLC for the National Nuclear Security Administration of the U.S. Department of Energy under contract DE-AC52-06NA25396. By approving this article, the publisher recognizes that the U.S. Government retains nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcher's right to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.

Response of High- T_c Superconductor Metamaterials to High Intensity THz Radiation

Nathaniel K. Grady

Bradford G. Perkins Jr., Harold Y. Hwang, Nate Brandt,
Darius Torchinsky, Ranjan Singh, Li Yan, Daniel Trugman,
Stuart A. Trugman Antoinette J. Taylor, Keith A. Nelson,
Hou-Tong Chen

Los Alamos National Lab
Massachusetts Institute of Technology




Introduction

YBCO

- High T_c superconductor
- Epitaxially grown on 0.5 mm thick LaAlO_3 substrates by pulsed laser deposition
- $T_c \approx 91 \text{ K}$


High intensity THz-pump THz-probe spectroscopy

- Metamaterials:
 - Active devices
- Thin Films:
 - Mechanism of nonlinearity



Spectroscopic Characterization of YBCO


- THz Time-Domain Spectroscopy
 - Amplitude and phase
 - Complex conductivity at 0.6 THz
- Conductivity above T_c
 - Real conductivity – normal carrier population
- Superconductivity
 - Transition temperature ~ 90 K
 - Imaginary conductivity grows as temperature drops
- Two-fluid model
 - Normal carrier fraction: $f_n(T)$
 - Superfluid fraction: $f_s(T)$





$$\sigma_{re} = \frac{ne^2}{m^*} \cdot \frac{f_n(T) \cdot \tau}{1 + \omega^2 \tau^2}$$

$$\sigma_{im} = \frac{ne^2}{m^*} \cdot \left[\frac{f_n(T) \cdot \tau}{1 + \omega^2 \tau^2} + \frac{f_s(T)}{\omega} \right]$$


High Intensity THz Source: Tilted Pulse Front Optical Rectification



YBCO Metamaterials




- Metamaterial fabricated from 100 nm thick YBCO film:
 $g = 4 \mu\text{m}$, $w = 4 \mu\text{m}$, $l = 46 \mu\text{m}$, $p = 46 \mu\text{m}$



H.-T. Chen et al., PRL 105, 247402 (2010)


Intensity-Dependent Transmission: Metamaterial



Increase incident intensity:



- Transmission increases: turning off resonance
- Resonance frequency shifts

Intensity-Dependent Transmission: Metamaterial




Increase incident intensity:


- Red-shift at low temperature
- Blue-shift at high temperature
- Transmission increases





High Intensity THz Source: Tilted Pulse Front Optical Rectification





Dynamics: Metamaterial




- Measure THz-TDS trace at every pump-probe delay
- Transmission shifts to higher energy and increases in strength with increasing pump-probe delay




Dynamics: Metamaterial




- Measure THz-TDS trace at every pump-probe delay
- Transmission shifts to higher energy and increases in strength with increasing pump-probe delay
- Two component decay



THz Field Dependent Transmission Spectra: 50 nm thick film






50 nm YBCO Film Conductivity





- THz-TDS: both magnitude and phase of electric field measured \therefore can extract complex refractive index
- Two Fluid Model:
 - Residual normal carrier Drude response + Superconducting Cooper pairs: $\tilde{\sigma} = \tilde{\sigma}_n + \tilde{\sigma}_s$
 - $\sigma_{im} = \frac{ne^2}{m} \left[\frac{f_n \omega \tau^2}{1 + \omega^2 \tau^2} + \frac{f_s}{\omega} \right]$
- Superconductivity decreases with increasing THz field strength
- Breaking cooper pairs: Impact ionization? Ballistic acceleration of supercurrent?
- Change in conductivity \rightarrow Shift in metamaterial resonance

Conclusions



Investigated the spectral and dynamic response of YBCO films and metamaterials to high intensity THz radiation




$$\sigma_{im} = \frac{ne^2}{m^*} \cdot \left[\frac{f_n(T) \cdot \tau}{1 + \omega^2 \tau^2} + \frac{f_s(T)}{\omega} \right]$$





Acknowledgements:

Los Alamos National Laboratory LDRD Program, Center for Integrated Nanotechnologies

Conclusions




Investigated the spectral and dynamic response of YBCO films and metamaterials to high intensity THz radiation



Acknowledgements:


Los Alamos National Laboratory LDRD Program, Center for Integrated Nanotechnologies

50 nm YBCO Film Conductivity




- THz-TDS: both magnitude and phase of electric field measured \therefore can extract complex refractive index
- Two Fluid Model:
 - Residual normal carrier Drude response + Superconducting Cooper pairs: $\tilde{\sigma} = \tilde{\sigma}_n + \tilde{\sigma}_s$
 - $\sigma_{im} = \frac{ne^2}{m} \left[\frac{f_n \omega \tau^2}{1 + \omega^2 \tau^2} + \frac{f_s}{\omega} \right]$
- Superconductivity decreases with increasing THz field strength
- Change in conductivity \rightarrow Shift in metamaterial resonance


YBCO Metamaterials



- Metamaterial fabricated from 100 nm thick YBCO film: $g = 4 \mu\text{m}$, $w = 4 \mu\text{m}$, $l = 46 \mu\text{m}$, $p = 46 \mu\text{m}$
- Resonance frequency shifts with temperature




■ ds




YBCO

- High- T_c Superconductor




YBCO Crystal
Structure

Dynamics: THz-Pump / THz-Probe




- Peak Scan: set electro-optic sampling delay to measure peak probe electric field, scan pump-probe delay
- Decay constant consistent with optical-pump / THz-probe measurements

Dynamics: Temperature Dependence




- Decay constant increases with temperature

50 nm YBCO Film Conductivity




- Change in conductivity → Shift in metamaterial resonance

THz Field Dependent Transmission Spectra: 50 nm thick film




High Intensity THz Source: Tilted Pulse Front Optical Rectification

- Generate THz fields up to 200 kV / cm at the sample
- Tilted pulse front allows “velocity matching” between the THz and optical pulses in LiNbO₃
- Use diffraction grating to tilt the pulse front
- Measurements performed in Keith Nelson’s lab at MIT




High Intensity THz Source: Tilted Pulse Front Optical Rectification

- Generate THz fields up to 200 kV / cm at the sample
- Tilted pulse front allows “velocity matching” between the THz and optical pulses in LiNbO_3
- Use diffraction grating to tilt the pulse front
- Measurements performed in Keith Nelson’s lab at MIT




THz Intensity Dependent Transmission




- Integrated THz waveform intensity: $T = \int |E_{\text{samp}}|^2 dt / \int |E_{\text{ref}}|^2 dt$
- Both axes now in intensity

THz Intensity Dependent Transmission



- Normalize: divide by transmission at lowest intensity
- Relative change in transmission largest at 40 K


THz Intensity Dependent Transmission



Fit 20K and 99K transmission to polynomial:


- 20K: Quadratic
- 99K: Linear

Dynamics: THz-Pump / THz-Probe




- Peak Scan: set electro-optic sampling delay to measure peak probe electric field, scan pump-probe delay
- Decay constant consistent with optical-pump / THz-probe measurements

Dynamics: Temperature Dependence



- Decay constant increases with temperature

Intensity-Dependent Transmission: Metamaterial



- Resonance red-shifts at low temperature, blue-shifts at high temperature

