

LA-UR-13-26476

Approved for public release; distribution is unlimited.

Title: Passive Nondestructive Assay of Nuclear Materials

Author(s): Santi, Peter A.

Intended for: Workshop on Nuclear Material Accounting and Control: Current Practices and Future Prospectives, 2013-10-03/2013-10-04 (Mumbai, India)

Issued: 2013-08-15



Disclaimer:

Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by the Los Alamos National Security, LLC for the National Nuclear Security Administration of the U.S. Department of Energy under contract DE-AC52-06NA25396. By approving this article, the publisher recognizes that the U.S. Government retains nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcher's right to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.

Passive Nondestructive Assay of Nuclear Materials

Dr. Peter A. Santi
Los Alamos National Laboratory

October 3, 2013

**Workshop on Nuclear Material Accounting and Control:
Current Practices and Future Prospectives**
Homi Bhabha National Institute
Aushaktinagar, Mumbai, India

Importance of Non-Destructive Assay Measurements

- NDA measurements involve the detection and analysis of radiation emitted from Special Nuclear Materials (SNM) to detect, identify, locate, and often quantify the composition and/or mass of material.
- NDA measurements have several advantages over DA measurements:
 - produce faster results
 - can be performed with the material in situ
 - produce no waste
- Results from NDA measurements are used for a wide range of facility operations including material control and accounting (MC&A), nuclear security, criticality safety, and waste management.




Spill at Processing Facility

Role of NDA Measurements - Safeguards

- Most frequently implemented measurement techniques to reliably determine the characteristics of SNM (e.g. 65-75% of all Pu inventory measurements at LANL performed using NDA).
- NDA measurements for MC&A purposes include:
 - Accountability Measurements
 - Confirmatory Measurements
 - Shipper/Receiver Measurements
 - Process control measurements
- Impact of poor quality or erroneous NDA measurement results include possible safety impacts (criticality safety), security impacts (loss of nuclear material) and economic impacts (cost of re-measuring items).

NDA Measurement Techniques



Gamma-Ray NDA

Enrichment or Isotopic Measurements


- ^{235}U enrichment (NaI, HPGe)
- Pu isotopic composition (HPGe)

Measuring SNM mass in Nuclear Waste

- Segmented Gamma-Ray Scanner
- Tomographic Gamma-Ray Scanner


Hold-up measurements (Quantifying amount of material in pipes/ductwork/etc)

Origin of X-rays and Gamma-rays



Gamma-rays



[Half-life = 704,000,000 y]



Gamma Rays:


185.7 keV	57 %
143.8 keV	11 %
163.4 keV	5 %
205.3 keV	5 %

^{235}U Decay Scheme and Branching Ratios




Uranium Gamma-Ray Spectrum (HPGe)


50.5% enrichment (HEU)



Various Gamma-Ray Detector Resolutions



^{235}U Enrichment Measurement with NaI Detector




Infinite Thickness Method

Detector views the item through a collimator.

Visible volume determined by collimator size and the absorption coefficient of U.

The measured 186-keV intensity is proportional to the ^{235}U in the visible volume. For an enrichment measurement on an infinite item thickness, the detector views a portion of the item volume through a collimator. **Isotopic uniformity is a requirement of this type of measurement.**



Accuracy of the Infinite Thickness Method

- Method requires one or two NM standards to calibrate the system
- Corrections required for container wall thickness and differences in chemical composition between item being assayed and NM standards
- 1-5% typically, depending on the item
- NaI and HPGe can provide similar accuracy
- In special applications involving installed systems, 0.1-0.2% accuracy is possible.


Ratio-Based Isotopic Measurements

$$\frac{N(E_1)}{N(E_2)} = \frac{C(E_1)}{C(E_2)} \cdot \frac{T_{1/2}(1)}{T_{1/2}(2)} \cdot \frac{BR(E_2)}{BR(E_1)} \cdot \frac{RE(E_2)}{RE(E_1)}$$

$N(E_i)$	Atom Number for Isotope i
$C(E_i)$	Photo-peak Area at Energy E_i
$T_{1/2}(i)$	Half Life of Isotope i
$BR(E_i)$	Branching Ratio at Energy E_i
$RE(E_i)$	Relative Efficiency at Energy E_i

The Isotopic Ratio Formula


$$\frac{N(E_1)}{N(E_2)} = \frac{C(E_1)}{C(E_2)} \cdot \frac{T_{1/2}(1)}{T_{1/2}(2)} \cdot \frac{BR(E_2)}{BR(E_1)} \cdot \frac{RE(E_2)}{RE(E_1)}$$



All these values are obtained from the spectrum itself or from standard nuclear references; no calibration is necessary!

Uranium Gamma-Ray Spectrum (HPGe)

50.5% enrichment (HEU)



Calculating Isotopic Fractions

Based on measuring relative intensities of gamma-ray lines, we can get:

$$\frac{^{234}\text{U}}{^{238}\text{U}} \quad \frac{^{235}\text{U}}{^{238}\text{U}}$$

And we know that:

$$^{234}\text{U} + ^{235}\text{U} + ^{238}\text{U} = 100\%$$

So

$$\frac{^{234}\text{U}}{^{238}\text{U}} + \frac{^{235}\text{U}}{^{238}\text{U}} + \frac{^{238}\text{U}}{^{238}\text{U}} = \frac{1}{^{238}\text{U}}$$

We can solve the above equation for ^{238}U which allows us to calculate ^{234}U and ^{235}U from the original ratios:

$$\frac{^{234}\text{U}}{^{238}\text{U}} \times ^{238}\text{U} = ^{234}\text{U} \quad \frac{^{235}\text{U}}{^{238}\text{U}} \times ^{238}\text{U} = ^{235}\text{U}$$

Independence of Analysis

Using **relative** efficiency and isotope **ratios** makes analysis independent of:

- **Item Characteristics**

- Size
- Shape
- Physical and Chemical Composition
- Packaging
- Filtering

- **Data Acquisition Limitations**

- Pulse Pile-up
- Deadtime

Two commercially available analysis programs

- MGA/MGAU (Multi Group Analysis) (R. Gunnick, LLNL)
 - Can analyze low energy region (94-104 keV) or high energy region (<1 MeV)
 - Rigid analysis routine
 - User friendly
- FRAM (Fixed energy Response function Analysis with Multiple efficiencies) (T. Sampson and D. Vo, LANL)
 - Can analyze gamma-rays up to more than 1 MeV
 - User configurable analysis (flexible)
 - Learning curve associated with initial use of code

Why Measure Pu-Isotopic Composition?

- **Neutron Coincidence/Multiplicity Counting**

- $^{240}\text{Pu}_{\text{eff}} = (2.52 \times ^{238}\text{Pu}) + (1.00 \times ^{240}\text{Pu}) + (1.68 \times ^{242}\text{Pu})$

- **Calorimetry**

$$P_{\text{eff}} = \sum_{i=1}^n R_i P_i$$

- n = number of isotopes in the item
 - R_i = mass fraction ($m_i/M_{\text{total Pu}}$) of the i^{th} isotope
 - P_i = specific power of the i^{th} isotope

Relative Isotopic Error


Isotopic Precision varies by isotope:

<u>Isotope</u>	<u>% RSD</u>
^{238}Pu	<1 - 10
^{239}Pu	0.1 - 0.5
^{240}Pu	0.5 - 4
^{241}Pu	0.2 - 0.8
^{241}Am	0.2 - 10



P_{eff}	0.2 - 2.0
$^{240}\text{Pu}_{\text{eff}}$	0.5 - 4.0

Neutron Signatures for Passive NDA


Spontaneous fission



(α, n) neutrons



Induced fission




Spontaneous fission

<u>Nuclide</u>	<u>Specific Intensity [n/(g.s)]</u>	
²³⁴ U	0.005	
²³⁵ U	0.0003	
²³⁶ U	0.0055	
²³⁸ U	0.0136	
²³⁸ Pu	2590.	
²³⁹ Pu	0.022	
²⁴⁰ Pu	1020.	$^{240}\text{Pu}_{\text{eff}} = (2.52 \times ^{238}\text{Pu}) + (1.00 \times ^{240}\text{Pu}) + (1.68 \times ^{242}\text{Pu})$
²⁴¹ Pu	~0.05	
²⁴² Pu	1720.	
²⁴¹ Am	1.18	
²⁴² Cm	2.1×10^7	
²⁴⁴ Cm	1.08×10^7	
²⁵² Cf	2.34×10^{12}	

N. Ensslin, et al., LA-13422-M (1998)

Passive Neutron Counter



- Fissioning source surrounded by neutron detectors
- Neutron detectors are nominally ^3He proportional counters which have high detection efficiency for thermal neutrons
- To thermalize the neutrons, ^3He detectors are embedded in moderating matrix such as polyethylene.

Neutron Multiplicity Counting

Standard Point Model Multiplicity Equations for Pu:

$$S = m_{eff} F_0 \varepsilon \nu_{s1} M (1 + \alpha)$$

$$D = \frac{1}{2} m_{eff} F_0 \varepsilon^2 f_d M^2 \left\{ \nu_{s2} + \left(\frac{M-1}{\nu_{i1}-1} \right) \nu_{s1} (1 + \alpha) \nu_{i2} \right\}$$

$$T = \frac{1}{6} m_{eff} F_0 \varepsilon^3 f_t M^3 \left\{ \nu_{s3} + \left(\frac{M-1}{\nu_{i1}-1} \right) [3\nu_{s2}\nu_{i2} + \nu_{s1}(1 + \alpha)\nu_{i3}] + 3 \left(\frac{M-1}{\nu_{i1}-1} \right)^2 \nu_{s1}(1 + \alpha)\nu_{i2}^2 \right\}$$

Converts S, D, T counting rates into properties of plutonium bearing item:

- effective mass of ^{240}Pu in item (m_{eff})
- ratio of (α, n) to spontaneous fission (SF) neutrons (α)
- multiplication (M)

Total Pu mass: $m = \frac{m_{eff}}{^{240}\text{Pu}_{eff}}$

Note: Measuring S and D known as coincidence counting
Measuring S, D, and T known as multiplicity counting

Comparison of Coincidence and Multiplicity Counting

Coincidence Counting


- Pure samples
- Results dependent on knowledge or assumptions concerning α and M
- In general, shorter measurement times than multiplicity counter measurements
- Coincidence counters less expensive than multiplicity counters

Multiplicity Counting

- Both pure and impure samples ($\alpha < 10$)
- Information on item α and M determined from measurement
- In general, longer measurement times than coincidence counting measurements
- Multiplicity counters more expensive than coincidence counters.
- Multiplicity counter can be used as coincidence counter

Epithermal Neutron Multiplicity Counter (ENMC)

H.O. Menlove and C.D. Rael, LA-UR-05-3041 (2005)



$\varepsilon = 64\%$ (Pu energy)
Die-away time = 19.1 μs



Neutron Multiplicity Uncertainty

N. Ensslin, et al.,
LA-13422-M (1998)

Table 7.1. Summary of past or expected multiplicity counter performance on various nuclear material categories. A well-designed multiplicity counter with roughly 50% to 55% detection efficiency is used, unless otherwise specified in the text.


Nuclear Material Category	SNM Mass (g)	$(\alpha, n)/sf$ rate α	Counting Time (s)	Assay Precision (% RSD)	Assay Bias (%)	References
Plutonium Metal	2000 g	0 to 0.2	1000 s	7.1%	-10.6%*	Langner 91b
	2000 g	0 to 0.2	3000 s	5.1%	-4.7%*	Krick 92b
	4000 g	0 to 0.2	1800 s	2.0%	0.0%	Langner 93b
	200-4000 g	0 to 1.3	3600 s	3.3%	-1.8%	Ensslin 98
Plutonium Oxide	2000 g	1	5000 s	0.7%	0.6%	Langner 91b
	1000 g	1	3000 s	0.8%	-2.7%	Krick 92b
	1000 g	1	1800 s	2.2%	-0.1%	Langner 93b
	4000 g	1-4	1800 s	3.0%	2.4%	Stewart 95
	1000 g	1-4	600 s	1-3%	0.9%	Stewart 98
Plutonium Scrap	100 g	5	1000 s	12%	2-5%	Langner 92
	100-1200 g	1-6	3600 s	4.5%	1.5%	Ensslin 98
Plutonium Residues	120 g	13-29	3000 s	20%	2-10%	Krick 92b
	300 g	7-34	3600 s	18.9%	-4.0%	Ensslin 98
	20-100 g	8-30	3600 s	7%	7%	Langner 98
	100 g	5-9	3600 s	8.7%	3.2%	Langner P.C.
Plutonium Waste (estimated)	1 g	1	1000 s	2%	1-2%	Ensslin 95
	1 g	5	1000 s	10%	2-5%	Ensslin 95
	1 g	20	1000 s	50%	5-10%	Ensslin 95
Plutonium Oxide in Excess	1000 g	1 - 10	1500 s	6.0%	0.02%	Stewart 96
	1000 g	1 - 8	1000 s	5.0%	1.0%	Stewart 97(PC)
Weapons	4000 g	1 - 6	1800 s	4.2% ^b	0.8%	Langner 96b
Materials	4000 g	1 - 6	1800 s	5.8% ^c	-1.0%	Langner 97b
Mixed Uranium/Plutonium Oxide	300 g	1 - 2	1000 s	1-2%	1-3%	Menlove 93
Large Drum Inventory Verification	1 - 4000 g	1 - 6	6 - 12 h	10.2%	-0.5%	Rinard 97
	1 - 4000 g	7 - 50	6 - 12 h	N/A	N/A	Rinard 97

* Assay bias quoted without multiplication correction curve for metal.

^b Assay precision based on counting statistics, gamma-ray isotopics, and scatter relative to calorimetry.

^c Assay precision based on counting statistics and scatter relative to destructive analysis.

Calorimetric assay compliments other NDA techniques




Calorimetry

- The most accurate and precise NDA measurement of Pu mass. The precision nominally ranges from:
 - ~0.5% for low power items (≤ 0.2 W)
 - ~0.1% for higher power items (≥ 1 W)
- You can't shield the heat of the material
- Inherently matrix independent
- Answer is bias free
- Integrates over total sample volume
- No representative physical standards needed

Calorimetric assay is the foundation for NDA of Pu in the US DOE.

Calorimetry

- Calorimetry – quantitative measurement of heat
- Calorimetric assay – Determination of the mass of radioactive material through the measurement of its thermal power by calorimetry and isotopic composition by gamma-ray or mass spectrometry.
- The approach to thermal equilibrium as a function of time is exponential in nature



D.S. Bracken, et al. "Application Guide to Safeguards Calorimetry", LA-13867-M

Calorimeter Measurement Uncertainty

Heat standard Power, Watts	Calorimeter diameter, m	Calorimeter Type, operation mode	Number Of Meas.	Precision, % RSD	Bias, %
98.0	0.06	rod, servo	29	0.065	0.02
3.5	0.15	rod, servo	55	0.09	0.00
4.0	0.25	twin, passive ¹	22	0.05	0.03
4.9	0.30	twin, passive ¹	34	0.06	0.05
0.0786	0.04	Solid state, passive ²	10	0.23	0.001

¹Pooled results from two calorimeters.

²Measurements made in laboratory.

D.S. Bracken, et al. "Application Guide to Safeguards Calorimetry", LA-13867-M

Calorimetric Assay measurement technique

- Measure total *Sample Power* in a calorimeter (Watts)
- Measure isotopic composition of sample, including all significant heat producing isotopes (e.g. ^{241}Am)
- Compute *Effective Specific Power*, P_{eff}

$$P_{eff} = \sum P_i \cdot f_i$$

P_i – Watts/gram for isotope i

f_i – Isotopic fraction in sample relative to total Pu

i – Pu isotopes, ^{241}Am

$$\text{grams Pu} = \frac{\text{Sample Power (Watts)}}{P_{eff} \text{ (Watts/g Pu)}}$$

Isotopics and Calorimetry

Heat due primarily to **alpha decay (not fission)**, except ^{241}Pu which is due to beta decay.

Isotope	Half-Life (Yr)	Specific Power (W/g)
^{238}Pu	87.7 ± 0.1	$0.56757 \pm 0.05\%$
^{239}Pu	24110 ± 30	$0.0019288 \pm 0.02\%$
^{240}Pu	6561 ± 7	$0.0070824 \pm 0.03\%$
^{241}Pu	14.325 ± 0.006	$0.003412 \pm 0.06\%$
^{242}Pu	3.75×10^5	$0.0001159 \pm 0.22\%$
^{241}Am	432.6 ± 0.6	$0.1142 \pm 0.37\%$
^{233}U	1.592×10^5	0.00028
^{234}U	2.455×10^5	0.00018
^{235}U	7.04×10^8	5.996×10^{-5}
^{238}U	4.468×10^9	8.51×10^{-6}

Calorimetric Assay Importance to Safeguards at LANL

D.S. Bracken, et al. "Application Guide to Safeguards Calorimetry", LA-13867-M

Table 1. Measurement Methods for LANL Pu Inventory Mass % for Each Material Form ¹				
Material form	Calorimetry + gamma spec	Analytical chemistry	Neutron counter + gamma spec	Segmented gamma scanner
Metal	71%	29%	0.3%	0%
Compounds pure	64%	35%	0.9%	0.3%
Compounds impure	72%	23%	2.6%	2.6%

¹From LANL Material Accounting and Safeguards System (MASS) database April 1999.

Routine Plutonium Calorimetric Assay

- Shipper receiver measurements
- **Outlier Resolution**
- Accountability Measurements
- **Calibration of NDA standards**
- Process Control Measurements

Only Calorimetric Assay

Summary

- NDA measurements play an important role in managing nuclear material through their ability to detect, identify, locate, and often quantify the composition and/or mass of material within a relatively short amount of time
- The three main passive NDA measurement techniques that are utilized in managing nuclear material are
 - Gamma-ray spectroscopy (composition)
 - Neutron Multiplicity counting (spontaneous fission rate of Pu items)
 - Calorimetry (heat production from decay of Pu bearing items)
- Through combination of Gamma-ray spectroscopy and either neutron multiplicity counting or calorimetry, mass of Pu bearing items can be measured.