

Direct observation of effective atomic diffusion distances in Zr/2Al multilayers due to self-propagating reactions

Robert V. Reeves, David P. Adams, Paul G. Kotula,
James A. Ohlhausen, Mark A. Rodriguez
Sandia National Laboratories

Robert Grubbs, Private

2013 AVS Symposium
October 2013




Sandia National Laboratories is a multi-program laboratory managed and operated by Sandia Corporation, a wholly owned subsidiary of Lockheed Martin Corporation, for the U.S. Department of Energy's National Nuclear Security Administration under contract DE-AC04-94AL85000.



**Sandia
National
Laboratories**


Experimental Material: Zr/2Al

- $\text{Zr} + 2\text{Al} \rightarrow \text{ZrAl}_2$; $\Delta H_{\text{exp}} = -46 \text{ kJ/mol atoms}$
(de Boer, Cohesion in Metals)
- Typical design of sputtered reaction foils:
single bilayer per foil, total thickness = $5.0 \mu\text{m}$
sputter deposited (pure) metals, full density





Nanolaminates

Assumed Reaction Progression




- Atoms diffuse to center line of neighboring reactant layer
- Final phase formed once this distance is traveled
- Can other mechanisms affect diffusion distance?
 - Dissipative thermodynamics
 - High temperature diffusion modes
 - Defects, grain boundaries



Marker Layer Design

Zr/2Al Nanolaminates with one Hf layer

- Hafnium replaces Zr at a single layer
- Hafnium and Zr are miscible with no distinct intermetallic phases
- Similar product phases with Al
- Similar chemistry for Zr and Hf, due to lanthanide contraction




ZrAl ₂	T _m = 1660 °C	HfAl ₂	T _m = 1650 °C
	ΔH = -46 kJ/mol		ΔH = -48 kJ/mol
hP12	a = 0.52824	hP12	a = 0.525
	b = 0.52824		b = 0.525
	c = 0.87482		c = 0.868
Zr ₂ Al ₃	T _m ≈ 1590 °C	Hf ₂ Al ₃	T _m = 1660 °C
	ΔH = -47 kJ/mol		ΔH = -48 kJ/mol
oF40	a = 0.9601	oF40	a = 0.9529
	b = 1.3906		b = 1.3763
	c = 0.5574		c = 0.5525

Marker Layer Design Revealed

Zr/2Al Nanolaminates with one Hf layer



- Marker layer distinct
- Hf placed at center of multilayer
- Clearly resolvable with z-contrast and EDS in TEM



Phase Identification

Zr/2Al and Hf/2Al Standards


- Zr/2Al films reacted in vacuum (10 mT)
- ZrAl_2 (~60% wt%) & Zr_2Al_3 (~40% wt%) phases identified by XRD
 - Hf/2Al films reacted in vacuum (10mT)
 - Phase pure HfAl_2



Marker Layer Design

Zr+(Hf)/2Al Nanolaminates


- Reaction disperses Hf marker material







Marker Layer Design

Zr+(Hf)/2Al Nanolaminates

- Reaction disperses Hf marker material
- 14 kx magnification: 5 x 5 μm ROI
- Probed through EDS and SIMS




Variation at smaller length scales




Marker Analysis by SIMS

Zr+(Hf)/2Al Nanolaminates


- Sputter area = $200 \times 200 \mu\text{m}^2$
- Analysis area = $50 \times 50 \mu\text{m}^2$ – much greater area than EDS
- Hf-baseline subtracted from signal




Diffusion model – Assumed progression




IR imaging of temperature history



- Plot is average meas. temp of surface in image (4.8 x 3.8 mm)
- Time average over 46 ms is 690°C (963 K)
- Information for comparison to best fit results from diffusion model




Diffusion model



50 nmBL

- Integration of EDS Hf signal over full 14 kx image ($5 \times 5 \mu\text{m}$)
- Average D is consistent with solid-state diffusion

Diffusion model




Integrated profile across 40
nm path at location shown,
y=50

80 kx, EDS

Best fit $D = 2.5 \times 10^{-12} \text{ m}^2/\text{s}$


Diffusion model

- Integrated profile across 40 nm path at location shown
- 80 kx, EDS
- Best fit $D = 2.5 \times 10^{-12} \text{ m}^2/\text{s}$



Diffusion model – Compare to SIMS data

- Best fit $D = 2.5 \times 10^{-12} \text{ m}^2/\text{s}$
- Average D is consistent with solid-state diffusion, at 960 K



Conclusions

- TEM-EDS and SIMS methodologies allow spatial tracking of marker layer species in reacted multilayers
- Resolution
 - TEM-EDS: spatial: nm, concentration: 0.1%
 - SIMS: concentration: ppm
- Hf marker layers showed atomic diffusion much greater than expected
 - 100's of nm vs. 1's of nm
 - Most likely occurred during elevated temperatures, post-reaction
- Will investigate rapidly quenched materials and unstable fronts