

Exceptional service in the national interest



Highly Porous Ceramic Foams from Magnesium Oxide Stabilized Pickering Emulsions

Christine Roberts, Lindsey Hughes, Dave Barringer,
Lisa Mondy, Anne Grillet, Chris Diantonio,
Tom Chavez, and David Ingersoll

2013 Society of Rheology
Pasadena, CA


February 10-14, 2013



Sandia National Laboratories is a multi-program laboratory managed and operated by Sandia Corporation, a wholly owned subsidiary of Lockheed Martin Corporation, for the U.S. Department of Energy's National Nuclear Security Administration under contract DE-AC04-94AL85000.

Overview

Goal: Produce *sintered ceramic foam* to electrically isolate the anode & cathode layers in batteries while allowing free ion transport




Current battery separators:

- Polymer separators for Lithium Ion batteries are susceptible to thermal runaway
 - Boeing 787 Dreamliner
- Pressed pellets used for molten salt batteries are expensive to manufacture and need to be thick to be robust enough to handle
- Ceramic foam scaffold backfilled with electrolyte has advantages in either case


Requirements

Desired scaffold properties

- Porous, but pores small enough to retain electrolyte
- Permeable to ions (connected porosity with low tortuosity)
- Robust enough to withstand manufacturing processes
- Chemically compatible in a wide range of batteries → Magnesium Oxide (MgO)




Separator must be flat and of an appropriate shape



2 mm diameter post driven into sample. Fracture force measured.

Processability



- Can large quantities be processed easily?
- Can robust green ceramic be processed into an appropriate shape?
- Is the sintered foam strong enough?
- Can it be backfilled with electrolyte?
- Does it allow appropriate ionic conductivity?



The ceramic foams are backfilled with conductive liquid and impedance tested. Molten salt electrolyte requires high temp (>370C) & inert atmosphere glove box.





Advanced Ceramics Processes

- Sacrificial template method with tape casting
 - Tape cast ceramic with sacrificial particles that generate pores within the microstructure during sintering
 - Tape cast can be layered to various thickness and punched into variety of shapes
- Foam replication
 - Foam is infiltrated with a ceramic suspension, dried, and sintered, which removes the original foam.
 - Tested MgO/toluene slip and toluene-resistant polyurethane foams.
- Emulsion-based approach
 - Extremely stable MgO Pickering emulsion can be tape cast or molded
 - Nanostructured ceramic allows high porosity and good mechanical strength
 - **Focus of this talk**




Pickering Emulsion

- After Akartuna et al. (2008), ceramics are made from particle-stabilized oil/water emulsions.
- We are focused on MgO ceramics
 - After Hibner et al. J. European Ceramic Soc. 1997 and Gonzenbach et al. Langmuir 2006, we treated MgO particles with carboxylic and dicarboxylic acids to make them neutrally wetting
- Resulting emulsion so stable that the liquids can be dried and leaving a structure of particles behind
- **Ceramic foams with porosity up to 94%**



Large Parameter Space Explored




Process Variables:

- MgO particle size & concentration,
- Milling time
- Amphiphile chain length & concentration
- Binder type & concentration
- Octane amount
- Mixing time & speed

Characterization of emulsions:

- Light scattering (MgO aggregate size)
- Thermal gravimetric analysis (TGA) for brucite amount
- Microscopy for droplet size
- Cryogenic scanning electron microscopy (SEM) for emulsion microstructure




Process Variables:

- Tape casting or cast in a mold
- Drying time
- Humidity
- Sintering temperature
- Sintering time and ramp rate

Characterization of green and sintered ceramics:

- Measure shrinkage
- Measure density and porosity
- SEM (microstructure)
- Electrochemical impedance spectroscopy (permeability)
- Indentation (fracture strength)

Ionic Conductivity




Impedance Spectroscopy

Sample filled with KCl + water solution
AC voltage applied across electrodes
Impedance measured vs AC frequency


$$\text{MacMullin \#} = \frac{\text{sample resistance}}{\text{solution resistance}}$$

Fracture strength







TA.XTPlus Texture Analyzer

Wide range of probe shapes
Strain rates 0.01 - 40 mm/s





Emulsion Characterization



- Cryo-SEM shows that MgO particles do coat droplet surfaces
- Microscopy for droplet sizing
- Droplet size depends most strongly on mixing speed.
- Too much mixing energy (e.g. ultrasonic mixer) seems to knock the particles off the droplets and destabilize the emulsion
- Particle suspension were ball milled to disperse in solution and break up aggregates



Emulsion Properties






- Valeric acid is important for stability of the emulsion






Emulsion Properties

- Basic recipe - %MgO, amphiphile, binder, octane, mixing speed
- Sinter with ?hr ramp and max temperature
- Many processing parameters, but many do not seem to affect the quality of the ceramic foam





Drop Size

- We can manipulate oil drop size, but that doesn't seem to influence properties





Controlling Porosity

- Fraction of octane is the main control for sintered porosity and also strength of the resulting ceramic foams





Ionic Conductivity

- Green Porosity → Sintered Porosity → Connected Porosity




- Ionic Conductivity very sensitive to connected porosity




Microstructure Key to Permeability

- Pickering emulsions most stable with H_2O -based formulation, leading to MgO hydrolyzing to $\text{Mg}(\text{OH})_2$
- Slow drying minimizes shrinkage, maximizes porosity, and allows brucite crystal formation
- MgO - H_2O gels with similar low MgO concentrations result in lower permeability than emulsions





Slow drying leads to less shrinkage = higher porosity



SEM images show emulsion microstructure evolution as it is allowed to dry for various amounts of time, forming brucite crystals (Unsinerted)

Brucite Formation


- MgO hydrolyzes to $\text{Mg}(\text{OH})_2$
- Thermogravimetric analysis (TGA) quantifies amount of brucite
 - After 24 hrs ball milling MgO in water, 92 wt% brucite
 - After 1 hour ball milling MgO in water, 41wt% brucite; after left in a humid atmosphere for 8 hrs, 88 wt% brucite.
- Composition influences amount of brucite: Surface-active amphiphile inhibits formation
- Modulus of gel can increase orders of magnitude with time, even at very low fractions of MgO
- Self-standing gel can be molded without making a Pickering emulsion
- Brucite converts to MgO on sintering
 - Lower initial density – greater shrinkage



Sintering Shrinkage

Higher temperatures = more shrinkage

Milled 24 hr, Dried fast




Mostly ground brucite = lots of shrinkage

$$\rho (\text{MgO}) = 3.58 \text{ g/cm}^3$$

$$\rho (\text{Mg}(\text{OH}_2)) = 2.39 \text{ g/cm}^3$$


Milled 1 hr, Dried Slow



Some large-crystal brucite
Very low shrinkage on sintering
Varied microstructure


Ionic Conductivity

- Ionic Conductivity depends more closely on connected porosity






Relatively Good Ionic Conductivity

MM = 3.2 ϕ =59%




MM = 2.6, ϕ =69%




Relatively Poor Ionic Conductivity





MM = 6.9, $\phi=54\%$



MM = 5.6, $\phi=72\%$





MM = 4.3, $\phi=81\%$




Optimize Microstructure

- Working with MgO suspensions to understand microstructure formation and control collected porosity & permeability
- Gelation is history dependent and thixotropic
- Ceramic properties as a function of milling conditions
 - 12.5% MgO in 0.1M HCl




Fracture Strength Comparison of Various Foamed Ceramics


Tape cast with and without poreformer ◆



Reticulated foam ▲




Ionic Conductivity



Impedance Spectroscopy

Sample filled with KCl + water solution
AC voltage applied across electrodes
Impedance measured vs AC frequency

Lower impedance desirable



$$MacMullin\# = \frac{\text{Sample resistance}}{\text{Solution resistance}}$$

Summary*

Goal: Create and characterize an effective, MgO -ceramic scaffolding for use as a battery separator that can be processed in large batches, molded or coated, sintered, and back-filled with electrolyte.

- Developed MgO ceramic techniques
 - Highly porous, permeable, mechanically strong

Pickering emulsion ceramic foams and replicated reticulated foams are the most permeable

Numerous parameters influence performance

Brucite formation & Microstructure need to be optimized

- Future: Demonstrate performance of new MgO structure
 - Fill with electrolyte
 - Test in battery stack


Single cell tests will determine if mechanical strength and conductivity are sufficient

*The authors would like to acknowledge support from the Laboratory Directed Research and Development Program at Sandia National Laboratories.



Effect of MgO

Microstructure Variations in Sintered Samples

24hr M



$\text{Mg}(\text{OH})_2$ particle shape
brucite



Macroscopic appearance

