

# **Adaptive Imaging for ISR Applications**

**David Wick, Mike Baker, Grant Soehnel, Brad, Boyce,  
Nicole Breivik, and Brett Bagwell**  
(Sandia National Laboratories)

**Robert Romeo and Robert Martin**  
(Composite Mirror Applications, Inc.)

**Chris Wilcox, Freddie Santiago, Ty Martinez, and Sergio Restaino**  
(Naval Research Laboratory)



**Sandia National Laboratories**

**EO/IR Systems Group**


**PO Box 5800**

**Albuquerque, NM 87185-1188**


**505-844-2517**

# Foveated Optical Adaptive Zoom (FOcAZ)

## Variable Field-of-View Imaging Sensor



10X  
Optical  
Zoom



10X  
increase  
resolution

Characterize and  
track multiple objects  
with High Resolution



Provide  
Wide FOV  
surveillance

Send relevant  
information to ground



# Airship ISR requirements

---

The parameters required to drive subsequent R&D efforts will include:

- **Wavelength** - day/night coverage requirements
- **Area coverage** - adjudicate between wide area exploration and dynamic region of interest (ROI) exploitation
- **Desired ground resolution**
- **Imagery update rates**
- **Sensitivity/Signal-to-Noise Ratio**
- **Instrument platform details**
  - **Altitude, speed, endurance, view angles**
  - **Size, weight, and power limitations**
  - **Platform jitter/PSD**
  - **Data storage/downlink requirements**
- **Ground station details**
- **Downlink data interface**

# Current or Alternative Approaches

- Gimbals/Pods (WESCAM MX-20, MTS-B, Litening, ATFLIR, WAPPS (AngelFire/BlueDevil) etc.)

- Often weigh > 200 pounds or more for 12" apertures



- Multiple staring systems

- ARGUS-IS (1.8 GPixel with a 500 pound pod)
- Gorgon Stare (1100 pounds - 12 separate cameras)

- Computational Approaches

- Coded Apertures (**LACOSTE** is predicted to have 10X lower resolution than the proposed Sandia system)
- Compressive Imaging (**MOSAIC** and similar) attempts to increase the space bandwidth product (SBP) – unproven technology that requires extremely complex processing. If successful, this approach is complementary and could be used WITH the Sandia technique

# Adaptive Imaging

- Adaptive zoom uses adaptive optical elements (Deformable Mirrors, Spatial Light Modulators, or Adaptive Lenses, etc.) to change the magnification of the system. (Patent #6,977,777)
- Optical (Foveated) scanning uses active optics to steer the high resolution area over a wide area without slewing the entire system (e.g. gimbals, reducing reduce weight and power requirements) (Patents # 6,473,241 and 6,421,185)

**F**oveated Imaging + **O**ptically **A**daptive **Z**oom

=

**FOcAZ**



# FOcAZ


## Concept of Operations

---





- Sensor collects WFOV ( $\pm 10^\circ$ ) imagery, to survey and coarsely track objects
  - Significantly lighter than conventional wide-field telescope (e.g. Schmidt) by replacing glass mirrors with composites and removing the need for a corrector plate
  - **NO** gimbals
  - All Reflective Zoom systems **DO NOT** currently exist
    - 3X reflective zoom has been demonstrated, but no systems have been deployed due to their complexity and weight.
- Sensor changes magnification to precisely track objects at coarse resolution or provide high resolution imagery on zoomed-in areas or targets of interest
  - 1/3 meter system would provide 36mm ground sampling distance from 65K feet altitude
  - Goal of 20X zoom that can be redirected **ANYWHERE** within the FOV in milliseconds
  - Co-boresited wavefront sensor to insure repeatability over time
- Format a compact data packet with minimal but sufficient information for downlink

# Adaptive Optics


Liquid Crystal Spatial Light Modulators




Continuous Electrostatic DMs




MEMS Deformable Mirrors



Composite – Variable Radius Mirror





Adaptive Polymer Lens




# Benefits of Foveated System vs. Conventional

Full Field of View =  $120^\circ$   
Effective focal length  $\sim 8$  mm  
Working f-number  $\sim 1.4$



**Patents: US 6,421,185**  
**US 6,473,241**

SLM fabricated by Boulder Nonlinear Systems, Inc, the University of Central Florida, and Narrascape.



# Foveated Demonstration




# Foveated Demonstration



# Foveated Demonstration



# Foveated Demonstration



# Foveated Demonstration



# Foveated Demonstration




# Foveated Demonstration



# Optical Zoom vs. Electronic (Digital) Zoom

Electronic (Digital) Zoom




4X Optical Zoom



# ZEMAX Layout

## Conventional 2.5X Zoom

Wide field-of-view




Narrow field-of-view – **ON AXIS**

# Adaptive Zoom

## How does it work?

Small changes in the individual focal lengths of elements




Large changes in magnification of the system.


### Adaptive Zoom

HIGH MAG

### Conventional Zoom



VS.



LOW MAG




- Power consumption can be greatly **REDUCED**

U.S. Patent #6,977,777

Page 18

# Active Optical Zoom vs Digital (Electronic) Zoom



Digital Zoom is simply larger:  
no increase in resolution.



Active Optical Zoom accomplished  
by changing the voltages that were  
applied to the two SLMs.

**NO MOVING PARTS**


# 4x Zoom using Adaptive Polymer Lenses



# First Demonstration Adaptive Lenses



1X

8X



# Scanning with zoom

Fast  
Steering  
Mirror  
 $\pm 7$  deg



# Off-axis Zoom using optical tilt in place of gimbal



# Why Composite Mirrors

---




Large aperture Carbon Fiber Reinforced Polymer (CFRP) mirrors are thin-shelled and lightweight yet significantly more rugged than other flexible materials (e.g. membranes) but not as brittle as SiC or thin glass.

- **Larger apertures** allow larger zoom ratios
- Size, Weight, Power a bigger issue as you move to larger apertures. Conventional approach: separate acquisition and tracking (Gimbaled).
- High resolution, reflective zoom **does not** exist – “Shadows” or off-axis tolerances
- Leveraging previous work from NRL

# System Concept




Actual images taken from an 1-8X  
REFRACTIVE, small aperture  
adaptive zoom system (in the lab  
with a poster - not at altitude).




Composite,  
variable  
radius mirror

# 16-ply CFRP Variable Radius Mirror




**UNACCEPTABLE**



**CFRP VRM**  
400 mm diameter X 1.75 mm thick  
Standard orientation 16-ply  
Coating: aluminum + SiO  
Measured with Ronchi, 50 lines/in.

# Parallel mirror development 24-ply CFRP VRM


## Thicker mirror – Significantly improved



Ronchi Image



Ronchi Inside  
focus with  
Hartmann  
mask




Foucault Image


**CFRP VRM**  
400 mm diameter X 2.5 mm thick  
Standard orientation 24-plyes  
Coating: aluminum + SiO  
Measured with Ronchi, 50 lines/in.

# Comparison 16- vs 24-ply CFRP mirrors

Ronchi Image comparison between 16 and 24-ply mirrors






16-ply



24-ply


# 4-pt bending test completed

- 25 composite coupons were fabricated (16-ply and 24-ply with standard layups and 0° and 12° orientations, along with 5 uniaxial samples).
- Coupons tested by Brad Boyce (1831) to ascertain Young's modulus in each direction (x, y, and z), Poisson ratios, and shear modulus. These 9 values are then used in ANSYS to describe each layer.



# 4-pt bend test results

Property	Published (psi)
$E_1$	$46.2 \times 10^6$
$E_2$	$1.07 \times 10^6$
$E_3$	$1.02 \times 10^6$
$\nu_{12}$	0.30
$\nu_{13}$	0.30
$\nu_{23}$	0.49
$G_{12}$	$0.7 \times 10^6$
$G_{13}$	$0.7 \times 10^6$
$G_{23}$	$0.63 \times 10^6$





Composite (Young's) modulus in fiber direction ( $E_1$ ), matrix modulus, and shear modulus ( $G_{12}$ ) adjusted based on measurements. Poisson's ratios ( $\nu$ ) were estimated based on literature values, and we used volume fraction of fiber as quoted by the vendor.




Composite  
Mirror  
Applications Inc.

# Zygo wavefront measurements



## CFRP Mirror

Peak to Valley = 6.3855 waves





# Wavefront with three point contact and point load in center

FEM with 0.86 N of force at Center




Measured 0.86 N of force at Center

Model deviation from best fit sphere

Measurement deviation from best fit sphere




# Change in Radius of Curvature Predicted Wavefront Error



Results in varying the radius from 2m to 1.25 m via tangential displacement (uniformly around circumference). Top shows wavefront compared to 1.25 m ROC sphere and the bottom is the difference (in microns).


# Proposed Development of Composite Mirrors




ACTUATION

## MATERIALS

MATERIAL REQUIREMENTS



SYSTEM REQUIREMENTS






## FABRICATION

## MODELING


MEASURED PERFORMANCE


PREDICTED PERFORMANCE



# CFRP potential capabilities




- **Variable Radius of Curvature** – Pan, Tilt, and >10X Optical Zoom without macroscopic motion. These thin shelled mirrors can vary their Radius-of-Curvature (ROC) with minimal mechanical motion and little power. Actuation will also allow aberration correction (dynamic aberrations (jitter/thermal) or due to variations over time).
- **Multispectral** – Reflective system not limited to single wavelength band (e.g. visible or SWIR).
- **Larger Apertures** – Higher resolution and greater light gathering capability (i.e. higher S/N)
- **Lightweight** 




# Example: 12X Zoom CFRP Design for 16" Primary Mirror





ONLY 4mm Deformation on the Primary



# 10X Zoom using a composite mirror




10X Zoom with an  
Uncoated 16-inch  
diameter CFRP  
shell  
and a MiroAO  
electrostatically  
addressed  
membrane mirror



# Acknowledgements and Questions



We would gratefully like to acknowledge support from the Office of Naval Research (Keith Krapels and Michael Duncan), DARPA (Len Buckley and Steve Wax), the IC Postdoctoral Fellowship program (Susan Durham and Dan Schuresko) and Sandia Labs LDRD Office. Sandia National Laboratories is a multi-program laboratory managed and operated by Sandia Corporation, a wholly owned subsidiary of Lockheed Martin Corporation, for the U.S. Department of Energy's National Nuclear Security Administration under contract DE-AC04-94AL85000.



*Composite  
Mirror  
Applications Inc.*