


Polyoxometalate “Solutions” for Redox Flow Batteries

MRS, Tuesday, December 2, 2013

Travis Anderson and Harry D. Pratt III,
Sandia National Laboratories



*Exceptional
service
in the
national
interest*



**OFFICE OF
ELECTRICITY DELIVERY &
ENERGY RELIABILITY**

**Dr. Imre Gyuk, Energy Storage Program, Office
of Electricity Delivery and Energy Reliability**



Sandia National Laboratories is a multi-program laboratory managed and operated by Sandia Corporation, a wholly owned subsidiary of Lockheed Martin Corporation, for the U.S. Department of Energy's National Nuclear Security Administration under contract DE-AC04-94AL85000.


RFB Project Goals and Approach

Problem: Getting higher concentrations of redox active species as a vehicle for lowering cost and improving performance.

Approach: New multi-valent anode/cathode materials by judicious selection of ligands and anions for lower viscosity AND new SNL rapid prototyping with 3-D printing to quickly evaluate membranes, solutions, and cell designs.

Target Metrics

- 59 mV/n separation ($n > 1$)
- Viscosity < 500 cP
- Conductivity > 0.5 mS cm⁻¹
- Open Circuit Potential > 1.5 V




Aqueous versus non-aqueous, including ionic liquids

$$\text{Energy Density}_{\text{RFB}} \approx \frac{1}{2} n F V_{\text{cell}} C_{\text{active}}$$

$$\text{ED}_{\text{AQ}} = \frac{1}{2} \mathbf{1F1.5}_{\text{cell}} \mathbf{2}_{\text{active}} = 1.5F$$

$$\text{ED}_{\text{IL}} = \frac{1}{2} \mathbf{2F2}_{\text{cell}} \mathbf{3}_{\text{active}} = 6.0F$$



Polyoxometalates (POMs)


–Early transition metal-oxide clusters with diverse fundamental and applied interests

Sc	Ti	V	Cr	Mn	Fe	Co	Ni	Cu	Zn
Y	Zr	Nb	Mo	Tc	Ru	Rh	Pd	Ag	Cd
La	Hf	Ta	W	Re	Os	Ir	Pt	Au	Hg

g

Undergo
multi-
electron
redox
processes

The image cannot be displayed. Your computer may not have enough memory to open the image, or the image may have been corrupted. Restart your computer, and then open the file again. If the red x still appears, you may have to delete the image and then insert it again.




Keggin
structure





POMs are commonly formed by **acid condensation** reactions.

A- α -K₆HSiV₃W₉O₄₀




Metal Incorporation

Compound was synthesized in **high yield** and **high purity** using literature methods.



Flow Cell Studies




Testing was performed in a cell with serpentine flow field, carbon felt electrodes, and a Nafion 117 membrane.

Electrochemical yield, observed capacity/theoretical, decreased from 90% to 80% after 100 cycles.

The image cannot be displayed. Your computer may not have enough memory to open the image, or the image may have been corrupted. Restart your computer, and then open the file again. If the red x still appears, you may have to delete the image and then insert it again.

The image cannot be displayed. Your computer may not have enough memory to open the image, or the image may have been corrupted. Restart your computer, and then open the file again. If the red x still appears, you may have to delete the image and then insert it again.

Cell Variations





Serpentine *versus* Well

The non-aqueous analog had a cycling rate and electrochemical yield that were 65% and 15%, respectively, lower than the aqueous analogue. Reduced performance by a protonated analogue highlights the importance of the alkali cation.

POM Variations

– Iterations on $A\text{-}\alpha\text{-K}_6\text{HSiV}_3\text{W}_9\text{O}_{40}$ were performed in order to determine what features lead to improved performance.



Infrared Spectra



^{31}P NMR Spectra




– To achieve high yield and purity of the $B\text{-}\alpha\text{-PV}_3\text{W}_9\text{O}_{40}^{6-}$, modifications to the synthesis were made. Specifically, the pH was increased from 1 to 5, and the compound was refluxed for 12 h.

$PV_3W_9O_{40}^{9-}$ Studies

A-isomer

B-isomer

– The B-isomer displays less reversible vanadium chemistry and higher capacity fading than its A analogue.




Overall Comparisons

- ← Wells-Dawson is a 1 e⁻ process
- ← Si-isomer is more efficient than P, reflects binding to $V_3W_9O_{40}^{3-}$ shell
- ← A-isomer is more efficient than B, corner *versus* edge sharing V

Both A-isomers show stable yields over cycling →

The B-isomer shows diminished yields over cycling →

POM Stability

 The image cannot be displayed. Your computer may not have enough memory to open the image, or the image may have been corrupted. Restart your computer, and then open the file again. If the red x still appears, you may have to delete the image and then insert it again.



Infrared data of the A- α - $\text{K}_6\text{HSiV}_3\text{W}_9\text{O}_{40}$ indicate that the compound is stable over cycling and is consistent with NMR.

 The image cannot be displayed. Your computer may not have enough memory to open the image, or the image may have been corrupted. Restart your computer, and then open the file again. If the red x still appears, you may have to delete the image and then insert it again.

^{31}P data indicates compounds are relatively stable, cell dissection indicates that capacity fading is likely due to compound precipitation.

Summary/Conclusions

- POMs offer a new multivalent approach to RFBs.
- Silicon-centered and Keggin-based clusters appear to be the most promising, provided solubilities can be increased.
- Exchange of potassium for lithium can potentially lead to concentrations competitive with VRBs.
- Smaller molecular weight POMs also offer potential new routes to higher concentrations.



Acknowledgments

- Dr. Imre Gyuk, OE Program Manager
- Sean Hearne, Sandia Program Manager
- Tom Wunsch, PSTG Manager
- **Funding:** OE and Early Career LDRD
- **Team Members:** Nick Hudak and Jonathan Leonard

Contact Information

Dr. Travis M. Anderson

Principal Member of Technical Staff

Org. 02546, Advanced Power Sources R&D

Sandia National Laboratories

PO Box 5800

Albuquerque, NM 87185

Email: tmander@sandia.gov

Phone: 505-844-4766