

Locally-controlled domain microstructures in bismuth-iron-garnet films for magneto- optical current sensors

SPIE Optics+Photonics
August 4, 2009

Michael J. Cich, Sayan D. Mukherjee, Gordon A. Keeler, Christopher D. Nordquist, Alan Y. Hsu

This work was supported by the Laboratory Directed Research and Development program at Sandia National Laboratories. Sandia is a multiprogram laboratory operated by Sandia Corporation, a Lockheed Martin Company, for the United States Department of Energy's National Nuclear Security Administration under contract DE-AC04-94AL85000.




Outline

- **Bismuth Iron Garnet (BIG) Introduction**
 - Magnetic and magneto-optical properties
 - Domain Motion
- **Magnetic field sensing application**
- **Using BIG as a magnetic sensor**
- **Sensor results**
- **Local domain phase control**

Introduction to Bismuth Iron Garnet


- Ferrimagnetic material used in Faraday isolators
- Roughly $\text{Bi}_3\text{Fe}_5\text{O}_{12}$ (+Y, Al, Ca)
- Grown as $\sim 450 \mu\text{m}$ thick epitaxial film on GGG substrate (substrate removed)
- Develops easy magnetization direction perpendicular to film surface, forms stripe/bubble domains to minimize total energy





Domain motion under changing B


500 μm




Increase B
0G to 500G



Decrease B
500G to 0G





Controlling Domain Location ($B_{ext}=0$)




Deposited SmCo bias magnet
Magnetized out-of-plane

Application:

Measuring current transients in high current cables



Field Sensing by Domain Size




100-turn coil
Field strength to ~ 1000 G
Notched cable field to ~ 6000 G



External magnetic field changes domain size

- Changes polarization state of beam reflected from back surface
- Changes intensity at detector
- Signal increases for external field parallel to domain, decreases for antiparallel orientation – not just magnitude sensitive


Probe beam results



Change in light scattering when probing a single bubble highly variable, difficult to reproduce



Field Sensing by Faraday Rotator Effect




External magnetic field changes domain size

- Change in intensity due to change in area of domains aligned with external field
- Signal increases for external field parallel to domain, decreases for antiparallel orientation – not just magnitude sensitive





Stripe phase imaging

No field




Coil @ 1A




0 – 0.75A pulse video

dark stripes expand and get slightly darker



bright stripes shrink but get slightly brighter


Stripe phase imaging results




Not very linear averaging over $\sim 500 \times 140$ micron stripe area

Bubble phase imaging


No field




Coil @ 1A




dark bubbles expand but get slightly brighter



Bubble phase imaging results



Improved linear averaging over $\sim 500 \times 140$ micron bubble area



Summary

- Optical detection of domain motion in BIG films was used to sense a magnetic field
 - Collimated probe beam gave poor results due to sensitivity of beam scattering to alignment with bubble
 - Stripe domain ensemble average gave more linear results
 - Bubble ensemble average was most linear
 - May be due to improved linearity in a particular portion of the magnetization curve
- Integrated SmCo thin film magnet used to influence bubble domain formation
 - next step is to engineer SmCo magnet shape to further define/control domain motion
 - linearization, reproducibility, sensitivity