


*Exceptional service in the national interest*



# New Macroporous Ceramic Pellets for use as Thermal Battery Separator Layers

Christine Roberts, Lisa Mondy, Anne Grillet, Melissa Soehnel, David Barringer, Christopher Diantonio, Tom Chavez, Lindsey Evans, David Ingersoll

Sandia National Laboratories, PO Box 5800, Albuquerque, NM, USA, 87185-0346



**46<sup>th</sup> Power Sources Conference, June 11, 2014**  
**Orlando, Florida**



Sandia National Laboratories is a multi-program laboratory managed and operated by Sandia Corporation, a wholly owned subsidiary of Lockheed Martin Corporation, for the U.S. Department of Energy's National Nuclear Security Administration under contract DE-AC04-94AL85000. SAND NO. 2011-XXXXP

# Motivation

## Current thermal battery separator technology



Pressed, porous pellet of electrolyte (LiCl/KCl salt) + Binder (MgO)

- Pressing operation : circular shapes, slow
- Pellet compresses, densifies on activation/melting salt
  - See talks 25.4, 28.1
- MgO properties significantly dictate performance, limit pellet thickness

# Goal:

New porous ceramic that will be coated, sintered, and filled with electrolyte to serve as a separator in thermal batteries

## ■ Performance


- Porous and permeable to electrolyte
- Robust enough to withstand battery closing force (~500 psi)
- Chemically compatible with batteries (MgO)
- Not dependent on MgO properties

## ■ Processability

- Ability to be coated, dried, and removed from substrate
- Sintered and cut to a flat shape
- Backfilled with electrolyte
- Robust enough to be handled




Lab-Cast Model TC-71LC




# Unsatisfactory fabrication methods


- Reticulated foam filled with ceramic slip



★ **Porous; not thin**




- Tape cast sample with punched hole array



★ **Strong; not porous**

- Dried Pickering emulsion

★ **Porous and strong; not flat, bad salt fill**








# Accepted fabrication methods

## Tape casting with poreformer burnout (“poreformer”)


- Mix ingredients in a turbula mixer, coat onto substrate



- Green tape is removed from substrate, layered, sintered
  - PTFE poreformer burns away, leaving pores




- Sintered tape is laser cut into circles




# Explored poreformer sample processing variables

- Poreformer concentration
  - 40 vol%, 50 vol%, and 70 vol% (total poreformer/total solids)
- Sintering temperature
- Sample thickness depends on number of layers laminated
  - 0.6 mm – 1.2 mm thickness, 1 inch diameter, center hole optional






Total porosity ranges from 20 vol% to 73%  
Current technology: Salt fraction = 80 vol%(?)  
when melted



# Accepted fabrication methods

## Tape cast of aqueous, gelled MgO (“gelled”)

- MgO hydrolyzes to brucite  $\text{Mg}(\text{OH})_2$  when added to water
  - $\text{MgO} + 2\text{H}_2\text{O} \leftrightarrow \text{Mg}(\text{OH})_2 + \text{OH}^-$
  - In basic solutions, brucite destabilizes and aggregates
- MgO + water + gellan or PVA (time sensitive)
  - Tape cast -> dried -> sintered-> laser cut into shapes
  - $\text{Mg}(\text{OH})_2$  converts to MgO upon sintering






# Gelled sample processing variables

- MgO concentration in initial slip
- Mixing time of slip, drying time
- PVA, gellan concentration (no effect on  $\phi$ )



Samples as thin as 0.4 mm made,  
Total porosity up to 84 vol%

Green sample morphology vs drying time







# Fracture strength



- Measured with a texture tester
  - 2mm diameter post
  - 2 kg ~ 900 psi
- Worst case scenario





# Sample Impedance

- Procedure:
  - Fill sintered samples with water + KCl
  - AC voltage applied across electrodes
  - Impedance measured vs AC frequency

$$MacMullin\# = \frac{\text{Sample resistance}}{\text{Solution resistance}}$$

- Compare to Li Ion batteries  $N_m = 6-12^{[1]}$

- Archie's Law<sup>[2,3]</sup>  $N_m = a\phi_c^{-m}$ 
  - $1.3 < m < 2.5$  in common materials




[1] Arora, P., Zhang, Z.J., "Battery separators." Chem. Rev. vol 104, pp 4419–4462, 2004.

[2] Archie G F 1942 "Trans AIME" 146 54–62


[3] Balberg I 1986 Phys Rev B 33 3618–3620

# Electrolyte filling methods

- Electrolyte: LiCl/KCl eutectic composition
- Challenges:
  - Unfilled samples are brittle
  - Salt: 352 °C melting point, deliquescent
- Multiple methods tried
  - Best filled >70% of porosity regularly



Poreformer sample filled with electrolyte





# Single Cell Performance: Constant current

1 inch diameter cell: FeS<sub>2</sub> + Separator material cathode, LiSi anode

500 °C, 8 psi axial load

50 mA/cm<sup>2</sup> constant current





Sample	h (mm)	Vol % MgO	Vol% Elect	Vol% pore
Control	0.42	20?	80?	0?
Red	1.39	16	30	53
Green	0.67	27	47	27

Sample	h (mm)	Vol % MgO	Vol% Elect	Vol% pore
Control	0.42	20?	80?	0?
Orange	1.06	28	48	24
Lt blue	0.48	29	62	9
Teal	1.02	31	34	36





# Pulsed Cell Performance: Gelled



Sample	h (mm)	Vol % MgO	Vol% Elect	Vol% pores
Control	0.42	20?	80?	0?
Red	0.97	22	37	41
Green	0.79	18	35	47
Light green	0.78	24	37	39

# Pulsed cell performance: Poreformer



Sample	h (mm)	Vol % MgO	Vol% Elect	Vol% pores
Control	0.42	20?	80?	0?
Red	0.97	27	57	17
Purple	0.78	24	56	16
Green	1.03	30	35	35

# Next Steps

- Sample optimization
  - Gelled samples: flat sintering
  - Poreformer samples: robust when thin, porous
  - Filling methods
  - Consistency
- Fabrication, testing at the battery level

## Acknowledgements

- Bob Fox, Linda Johnson – help with single cell testing
- Adrian Wagner - sample laser cutting
- Discussions with Karen Waldrip, Chris Apblett, Michael Russel over electrolyte filling methods
- This project was funded under LDRD project # 151359