

Miniature trapped-ion frequency standard with $^{171}\text{Yb}^+$

Micro Position, Navigation, and Timing Program
Integrated Micro Primary Atomic Clock Technology (IMPACT)
DARPA/MTO

Peter Schwindt
Sandia National Laboratories

April 16th, 2015



Sandia
National
Laboratories



JPL

Jet Propulsion Laboratory
California Institute of Technology



Microsemi



Microfabricated Ion Frequency Standard Team




- Principal Investigator/Project Manager
 - Peter Schwindt
- Trapped Ion Clock
 - Heather Partner
 - Yuan-Yu Jau
- JPL
 - Nan Yu
 - John Prestage
 - James Kellogg
- UV Light Source
 - Darwin Serkland
- Optics Integration
 - Robert Boye
- Yb Source
 - Ron Manginell
 - Matthew Moorman
- Miniature Vacuum Package
 - Adrian Casias
- Electronics (Microsemi)
 - Dan Boschen
 - David Mailoux
 - David Scherer
 - Igor Kosvin

Sandia National Laboratories is a multi-program laboratory managed and operated by Sandia Corporation, a wholly owned subsidiary of Lockheed Martin Corporation, for the U.S. Department of Energy's National Nuclear Security Administration under contract DE-AC04-94AL85000.

This research was developed with funding from the Defense Advanced Research Projects Agency (DARPA). The views, opinions, and/or findings contained in this article/presentation are those of the author(s)/presenter(s) and should not be interpreted as representing the official views or policies of the Department of Defense or the U.S. Government.

IMPACT Project Goals


- Achieve Cs Beam Clock performance in a mass and power constrained package
- 5 cm³, 50 mW, 10⁻¹⁴ performance



Applications--Excellent timing for:



- Rapid GPS acquisition, and GPS denied navigation and timing
- Nano/pico (cube) satellites
- Pulsed radio and spread spectrum communications

Symmetricom
5071A





Trapped Ion Clock for Miniaturization

- Trapped ion clocks are already compact while delivering excellent performance.
- Low mass, size, power
- Trapped ion lifetime: up to 10,000 hrs
- Coherence time: > 100s
- Other approaches for IMPACT:
 - Miniature fountain clock
 - Locked optical frequency converted microwaves with WGM resonator




^{199}Hg Trapped Ion Clock from JPL


Atomic Frequency Reference with $^{171}\text{Yb}^+$



Critical Elements of the $^{171}\text{Yb}^+$ Clock




Physics Package




3 cm³ Vacuum Package and Ion Trap

Vacuum package w/ Detector



Ion-trap electrodes



1. Vacuum package
2. μ -metal shield
3. Copper pump-out tube
4. Yb oven appendage
5. Electrical feedthroughs
6. C-field coils
7. Laser port (sapphire)
8. Fluorescence collection window (sapphire)
9. Lens and filters tube


- Titanium body with sapphire windows.
- Linear Quadrupole RF Paul Trap
- Pinched off since April 25th, 2012

- Getter Pumped.
- Trapped ion lifetime > 3 weeks.


Independent Testing of Long-Term Stability

- Bread board clock with 935 nm VCSEL and MEMS shutter
- Large doubled 369 nm laser

Integrated Vacuum Package



- Blu Ray burner diode at 405 nm to creates ions.
- Allan deviation derived from data sets of 6 days, 26 days, 3 days, 4 days, and 10 days.
- 49 days of data



Miniature Laser Sources



369 nm Direct Diode

Nichia diode packaged by Ondax. Size: 1 cm³

Mode-hop free tuning: 8 GHz

Power consumption: 300 mW

Power output: 1-5 mW





935 nm VCSEL

New 935 nm VCSEL fabricated.

Initial results indicate no frequency drift.


Single mode P > 1 mW



Optics Package


Integrated Optics Package

- 369-nm light from an optical fiber: flexibility of sources
- 935-nm VCSEL with temperature control mounted on a PCB
- Mix of adjustable and fixed optical components achieving good overlap of two beam with themselves and with the ions.




369-nm Laser Package

- The package provides temperature control for the 369 nm external cavity diode laser.
- Intensity and polarization control are implemented by the ND filters and the half waveplate (HWP) prior to the light being coupled into the optical fiber.




Physic Package Interface Board




Complete Physics Package

Integrated Optics




Physics Package Interface




Vacuum Package



Optics & Lasers



Integrated Clock Performance







Co-Fired Hybrid Ceramic/Titanium Package





- High temperature co-fired ceramic (HTCC) simplifies the electrical vacuum feedthroughs and internal connections.
- Make the ion trap an integral part of the vacuum package for maximum miniaturization.
- Integrated Yb sources: Silicon micro hotplate
- CuAg braze the Ti parts to the HTCC
- AuGe solder Si hotplates to HTCC
- E-beam weld the base to the lid
- Size of package cube: 0.8 cm³

Exploded View






Yb sources: Silicon Micro Hotplate

- Evaporate Yb into the Si micro hotplates
- Heat base to 620 °C for 2 hours in vacuum
- 30-50% is deposited into the Si micro hotplate: 0.5-0.8 mg
- Inner circular structure in hotplate prevents CTE mismatch between Yb and Si from cracking the Si.
- Typical power for Yb evaporation: 1.5 V \times 0.17 A = 255 mW



Performance of the Phase III Vacuum Package

- The vacuum package was pinched-off on Thursday, October 30th, 2014.
- Trapped ion lifetime is \sim 50 hours.
- Achieving Phase III performance
 - $T_{\text{microwave}} = 700 \text{ ms}$
 - $T_{\text{optical pumping}} = 300 \text{ ms}$
- Magnetic field correlations removed



F-State Trapping Problem

- Collisions of Yb ions in the $P_{1/2}$ and $D_{3/2}$ states with He will transfer Yb ions into the $F_{7/2}$ state.
- Noble gasses do not quench the $F_{7/2}$ state.
- Lasers at 760 nm, 638 nm, or 864 nm will clear the F-state.

- Another laser is too complicated.

- Nitrogen is known to clear the $F_{7/2}$ state, but it is pumped by the getter.
- Methane is not pumped by the getter and is a molecular gas.









FIG. 3. Quenching rate of ytterbium's trap state vs N_2 buffer-gas pressure. The curved line represents a least-squares fit of the data to the polynomial $\Gamma_{31} = aP + bP^2$; $a = 3.63 \pm 0.12 \times 10^4/s \text{ Pa}$ and $b = -7.45 \pm 1.15 \times 10^6/s \text{ Pa}^2$, while the straight line represents a linear least-squares fit to pressures $\leq 26.6 \times 10^{-5} \text{ Pa}$.


Testing Methane as a Quenching Gas



Methane Pressure = 1×10^{-6}




Fraction Remaining in the F-State




Methane Effects on the Clock State

- Estimated methane pressure required for F-State quenching in ^{171}Yb
 - 10^{-8} to 10^{-7} Torr
- F-state Fraction
 - $< 20\%$
- Effects on the ^{171}Yb ground state
 - Frequency shift due to collisions
 - 10^{-14} to 10^{-13}
 - Relaxation and decoherence of ^{171}Yb ground state due to collisions
 - $T_2 = 1000$ to 100 s

Frequency Pulling of Methane




Decoherence Rate in ^{171}Yb Ground State



Conclusion




- Developed a clock prototype using the sealed 3 cm^3 vacuum package
 - Long-term stability: 6×10^{-14} @ 1 month
- Completed integrated physics package shows $2 \times 10^{-11} / \sqrt{\tau}$
- Hybrid metal/ceramic vacuum package shows $2 \times 10^{-11} / \sqrt{\tau}$
- Solved many problems and developed new technologies
 - Miniature vacuum packages
 - Simple ionization technique
 - F-state quenching with methane
 - Miniature Yb sources
 - 740 nm VCSELs
 - Low-power RF drive for the ion trap
- Need for technological improvements
 - 369 nm laser with low-power and long-term stability
 - Low power local oscillator
 - Improve signal-to-noise ratio
 - Detect 369 nm fluorescence



Back up slides

369-nm Light Source Development: VECSELs

- 740nm VECSEL testing
 - New implant VECSEL wafer
 - 15-mm external cavity
 - Add filters to suppress high-order modes








Integrated Micro Primary Atomic Clock Technology (IMPACT) Program Milestones



Milestone	Phase I	Phase II	Phase III
Power consumption (mW)	160 (physics package)	250	50
Size (cc)	30 (physics package)	20	5
Atom detector Q*S/N	1×10^{10}	2×10^{10}	5×10^{10}
Time Loss (ns) @ 1 ms	3.2×10^{-3}	1.6×10^{-3}	6.3×10^{-4}
Time Loss (ns) @ 1 s	0.1	0.05	0.02
Time Loss (ns) @ 1 hour	< 60	6	1.2
Time Loss (ns) @ 1 day	< 300	29	5.2
Time Loss (ns) @ 1 month	< 1600	160	32
Fractional Frequency Retrace (1-hour turn on, once every day)	1.7×10^{-11}	1.0×10^{-13}	1.0×10^{-13}

Phase I 10 cm³ Vacuum Package

- Designed, fabricated, two 10 cm³ vacuum physics packages
 - The trap is integrated in to the walls of the trap to allow a smaller package.
 - 400 C bake/de-gassing, getter pumped
 - Pinched off since April 4th 2011, no active pumping.
 - Trapped ion lifetime > 500 hours.




JPL phase II package summary




Compact experimental setup

- Trapped ion lifetime of days, and the lifetime is increasing with time
- Volume is approximately 3 cubic cm
- No active vacuum pump is required
- RF drive consumes 20 mW (1.8MHz, 160 Vrf)
- Signals are detected at 297 nm by using the low-power compact PMT + Amp.
- The ions are loaded using 405 nm laser diode.
- All nonmagnetic materials, 400C bake temperature (>600 C survival)
- Design integrates coils and magnetic shield
- Compact 935 nm VCSEL control electronics developed by Symmetricom

935 VCSEL optical power 0.4 mW
369 nm optical power thru trap: 20 uW



Phase II 3 cm³ metal package




For demonstration of a complete portable clock

Smaller sealed Titanium package - all nonmagnetic materials


Incorporates shield and field coils to control magnetic field fluctuations which are one of our limiting factors for long-term performance

Continuous Operation with Ion Reloading



Clock Performance

- Operate physics package with Symmetricom developed control electronics.
- Local oscillator: 10 MHz OCXO: 60 mW
- 12.6 GHz microwaves phase locked to OCXO.
- Clock cycle = 500 ms
 - Microwave = 200 ms
 - Detection/Optical Pumping = 300 ms





Independent Testing

Delivered the clock to test facility in late June 2012

Demonstrated 31 days of continuous operation, 49 days of data collected

Allan deviation derived from data sets of 6 days, 26 days, 3 days, 4 days, and 10 days. Phase steps removed.


Frequency reproducibility between data sets: 2×10^{-13}



Evolution of the Vacuum/Trap Packages



Phase-I 1-liter package for proving the operation of the mini-ion-trap.





Sealed off
Getter pumped







Demonstrated trapped ion lifetime > 600 hrs.

Phase-I Sandia designed 10 c.c. vacuum package. Pinched off, getter pumped.



Demonstrated trapped ion lifetime > 500 hrs.

Phase-II 1 c.c. Sandia developed ceramic package.



Braze Ring
Connection Pads

Demonstrated long-term ion trapping.



Phase-I 18 c.c. package for proving the feasibility of small vacuum volume.



Sealed off
Getter pumped


Demonstrated trapped ion lifetime > 100 hrs.

Phase-I JPL designed 10 c.c. vacuum package. Pinched off, getter pumped, electron emitter.



Demonstrated trapped ion lifetime > 1000 hrs.

Phase-II JPL designed 3 c.c. vacuum package.



Phase II Clock Prototype


Physics Package

Fiber from
369 nm Laser

935 nm VCSEL

HWP


Symmetricom Electronics



MEMS Shutter

- Small moving blade
 - 60 μm throw
- Mounted with 50 μm pinhole above the blade
- Requires 20-25 V to activate.
- Extinction > 40 dB
- 10-90 Switch time
 - On: 47 μs
 - Off: 62 μs

Physics Package



Integrated Vacuum Package, Magnetic shield, Yb oven, and Detector

- Signals are detected at 297 nm by using the low-power compact PMT + Amplifier.
- Yb oven heats Yb metal to create a vapor at 450-500 C.
- Blu Ray burner diode at 405 nm to creates ions.

