

Image Analysis of Off-Eutectic Alloys with Lamellar Microstructures

**Don Susan^a, Charlie Robino^a, John DuPont^b,
and Mike Minicozzi^b**

**^aSandia National Laboratories
Albuquerque, NM**

**^bLehigh University
Bethlehem, PA**

**39th International Metallographic Society Symposium
Microscopy and Microanalysis 2006
Chicago, IL
August 1st, 2006**


Sandia is a multiprogram laboratory operated by Sandia Corporation, a Lockheed Martin Company,
for the United States Department of Energy's National Nuclear Security Administration
under contract DE-AC04-94AL85000.



Motivation

- **Ni-Cr-Mo-Gd alloys are being developed for safe transportation and storage containers for spent nuclear fuel.**
- **An understanding of the solidification behavior of these alloys is needed to aid in processing (ingot metallurgy, welding, etc.) and microstructural control.**

Ni-Cr-Mo-Gd As-Cast Microstructure




- Microstructure consists of primary austenite (γ_{pri}) dendrites and interdendritic “eutectic-like” mixture of austenite (γ_{eut}) and GdNi_5 .
- Beraha’s 7A tint-etch used to delineate the GdNi_5 constituent. Good contrast is achieved for thresholding and image analysis.

Alloy	Element (wt%)										
	Ni	Mo	Cr	Fe	Gd	P	S	Si	O	N	C
1B	67.7	15.67	16.00	0.016	0.46	<0.001	<0.001	0.070	0.0044	0.0045	0.0052
2B	67.2	15.53	16.08	0.017	1.01	<0.001	<0.001	0.081	<0.001	0.0044	<0.005
3B	66.9	15.56	15.91	0.015	1.49	<0.001	<0.001	0.070	<0.001	0.0039	0.0064
4B	66.8	15.16	15.95	0.016	1.9	<0.001	<0.001	0.070	0.0021	0.0041	0.0065
5B	66.7	15.12	15.56	0.016	2.45	<0.001	<0.001	0.071	0.0056	0.0043	0.0066








Five alloys studied with increasing Gd content

Mosaic (montage) Images used for Image Analysis




- Ability to cover a significant area of the sample and **collect statistically significant IA data**, while maintaining higher resolution of the individual images.
- Each mosaic typically has 12 images obtained at 500x magnification. Three or four separate mosaic images analyzed for each alloy sample (36-48 individual images).
- Clemex Vision PE image analysis system



Amount of GdNi_5 increases with Gd content in alloy



Differential Thermal Analysis (DTA)
used to determine liquidus temps.
and approximate “eutectic” temp.




Partial γ-Gd “solidification diagram”



On-heating and on-cooling
DTA scans

Challenge: Determine the eutectic-like point by image analysis of a few, relatively dilute alloys. Specifically, determine the ratio of γ and GdNi₅ within the eutectic-like regions (Lever Rule).




Attempt to threshold and “fill-in” eutectic regions (“closed” GdNi_5 image) is incorrect--**this method does not account for γ_{eut} that forms on the primary γ_{pri} dendrites.**

In this alloy system, the fill-in technique results in 58-65 vol.% GdNi_5 within the eutectic – this value is inaccurate, too high.


Problem: γ_{eut} cannot be distinguished from γ_{pri} in the microstructure.

Method of Dutta and coworkers

- Uses a dilation and erosion technique (also called the “chord size technique”) to determine the eutectic fraction, while taking into account the portion of γ_{eut} that solidifies on the primary γ_{pri} dendrites
- Dutta et al. studied several image analysis methods for analyzing Al-Si, Al-Fe-Si, and Al-Cu alloys




Schematic diagram of eutectic structure with layer of α_{eut} which solidifies on the primary α_{pri} dendrites (ref 1)



“Reconstructed” eutectic microstructure in Al-0.8Fe-0.8Si alloy (ref 1)

1. B. Dutta, O. Pompe, and M. Rettenmayr: *Materials Science and Technology*, 2004, vol. 20, pp. 1011-18.
2. B. Dutta and M. Rettenmayr: *Materials Science and Technology*, 2002, vol. 18, pp. 1428-34.
3. B. Dutta and M. Rettenmayr: *Materials Science and Engineering A*, 2000, vol. A283, pp. 218-24.
4. O. Pompe: *Prakt. Metallogr.*, 1994, vol. 31, (6), pp. 274-83.

1. Estimate the γ_{eut} Spacing with Chord-Size Technique




1. Estimate the γ_{eut} Spacing with Chord-Size Technique

“chord sizes”
in eutectic γ

“chord sizes”
within γ dendrites

Histograms of γ (Austenite) Chord Lengths used to determine γ eutectic spacing

This value is used in dilation-erosion technique to add a layer of $(1/2)L_{\text{eut-}\gamma}$ on the γ primary dendrites



γ eutectic spacing
dilations

$$D - E = \frac{\overline{L}_{\text{eut-}\gamma}}{2L_{\text{pix}}}$$

erosions

Pixel size
in image

In our alloys,
 $D-E \approx 6$


2. Dilation-Erosion technique adds a layer of γ_{eut} onto the γ_{pri} dendrites, while simultaneously filling in the eutectic regions.

Final microstructure
of γ dendrites and
Eutectic mixture $\text{GdNi}_5 + \gamma_{\text{eut}}$
(2.45wt.% Gd alloy)

GdNi_5


γ_{eut}

Reconstructed interdendritic eutectic microstructure of $\text{GdNi}_5 + \gamma_{\text{eut}}$




2.45 wt. % Gd alloy

How is the correct number of dilations determined?




- Increase # dilations while keeping (D-E) constant
- Vol. % eutectic levels off when eutectic regions are filled and *before small, primary dendrite tips begin to be filled...*




Mosaic image, 2.45wt.% Gd alloy

Regions with “Divorced” Eutectic Morphology




- Modifications to Dutta method were made to address the partly divorced eutectic microstructure (a semi-automated procedure)

Final Image Analysis Data and Solidification Diagram




The 5 alloys show increasing GdNi_5 , increasing eutectic content, but **constant eutectic phase ratio**, i.e. eutectic-like behavior




Eutectic composition is 14.7 wt.% Gd (41 vol. % GdNi_5 in eutectic mixture)

High Magnification SEM



BSE/SEM image of eutectic only



Binary threshold image of eutectic only

- Eutectic composition determined to be 40 ± 0.8 vol. % GdNi_5 (60 % γ)
 - This is very close to 41 ± 1.9 % GdNi_5 obtained with optical microscopy/image analysis technique
- (recall 58-65 vol. % GdNi_5 was found with simple OM “fill-in” of eutectic regions)



Summary

- A dilation-erosion technique, first developed by Dutta et al., was employed to determine the eutectic point in a model solidification diagram for γ -Gd alloys. The method accounts for the portion of γ_{eut} that grows on the primary γ dendrites and, in principle, **can be applied to any (off-eutectic) alloy system.**
- A modified, semi-automated technique was employed to characterize the complex, partially divorced morphology in these alloys.
- The “eutectic point” was determined to be 14.7 ± 0.68 wt. % Gd. This value corresponds to a eutectic mixture of 41.0 ± 1.93 vol. % GdNi_5 (and ~ 59 vol. % γ_{eut}).



Acknowledgements

Special thanks to Arlan Benscoter (Lehigh U.) and Alice Kilgo (Sandia) for metallography expertise. Thanks also to Bonnie McKenzie (Sandia) for SEM analysis.

This work was performed through support from the National Spent Nuclear Fuel Program under DOE Idaho Operations Office Contract No. DE-AC07-99ID13727.