

Exceptional service in the national interest





Nanoporous Metal Films and Powders Formed with Soft Templates

Presented by David B. Robinson
American Chemical Society National Meeting
San Diego, CA
March 2016


Porous materials for energy storage

- Battery electrodes
- Supercapacitors
- Hydrogen storage, fuel cells
- Needed: energy density, power density



Porous materials for chemical separations


- Chromatography columns
- Needed: narrow bands, faster band velocity, selectivity, shorter column, low flow resistance



Bob Nilson and Stewart Griffiths
Phys Rev E 79 036304 (2009)
Phys Rev E 80 016310 (2009)

Porous materials for catalyzed chemical reactions

- Automotive catalytic converters, industrial flow reactors
- Needed: low flow resistance, thermal stability, optimized catalyst loading




"Aufgeschnittener Metall Katalysator für ein Auto" by User Stahlkocher on de.wikipedia - Originally from de.wikipedia; description page is (was) here. Licensed under CC BY-SA 2.0 via Wikimedia Commons - http://commons.wikimedia.org/wiki/File:Aufgeschnittener_Metall_Katalysator_f%C3%BCr_ein_Auto.jpg#/media/File:Aufgeschnittener_Metall_Katalysator_f%C3%BCr_ein_Auto.jpg




"Pot catalytique vue de la structure" by The RedBurn - Own work. Licensed under CC BY-SA 3.0 via Wikimedia Commons - http://commons.wikimedia.org/wiki/File:Pot_catalytique_vue_de_la_structure.jpg#/media/File:Pot_catalytique_vue_de_la_structure.jpg

Reduction in lyotropic liquid crystals




- Robinson et al.,
Int. J. Hydrogen Energy 35 5423 (2010)
- Particles grow around surfactant phase
- Pd and PdRh alloys
- Prior work: Attard, Bartlett et al. Science 278 838 (1997)



Surfactant removal

- Can require long soaks
- Easier with oxidized surfaces




Ong et al.
Chem Mater. 24 996 (2012)


Pd:Rh 9:1
4h ethanol-water soak

Thermal Stability Constrains Pore Size

3 nm
pores



Room Temperature





600°C

- STEM and STEM-tomography show that pores begin to collapse at 200°C
- By 600°C Pores have coalesced into large voids
- Larger pores should be more stable


Block copolymer gels

- Prior work: Pt films from Block copolymer gels
Yamauchi et al., Angew. Chem. 47 5371 (2008)
Takai et al., JACS 132 209 (2010)
- Pores in SEM range
- Gram scale, H₂-reduced Pd
Cappillino et al. J. Mater. Chem. A 1 602 (2013)




500 nm

Liquid stage STEM





Lucas R. Parent et al., ACS Nano, 6 3589 (2012)

Reduction of $(\text{NH}_4)_2\text{PdCl}_4$ in water + (bcp-3.8,5k)




Nanoparticles nucleate, grow, and fuse to form porous structure




Lucas R. Parent et al., Chem. Mater. 26 1426 (2014)

Size tuning with block copolymers

- Cappillino et al. J. Mater. Chem. A 1 602 (2013)
- Poly (styrene-block-ethylene oxide)



Name	x	y	Pore, nm	Pitch, nm
Pd _S	22	70	7	15
Pd _L	36	113	12	30





100 nm

100 nm₁₁

7 & 13 nm pores stable to $> 600^{\circ}\text{C}$

Both 7 nm (left) and 13 nm (right) pores are intact to 600°C . Collapse occurs by 700°C




NP forming ligaments fuse upon annealing (small voids collapse)
Pore structure remains intact

50 nm scalebars

Plating from dilute micellar phase

- Eliminates slow, messy pastes, gels; pores less ordered
- Prior work: Pt + F127, aqueous: Wang et al., Chem. Mater. 24 1591 (2012)
- Prior work: Au + PS-PEO, mixed solvent: Li et al., Nature Comm. 6 6608 (2015)
- Our work: Pd, 20x thicker films

Pluronic F127 is $\text{EO}_{101}\text{PO}_{56}\text{EO}_{101}$
 $\text{EO}_2\text{PO}_2\text{EO}_2$ is :






Tricks:


- Similar working-, counter-electrode areas
- Double junction Ag/AgCl reference electrode
- Pd^{2+} , HCl concentration > 0.1M
- F127 > 1 wt %
- Current density near 1 mA/cm²




SEM cross section shows nanoporosity



Small-angle X-ray scattering




- Ring indicates presence of bulk porosity
- Crescent indicates pore orientation
- Advanced Light Source beamline 7.3.3
- Grazing incidence




Electrochemical capacitance

- Provides a measure of surface area
- Measures reversible electrostatic adsorption of aqueous ions to surface without redox reactions




Robinson et al.,
Langmuir 26 6797 (2010)

Chae et al.,
ACS Appl Mater. Interf.
4 3973 (2012)





Electrochemical hydriding rates

- Apply negative current for fixed time: $\text{Pd} + \text{H}^+ + \text{e}^- \rightarrow \text{PdH}$
- Then step to positive potential, observe reverse reaction



Iterative Electroless Porous Pd

- Stepwise growth of nanoporous Pd from dilute F127
 - $\text{Pd} + \text{H}_2 \rightarrow \text{PdH}_{0.6}$
 - $\text{PdH}_{0.6} + \text{Na}_2\text{PdCl}_4 + \text{F127} \rightarrow \text{porous Pd} + \text{HCl}$
- Films or powders



Acknowledgements

- Gail F. Garcia
- Christopher G. Jones
- Patrick J. Cappillino
- Benjamin W. Jacobs
- Joshua D. Sugar
- Ryan K. Nishimoto
- Mark Homer
- George M. Buffleben
- Lucas R. Parent
- Ilke Arslan
- Matthew Klein

