




Thermal Spray Research at Sandia

Deidre Hirschfeld, Andrew Vackel, Joe Fonseca

ITSA, Oct 12, 2017





Acknowledgement



Support of TSRL Staff & Students

- Jesse Adamczyk, NM Tech now Grad Student Colorado School of Mines
- Pylin Sarobol, former staff now with Lance
- Awesome Techs
 - Tom Holmes
 - Andrew Miller
 - Carlos Silva
 - Joe Padilla
 - Mike Clearwater
 - Andy Mayer
 - Dave Beatty


General Coating Comparisons




Film Characteristics of Various Processes

Film Parameters	Physical Vapor Deposition [1]	Aerosol Deposition	Thermal Spray
Max Film Thickness	5 μm	100 μm	1 mm
Grain Size	10-100 nm	10-100 nm	10-100 μm
Density	Low	Near Theoretical	Low


Microstructures of PVD, AD, and TS coatings



Physical Vapor deposited columnar MgF₂ [2]



Aerosol deposited Al₂O₃ on Sapphire substrate



Thermal sprayed Mo On Bi₂Te₃ Substrate

Thermal Spray at Sandia



- Thermal Spray Technologies
 - Plasma Spray, CAPS (VPS, VLPPS)
 - TWA
 - Cold Spray
 - HVOF
 - Powder Flame Spray
 - Aerosol Deposition
- Process Diagnostics
- Highlight Recent Work in Aerosol Deposition

TSRL operates at least one version of every major spray process



Atmospheric Plasma Spray



CAPS:Vacuum, low pressure, and very low pressure plasma spray




Aerosol Spray Deposition



Cold Spray





Powder Flame Spray



Wire Flame Spray



HVOF




TSRL






Booth 1





Booth 1





CAPS







What makes the TSRL unique?





- Focus on Process Diagnostics for Thermal Spray
 - DPV-2000, Accura G3
 - Control Vision
 - Spectroscopy
 - Xenon-Flash Thermal Diffusivity
 - Beckman Coulter Particle Size Analysis
 - In-Situ Coating Property (ICP)
 - Laser Doppler Velocimetry
- Materials Science Expertise and Analysis Capability
- Strong Ties to Materials & Process Modeling at SNL
- LPPS® Thin Film & Cold Spray
- Experience supporting spray processes across entire technical and manufacturing readiness levels




Sensor based particle diagnostics measure particle temperature (Tp) and velocity (Vp).







Tp $\propto \lambda 1/\lambda 2$



 $\mathbf{V}\mathbf{p} = \Delta \mathbf{x} / \Delta \mathbf{t}$



Wire tip imaging


11 Powder particle size distribution


Incorporation of spray diagnostics for process optimization






Coating diagnostics tools for coating stress, modulus









BaTiO₃, Cu, and Residual Stresses


AEROSOL DEPOSITION RESEARCH

Aerosol Deposition (AD)


Sandia National Laboratorie:

- Room temperature, solid state deposition process for thick films (>1µm)
- Relies on aerosolized fine powder (sub-micron) accelerated to high speeds (>300m/s) within a vacuum environment for coating consolidation
- Capable of depositing ceramics, carbides, and metals with no feedstock melting or substrate heating

Enabling integrations of high melting temperature and/or thermally sensitive materials




Nozzles for achieving supersonic particle flow





Aerosol Generator for controlled powder feed




carrier gas

In Situ TEM Compression Results




Diameter ~ 0.24 μm, Open loop, Strain rate ~ 0.009 s⁻¹



Observed dislocation nucleation & movement. Dislocation plasticity preceded fracture.

Large displacement gain at a constant load ("burst") corresponds to particle fracture.




Mechanisms Underlying AD





INDENTATION


SINGLE-PARTICLES DEPOSITION



In both quasi-static and high strain-rate loadings, 0.3 μ m Al $_2$ O $_3$ feedstock particles underwent plastic deformation. Characteristics include:


- dislocation nucleation and slip
- shape change
- fracture into nanocrystals (15-30 nm)
- polycrystalline with mosaicity

- Kinetic energy →
 Absorbed strain energy
- Dislocation plasticity
- Fracture without fragmentation
- Tamping from subsequent impacting particles → building up dense coating



RT Deformation & Bonding Mechanisms Rational National Nat






RT Deformation & Bonding Mechanisms National Inhoratories




Kinetic Energy converted to absorbed strain energy, providing

- Dislocation plasticity to deform particle
- Fracture nanocrystalline formation in particle
- Chemi-mechanical bond between alumina particlesapphire substrate



RT Deformation & Bonding Mechanisms Sandia National Inhoratories






RT Deformation & Bonding Mechanisms National Inhoratories




Subsequent impacting particle imparts sufficient energy to

- Further deform splatted particle
- Provide further bond formation between splatted particle-substrate from "tamping effect"
- Compaction and densification of deposited coating from "tamping effect"



RT Deformation & Bonding Mechanisms Sandia National Indicatories







Residual Stress in AD films




- Motivation for study
 - Multi-layer integration, device building utilizing AD films
 - Understand process parameter influence on stress, coating formation dynamics, and resultant properties
 - Additional method for accessing repeatability of process



- Common measurement techniques for thin/thick films
 - X-Ray diffraction (Ψ² method)
 - Neutron diffraction
 - Substrate Curvature Stoney Formula




Schubert, Michael, Jörg Exner, and Ralf Moos. "Influence of carrier gas composition on the stress of Al2O3 coatings prepared by the aerosol deposition method." Materials 7.8 (2014): 5633-5642.



In-situ Curvature Measurements in Thermal Spray




- Allows observation of coating dynamics in real time
- Discrete measurements of stress during deposition and cooling
- Available as commercial tool



Kuroda, S., T. Fukushima, and S. Kitahara. "Simultaneous measurement of coating thickness and deposition stress during thermal spraying." Thin solid films 164 (1988): 157-163.






Matejicek, J., et al. "In situ measurement of residual stresses and elastic moduli in thermal sprayed coatings: Part 2: processing effects on properties of Mo coatings." Acta Materialia 51.3 (2003): 873-885.

In-situ deflection monitoring of AD films




Experiment Schematic



3-4 µm BaTiO₃ deposited onto soda lime glass


Collected Data



- Linear substrate curvature is observed with AD film deposition
- No thermally induced substrate curvature after deposition


Preliminary Experimental Results – Deposition Sandia National Inhoratories






Preliminary Experimental Results – Etching





Al₂O₃ on Glass


- Highly damaging to substrate Etches glass
- Self limiting film growth Requires process modification for deposition



Substrate Deflection Measurements of AD Deposition




BaTiO3 on Glass




Comparison to Thermal Spray




- AD has linear deflection accumulation with film growth
- Peak and Trough of deflection data correspond to raster pattern



- TS has linear deflection accumulation with film growth
- Peak and Trough of deflection data diverge with film growth due to CTE mismatch and temperature undulations with each layer addition






Schlieren Imaging of AD



We are using Schlieren imaging to better understand the dynamics of AD to improve process control. Note Shock Diamonds and Bow Shock visible as pressure is varied from vacuum to 15 psig



BaTiO₃ Aerosol Deposited Film




Why BaTiO₃?

- Ferroelectric with high dielectric constant (up to7,000) with spontaneous polarization
- Well studied and used material

Why AD?


- No feedstock heating -> Preservation of material stoichiometry and phase
- Room temperature process -> Integration with low melting temperature materials



Desheng Fu and Mitsuru Itoh DOI: 10.5772/61017

BaTiO₃ case study:


- Phase and grain size from deposition and heat treatment
- Residual stress by XRD and substrate curvature
- Electrical properties



AD built Cu and BaTiO₃ capacitor

XRD results – Composition & Phase






XRD Measurement – Grain growth



- >700°C, BaCO₃ decomposes & Ba₂TiO₄ forms
- Band narrowing & increased intensity Grain growth
- >900°C, see significant grain growth




XRD Measurement – Grain growth



INCREASING TEMPERATURES

- Crystallite size from (110)&(111) peaks
- 15-20 nm as-deposited vs. 80-90 nm 900°C
- Significant grain growth occurred >600°C
- After 1,000°C, > 100 nm detection limit



ISOTHERMAL HOLD

 Very little grain growth, even when held at 900°C for 16 hrs


Starting Grain Size (nm)	Annealing Temperature (°C)	Time (hrs)	At Temperature Grain Size (nm)
24	650	16	31
33	700	2	35
41	800	16	55
64	900	16	90

Isothermal hold at 900°C did not result in significant grain growth. Ramping temperatures appears to be more effective, providing higher growth rate.

We recognized the high temperatures needed to grow the grains and are currently exploring other treatment methods to effectively integrate with Cu (T_m 1083°C).³

Film Microstructures - FIB / TEM







As-deposited

Film Microstructures - FIB / TEM








- As-deposited films showed
 - undefined particle boundaries
 - polycrystalline with crystallite size <30 nm
 - some entrained particles (not significantly deformed)
 - cracks
- After 1200° C heating
 - Ba₂TiO₄ segregation to grain boundaries
 - Grain growth
 - pores

Residual Stress in BaTiO₃ on Glass




Experiment Schematic



3-4 µm BaTiO₃ deposited onto soda lime glass

Collected Data





- Linear substrate curvature is observed with AD film deposition
- No thermally induced substrate curvature after deposition


Sin²Ψ XRD Measurement - Strain






















Sin²Ψ XRD Measurement - Strain





















Electrical Properties – As-Deposited Feedstock Comparison




- 2 different powders, 2 different responses
 - Powder A psuedo cubic
 - Powder B tetragonal?
- As deposited films exhibit k<200
- Low frequency loss (space charge) observed in Powder B films

$C = \in_0 \in_r \frac{A}{d}$

Dielectric Permittivity




Capacitance and Loss



Brick-wall model and size effects






- A permittivity of the AD BaTiO₃ (k~100-200) agrees well with brick-wall theory
- Significant dilution from grain boundaries. Grain growth is required to increase permittivity.

P-E Loops indicate paraelectricity



- Pseudocubic nanocrystallinity generates <u>linear dielectric response</u>
- Nested loops show negligible hysteresis that is caused by conduction
- Voltage withstanding suggests no thru cracks are present





Other AD materials - Cu





BaTiO₃


Cu












Similarities and Contrast to Cold Spray (CS)


Sandia National Laboratories

- Relies on ductility of material to bond particles at high velocity – CS uses warmed particles for softening
- Substrate heating
 - CS warms substrates
 - AD remains at room temperature
- Particle Sizes
 - CS 5-25µm
 - AD 0.1-5µm
- Higher resistivity (10-25x) than bulk






King, Peter C., et al. "An experimental and finite element study of cold spray copper impact onto two aluminum substrates." Journal of thermal spray technology 19.3 (2010): 620-634.



Adhesion and Resistivity






Tape test with Kapton - Passed





500µm sprayed onto glass – delaminated with masking removal










Cu trace in Kapton tape









Cu in Kapton — Curvature vs Resistan Creditional Laboratories








Cu on APS Ceramic






Measured by multi-meter probes



Embedding Cu traces






Summary



- AD produces dense nanocrystalline functional films at room temp, enabling integration with low temp materials.
 - Great for structural and environmental protection applications.
 - Grain size can be tuned after deposition through heat treatment.
- Submicron sized ceramic particles can undergo dislocation plasticity under quasi-static loading and high strain-rate loading.
- Aerosol Deposition (AD) leverages use of submicron particles that are accelerated, impacted, deformed, and consolidated as films.
- Utilize substrate deflection and Schlieren to understand role of process parameters
- AD BaTiO₃ for capacitor application: In progress
- AD Copper for conductive film: In progress



Nanocrystalline AD BaTiO₃

& BaTiO₃ layers.

