



Ultrafast Laser Diagnostics to Interrogate High Pressure, Highly Collisional Plasma Environments

70th Annual Gaseous Electronics Conference
Pittsburgh, PA
Thursday, November 9, 2017

Ed Barnat and Andrew Fierro
Sandia National Laboratories, Albuquerque NM

INTRODUCTION AND MOTIVATION: CHALLENGES AND OBJECTIVES


- High pressure (~ 1 ATM and beyond) plasma is challenging environment.
 - Higher densities.
 - Chemically complex environments
 - Smaller length scales.
 - Shorter lifetimes.
- Investigate diagnostics methods to access this challenging environment
 - Extend laser-collision induced fluorescence (LCIF) to atmospheric pressure helium discharge.
 - Examine suitability of ultrafast-short pulse lasers for use to these environments.



Outline challenges and demonstrate implementation of LCIF to highly collisional environments.

OVERVIEW OF CHALLENGES OF EXTENDING LCIF TO HIGH PRESSURE

- Observed LCIF is superposition of several complex processes.
 - In general need a good model to describe the redistribution.



$$\frac{dN_j}{dt} = \underbrace{\left[\sum_{i \neq j} K_{ij}^e N_i - \sum_{i \neq j} K_{ji}^e N_j \right] n_e}_{\text{"Electron mixing"}} + \underbrace{\sum_k \left[\sum_{i \neq j} K_{ikj}^a N_i - \sum_{i \neq j} K_{jki}^a N_j \right] N_k}_{\text{"Neutral mixing"}} + \underbrace{\left[\sum_{i > j} A_{ij} N_i - \sum_{i < j} A_{ji}^j N_j \right]}_{\text{"Photon mixing"}}$$



$$\Delta N_j \sim K_{ij}^e n_e \times \Delta N_i \times \Delta t$$

$$\text{Photons emitted} \sim A_{jk} \times \Delta N_j \times \Delta t$$

Simplifications likely not to be so forthcoming at higher pressures

NEUTRAL INTERACTIONS KEY SOURCE OF INCREASED COMPLEXITY

- Neutral-impact redistribution can play dominant role at higher pressures
 - More-types and evolving nature of neutrals (dimers).
 - “Book keeping” can require sophisticated models.
 - Uncertainties in species and cross-sections limit accuracy.

Neutral mixing

$$\frac{dN_j}{dt} = \sum_k \left[\sum_{i \neq j} K_{ikj}^a N_i - \sum_{i \neq j} K_{jki}^a N_j \right] N_k$$

Bounds on detection

$$\frac{\Delta N_{Electrons}}{\Delta N_{Neutrals}} \sim \frac{K^e n_e}{K^N n_0} \sim 1$$

$$n_e \sim \frac{K^N}{K^e} n_0 \sim \frac{10^{-11}}{10^{-5}} n_0$$



Limit $\sim 10^{13}$ e/cm³ at 1000 Torr

Neutrals are anticipated place limits on lower bound of electron detection.

LIFETIMES OF EXCITED STATES BECOME VERY SHORT AT HIGHER DENSITIES

- Physics of electron-impact redistribution is not expected to change at higher pressures.
 - Sheer number of electrons increase probability of redistribution.
 - Effective Lifetimes become reduced because of redistribution.

$$\frac{dN_j}{dt} \sim \left[\sum_{i \neq j} K_{ij}^e N_i \right] n_e$$




Lifetime of excited states are quite short (~5 ns) at target conditions.

ULTRASHORT-PULSE LASER IS USED FOR INITIATION LCIF EVENT

- Ti:Sapphire, regenerative laser used to generate excitation pulse.
 - Tuned amplifier to 780 nm – doubled in BBO for ~ 390 nm.
 - ~ 100 fs pulse with 10 nm bandwidth (~ 100 cm $^{-1}$).
- Short-pulse laser well suited to interrogate short lifetimes (< 10 ns) and broad absorption profiles (~ 1 nm) associated with high pressure.
 - Still realize “step-like” populating process.
 - Sample most or all of the probed states.

Anticipated absorption profiles



Estimates of linewidths

ns laser ~ 0.5 GHz or 0.1 cm $^{-1}$

fs laser ~ 500 GHz or 100 cm $^{-1}$


Pressure Broadening ~ 0.01 GHz/Torr (He)

Short pulse enables access to all of the pressure-broadened line.


KEY CHALLENGE: GENERATING AND MANIPULATING WELL CHARACTERIZED PLASMA

- Need plasma with well controlled n_e , E/N to calibrate LCIF.
 - Plasma generation in 640 Torr He.
 - Double pulse method to separate generation and interrogation.
 - Spectrometer to identify, camera to image.

Discharge configuration



Key interrogation methods




Setup enables good access and control of the plasma for LCIF calibration.


DOUBLE PULSE PLASMA SEPERATES GENERATION FROM MANIPULATION

- Need plasma with well controlled n_e , E/N to calibrate LCIF.
 - First voltage pulse dictates plasma density and distribution.
 - Second pulse drives current through afterglow.

Sample Response



Observed Filament




Structure of the filament does not change significantly as it is “heated” – at least initially.

UTILIZE CURRENT-VOLTAGE TRENDS TO BOUND PLASMA PARAMETERS

- Published drift data (Phelps) is used to bound E/N with heating voltage.
 - Knees in current correspond to knees in drift velocities.
 - Electron density remains roughly constant at lower E/N values.

Extracted Current



Anticipated plasma parameters

$$n_e = \frac{m_e}{e^2} \frac{v_m}{N} \frac{N}{E} \frac{I}{A}$$

V	I	J	E/N	Vd	ne
V	A	A/cm2	Td	cm/s	e/cm3
225	0.1	3.18	0.1	1.50E+05	1.32E+14
700	0.6	19.10	5	1.00E+06	1.19E+14

Delay between first pulse and second pulse - Density



Magnitude of second voltage pulse – E/N

LCIF EVOLVES THROUGH SEVERAL SPECTROSCOPIC PATHWAYS

- Transitions from the laser excited 3^3P state have different E/N scaling
 - Capitalize on unique characteristics to assess $\langle E \rangle$ and E/N.

Pathway and Rates

Singlet




Identify pathways that yield good signals and are “easy to” evaluate.

RATIO OF LCIF LINES ARE UTILIZED TO IDENTIFY SCALING TRENDS

- E/N is tuned and LCIF is measured early during applied pulse.
 - Ratio of LCIF to laser excited 3^3P LIF is used to normalize signals.
 - LCIF acquired for ~ 10 ns, immediately after laser pulse.

LCIF scaling with E/N



Several LCIF transitions are observable!

RATIO OF LCIF LINES ARE UTILIZED TO IDENTIFY SCALING TRENDS


- Benchmark scaling of density dependence of 3³D LCIF.
 - Utilize the E/N invariance of 3³D LCIF above ~ 2 Td

Simplified Scaling

$$\Delta N_{3^3D} \sim K_{ij}^e n_e \times \Delta N_{3^3P}$$


$$\frac{\Delta N_{3^3D}}{N_{3^3P}} \sim K_{ij}^e n_e$$

Observed Scaling of LCIF



LCIF from 3³D scales linearly with electron density

DEMONSTRATION OF SPATIAL RESOLUTION PROVIDED BY LCIF




Averaged domain

cathode

anode


- Radial structure observed for various E/N.
 - Initial peak electron density of $2 \times 10^{13} \text{ e/cm}^3$.
 - Measured $\sim 2 \mu\text{s}$ in afterglow of first voltage pulse.
 - Measured in first 20 ns of applied heating pulse.



Observations consistent with initial assertions made

DEMONSTRATION OF SPATIAL AND TEMPORAL RESOLUTION PROVIDED BY LCIF

- Measured evolution of plasma formation during second pulse.
 - Initial peak electron density of $2 \times 10^{13} \text{ e/cm}^3$ (2 μs afterglow)




*LCIF provides two-dimensional
plasma structure*

UTILIZATION OF LCIF TO UNDERSTAND DISCHARGE EVOLUTION

anode


Averaged
domain



cathode


- Streak-like images of plasma initiation to examine dynamics of plasma formation.
 - Axial profiles at center of discharge.

Waveforms




Powered
anode


Emission



Metastables



Electrons



Grounded
cathode

LCIF captures spatial and temporal evolution of plasma formation.

CONCLUSIONS

- Ultra-fast LCIF shows promise for interrogating high pressure plasma systems.
 - Outlined pitfalls that might be encountered at higher-pressure systems.
 - Can be extended to other systems of interest (Ar, N,...).
- Preliminary LCIF results were published earlier this year
 - E.V. Barnat and A. Fierro, J.Phys.D:Appl. Phys. 50 (2017) 14LT01

Thank you for your attention!

*This work was supported by the Department of Energy Office of Fusion
Energy Science
Contracts DE-SC0001939 and DE-AC04-94SL85000*

AUXILARY SLIDES

UTILIZE CURRENT-VOLTAGE TRENDS TO BOUND PLASMA PARAMETERS

Published drift data

J. Pack et al. JOAP, 71 (11) p5363, 1992

