







The Challenges and Consequences of Uncertainties in Metal Laser Powder Bed Fusion

Bradley Jared

Materials Engineering & Manufacturing S&T






Outline

- Background
- Motivation
- 17-4PH inter-build study
 - structure-performance
- 316L intra-build study
 - process-structure-performance
- In-situ diagnostics
 - process-structure
- Summary
- opportunities for material design, collaboration



CORNING

3M



Acknowledgements

- Structure-performance research
 - Brad Boyce, Jon Madison, Jake Ostien, Jeff Rodelas, Brad Salzbrenner, Laura Swiler, Olivia Underwood, David Saiz, Kevin Webb (Georgia Tech), Burke Kernan
- Process-structure research
 - Jon Madison, Laura Swiler, David Saiz, John Mitchell, Erich Schwaller (UNM), Josh Koepke (UNM), Thomas Ivanoff, Daryl Dagel
- Topology optimization
 - Ted Blacker, Brett Clark, Josh Robbins, Miguel Aguiló





Sandia National Laboratories

- A National Security Science & Engineering Laboratory
 - “Exceptional service in the national interest”
- Nuclear Weapons
- Defense Systems & Assessments
- Energy & Climate
- International, Homeland, & Nuclear Security






Laser & Precision Manufacturing






microsystems-enabled photovoltaics (MEPV) module, Jared, *Opt Exp*, 2014




pulsed laser processing




precision machining




non-rotationally symmetric freeform mirror, Boye, *Opt Eng*, 2013






SNL's Additive Interests

- Reduce risk, accelerate development
 - simplify assembly & processing
 - prototypes, test hardware, tooling & fixturing
- Add value
 - design & optimize for performance, not mfg
 - complex freeforms, internal structures, integration
 - engineered materials
 - gradient compositions
 - microstructure optimization & control
 - multi-material integration
 - “print everything inside the box, not just the box”



prototype AM mirror & structure




printed battery



printing of
alumina




full scale additive weapon
mock-up



100%
dense



10%
dense


lattice implementation
w/TO solutions from
PLATO,
Robbins, **Add Mfg**, 2016



Powder Bed Fusion


- 3D Systems ProX 200 @ Sandia
 - 1070nm laser, 300W max power
 - scan speed = 1.4m/sec
 - 30 μ m powder layer, 100 μ m beam diameter, 50 μ m overlap
 - deposition rate $\sim$ 100 mm³/min
 - 10⁵-10⁶ °C/sec heating & cooling rates
 - melt pool depth $\sim$ 2-3x layer thickness
 - research platforms for process & material characterization
 - 316L SS
- Part capabilities
 - 0.001-0.002" best accuracy
 - surface finish
 - >5-10 μ m Sa ($\sim$ casting)
 - worse for downward surfaces
 - geometry limits
 - wall thickness > 100 μ m, overhangs < 45°
 - single material
 - > 99% density
 - strength typically near to, but less than wrought
 - anisotropic properties






Material Assurance


- Material formation concurrent w/geometry
 - want to predict part/material performance
 - feedstock certs inadequate for performance
 - **how to ID a bad part?**
 - complexity isn't "free"
 - requires significant design margins and/or rigorous post-process inspection / validation
- Quantify critical material defects & useful signatures
 - D-tests, NDE, process monitoring, mod-sim, ?
- Understand mechanistic impacts on properties
 - build process-structure-property relationships to predict margins & reliability
 - characterize stochastic response to design for uncertainties
 - provide scientific basis for qualification of AM metals for high consequence applications



17-4PH dogbone fracture surface








17-4PH dogbone porosity




17-4PH dogbone stress-strain response




Representative Material Defects




defect
dominated
failure, 2%
elongation,
17-4PH






17-4PH Study


- Exploring as alternate to 304L
 - higher strength w/multiple strengthening mechanisms
- Monolithic build w/110 dogbones
 - custom design per ASTM
 - external vendor w/constant process
 - Concept Laser M2
 - SHT + H900 HT @ Sandia
- High-throughput testing
 - digital image correlation (DIC)
 - custom dogbone per ASTM
 - necessary to rapidly capture material distributions
 - applicable for the lab & production




high throughput test sample w/120 dogbones,
1x1mm gage x-section



drop-in tensile tester




tensile test w/DIC
strain field
overlay




Stochastic Response


- Defect dominated failure
 - 3-parameter Weibull fits inform design threshold
 - ductile dimples & shear rupture planes
 - voids & lack-of-fusion boundaries are likely crack nucleation sites
- Extensive performance variations
 - can inter-build performance be predicted?



110 stress-strain curves for 17-4 PH after SHT+H900



failure at 2% elongation, SHT+H900






Material Performance Fit to 3-Parameter Weibull Distributions

- Based on weakest link theory

$$P = 1 - \exp \left[- \left(\frac{\sigma - \sigma_0}{\sigma_\theta - \sigma_0} \right)^m \right]$$


- where

- P = probability of failure at stress, σ
- m = Weibull modulus, i.e. scatter
- σ_θ = characteristic strength
- σ_0 = threshold, strength where $P = 0$









AM vs. Wrought 17-4PH




H900 data for vendor 1 (top left), vendor 2 (top right) & wrought (bottom) w/corrected stress area







Material Characterization

- NDE before testing
 - detect defects, performance correlations
 - density (Archimedes)
 - resonant ultrasound spectroscopy (RUS)
 - optical surface measurements
 - computed tomography (CT)
- Post mortem after testing
 - inform performance & failure mechanisms
 - fractography
 - metallography
 - composition
 - XRD
- Do reasonable defect signatures exist which tie to performance tests?



17-4PH dogbone porosity




fracture surface



Metallurgical Interrogations


- Microstructure
 - optical, SEM, EBSD, WDS micro-probe
- Composition
 - LECO combustion, ICP mass-spec, XRD
 - powder analysis
- Microhardness




EBSD phase map, SHT+H900, 22% retained austenite

Element	Vendor 1, run 2 (wt%)
Cr	16.64
Mo	0.045
Si	0.38
Nb	0.3
V	0
W	0
Ti	0
Ta	0
Al	0
Ni	4.24
Mn	0.24
C	0.012
N	0.056
Co	0
Cu	4.05
P	0.019
S	0.003
O	0.100
Nb	0.30


bulk chemical analysis




SHT+H900 microhardness along dogbone length




as-printed microhardness on gauge cross section




bulk XRD analysis



Trends Across the Part







Implicit Part Correlations

- Archimedes density
 - stronger correlations w/process performance
- Surface finish
- No significant trends observed




17-4PH dogbone surface roughness






Resonant Ultrasound Spectroscopy

- Swept sine wave input from 2-point transducer
 - spectrum = 74.2 kHz to 1.6 MHz
 - intent is to identify outliers, variations, process limits, defects
- Identified 19 resonance peaks
 - Z-score compares peak frequency w/average & std. dev.
 - no strong trends across 17-4PH dogbone population




resonance response spectra







Explicit Porosity Measurements

- Computed tomography (CT)
 - NDE “gold standard” for porosity measurement
 - gage sections imaged w/resolution of 7 or 10 μm voxel edge length
- What can we see? Does it inform material behavior predictions?
 - justifiable for qualification and/or production?




dogbone B,16 CT surface image (left), porosity map (right)





Defect Characterization








- Total Volume of Defects (V_{tot})
- Pore Volume Fraction (V_{fract})
- Spatial Location of Pores (x, y, z)
- Total Number of Defects (N)
- Total Defects/Length (N/L)
- Average Defect Volume ($V_{avg.}$)*
- Average Equivalent Spherical Diameter ($ESD_{avg.}$)*
- Average Cross-Sectional Area ($CSA_{avg.}$)*
- Average Nearest Neighbor Distance ($NND_{avg.}$)*


How do we *best* represent the defect populations present?



Statistical Correlations Are Flusive






Measure	R^2
No. of Defects	0.50
Avg. NN Distance (mm)	0.40
Avg. ESD (mm)	0.36
Max CSA Redux (mm^2)	0.38
Total Pore Volume (mm^3)	0.27
Avg. Defect Vol. (mm^3)	0.25
Max CSA Redux (%)	0.24
Maximum Pore Size	0.07
Seven factor multivariate regression	0.60



Post Mortem Analyses

- Can forensic trends be identified?
- CT data analysis
 - calculate cross-section per layer
 - gage sections are rough & porous
 - fractures sometimes correspond to minimum areas
 - general trends remain weak





Fractography

- Defect dominated failure observed
- Increasing data fidelity & integration
 - overlay fracture surface w/porosity map using DREAM.3D
 - roughness inhibits registration accuracy
 - fracture surface may correlate to large pore






B2, fracture surface optical image by structured light scanning






Microstructure Examination

- Compositional analysis identified no anomalies
- XRD revealed unexpected austenite variation in X-Y
 - what about Z?
 - further complication to dogbone performance
 - source = powder, atmosphere?







material performance variation w/austenite phase fraction



Material Models



- Want to inform & predict material variability
- Approach
 - explicitly subtract spherical CT porosity volumes from dogbones
 - solve tensile loading
 - ignore residual stress, surface finish & defects w/volume below $\sim 90\mu\text{m}^3$
 - continuum properties calibrated to low porosity sample D16
 - leveraged in on-going efforts
- Expectations
 - large defects will intensify & localize deformation
 - microscale void mechanisms will drive failure





316L SS Study


- Exploring intra-build variations, process sensitivities / margins / optimization
 - leveraging analysis tools developed
- Sandia ProX 200
 - 25 dogbones / process setting
 - parameters
 - power, velocity, cross-feed, scan strategy, # parts/plate
 - represents ~2500 dogbones
 - Gen2 HTT development
 - measurements
 - top surface distortion (after EDM)
 - surface finish (top, side, angles)
 - Archimedes density
 - CT
 - resonance testing
 - tensile testing
 - metallography, fractography




UTS variation w/power, velocity & scan pattern



representative texture map via EBSD, phase content has been relatively consistent across process settings







High Throughput Testing: Gen 2









Intra-Build Process Trends





Intra-Build Process Trends







ProX 316L Process Development

- Scope
 - process mapping w/CMU
 - process sensitivity study
 - powder reuse
 - machine metrology
 - in-situ process signatures


- Very robust material




unique EBSD grain structure for 316L SS



Gen 2 samples w/varying laser power









HTT 316L SS data, 50 1x1mm dogbone samples






Beam Diagnostics






Structure-Properties Summary

- Material assurance is a challenge
 - material behavior is complex
 - predictive inter-build correlations for 17-4PH have not been straight-forward
 - contributing factors include process, feedstock, measurement, surface finish, microstructure, residual stress, part geometry
 - orthogonal testing pursuing multiple signatures is invaluable (& necessary) for qualification / product acceptance
- Tools developed to interrogate & analyze defects
 - performance distributions can be captured efficiently & used to understand material & process
 - tracking intra-build population shifts may be possible
 - intra-build / process change correlations identified for 316L SS




predicted (color) vs. measured (grey) response for welds (PPM)




Pursuing In-Situ Signatures


- 3D Systems ProX 200
 - 3D Systems Open Protocol platform
- Thermal
 - Stratronics ThermaViz two-color pyrometer
 - IR cameras: FLIR C2, A310 & SC6811
- Optical
 - Photron PhotoCam Speeder V2 high speed cameras
 - blue light illumination
 - Ocean Optics LIBS2500plus spectrometer
 - Keyence LJ-V7020 & LJ-V7200 laser line scanners
- Acoustic
 - audio microphone, acoustic emission
- Laser characterization
 - Ophir Spiricon SP928 beam profiler
 - Ophir L50(300)A-LP1 power meter



FLIR A310, laser on plate, ~100W, 1.4m/sec, 125 μ m hatch, 100 μ m beam dia.




Photron high speed optical melt pool video




Intentional Porosity Structure


- Introduced intentional pores
 - 316L stainless steel
 - 1-10 layer thickness
 - 30-300 μ m
 - 1x1x5.25mm column
 - 175 layers
 - 87,500 T-V frames per part
- Tests are quick
 - data analysis is not...
 - seek to correlate spatial sensor data (X,Y,Z,time) to material porosity (X,Y,Z)



captured hole structure




captured defect holes part CT image, Zeiss Xradia 520 Versa, voxel resolution ~ 2 μ m, Harlan Brown-Shaklee



porosity map generated using DREAM.3D near the 10 & 20 μ m pores



Material Reconstruction




Adobe Photoshop



batch processing
16bit > 8bit conversion
lossless filetype
conversion

FIJI



alignment & registration
cropping
grayscale matching
autoleveling
image filtering
thresholding

3D reconstruction
3D quantification



DREAM.3D





image processing &
quantification. 3D
reconstructions



BlueQuartz Software
Specializing in Software Tools for the Scientist
<http://dream3d.bluequartz.net>




Serial-sectioning





μCT Data Registration

- Rough surfaces create challenges
- Registering pore structures to nominal design
 - calculate top three hole centroid locations
 - calculate $\Delta(x,y,z)$ from design locations
 - remove slope & offsets








intentional pore locations showing data misalignment






Pore Identification

- Largest 9 pores easily distinguished by volume
- 30 μm pore indistinguishable from process porosity by size








Melt Pool Monitoring


- Stratronics Therma-Viz two-color pyrometer
 - CMOS imagers, $\sim 20\mu\text{m}/\text{pixel}$
 - 750 & 900nm filters (short & long)
 - $T_{\text{pixel}} \cong \text{func}(I_1 / I_2)$
- Fixed field, angled side viewing
 - FOV: 80 x 65 pixel (1.6 x 1.3 mm)
 - frame rate: 6-7kHz
 - exposure: 90 μsec
- Challenges
 - data rate
 - image resolution & registration
 - emissivity variation across melt pool



ThermaViz installed in the 3D Systems ProX 200




ThermaViz raw intensity data (left), radiance data (center) & melt pool temperature (right)




Therma-Viz Data Analysis


- Registration tied to process layers
- Melt pool metrics
 - peak temperature, centroid location, area, length, width, kurtosis, skewness
- Two approaches
 - process experiments
 - Matlab, Stratonix CSVs, 10s-100s images
 - porosity column builds
 - Python scripts, Stratonix 'raw.viz' files, 100k images quickly (minutes)
 - compute pool properties using contour data












layer 155 melt pool temperature




layer 156 melt pool raw intensity, short wavelength (left), long wavelength (right)








Melt Pool Metrics













Line Scan on 316L Plate, 10mm/sec, 65W







Which are most important / indicative?







Line Scan on 316L Plate, 100mm/sec, 65W






Line Scan on 316L Plate, 1000mm/sec, 65W




Temperature Maps Developed Per Layer



frame #3

+




frame #4

+


...

+




frame #184

=




max temperature value @ each pixel across all frames




sum all temperature values @ each pixel across all frames


Data Correlations – 300 μ m Pore, Layer 155




μ CT intensity, 2 μ m voxels averaged over 15 layers




porosity




max temperature data



max intensity data, long wavelength




total temperature data




total intensity data, long wavelength


Data Correlations – 60 μ m Pore, Layer 31




μ CT intensity, 2 μ m voxels averaged over 15 layers



porosity




max temperature data




total temperature data

Finding Process Porosity





max temperature data, layer 173


?







15 layer averaged μ CT intensity (left) & porosity (right), layer 174






15 layer averaged μ CT intensity (left) & porosity (right), layer 173







Finding Process Porosity





Process-Structure Summary


- Exploring two color pyrometry for porosity detection
 - absolute temperature accuracy is questionable
- Intentional porosity
 - observed in pyrometry data down to $60\mu\text{m}$ size
 - $30\mu\text{m}$ pores $\sim$ same scale as process porosity
- Process porosity
 - correlations less straightforward
 - additional analyses on-going
- Is lower resolution & slower data rates still useful?
 - scale-up is a challenge




ThermaViz raw intensity data (left), radiance data (right) & melt pool temperature (bottom), 99ms exposure, 9Hz sample rate



-
- The diagram illustrates a multi-scale, multi-physics framework for Additive Manufacturing (AM) optimization and performance prediction. The central flow involves the following components and interactions:
- AM Process** (Central Blue Box): The core process being optimized and measured.
 - Quantify & Optimize** (Green Cloud): A feedback loop that uses **Performance Predictions** and **Exemplar Performance** to guide the **AM Process**.
 - Measure** (Blue Arrow): Data from **In-Situ Measurements** and **Ainstante Properties** is used to measure the **AM Process**.
 - In-Situ Measurements** (Blue Box): Real-time data collection during the AM process.
 - Ainstante Properties** (Blue Box): Properties measured during the AM process.
 - Inform** (Blue Arrow): Data from **In-Situ Measurements** and **Ainstante Properties** is used to inform the **Exemplar Models**.
 - Exemplar Models** (Blue Box): A collection of models used for performance prediction, including:
 - Process Models** (Blue Box): Models that predict the AM process outcomes.
 - Materials Models** (Blue Box): Models that predict the material properties of the AM process.
 - Predict** (Blue Arrow): The **Exemplar Models** are used to predict the **Exemplar Performance**.
 - Exemplar Performance** (Blue Box): The predicted performance of the AM process, which is used to guide the **Quantify & Optimize** loop.
 - Data Analytics** (Blue Cloud): A central hub for analyzing data from various sources, including **Exemplar Performance** and **Property Aware Processing**.
 - Property Aware Processing** (Red Cloud): A process that uses data from **Data Analytics** to inform the **AM Process**.
- Surrounding the central flow are several visualizations and data plots:
- material / part performance simulation**: A 3D visualization of a bracket with a color-coded stress distribution (vort_mises) ranging from 0.00 to 3.00.
 - process simulation**: A 3D visualization of a cylinder on a base, showing a color-coded temperature distribution (temp) ranging from 2,200 to 3,800.
 - AM 17-4PH tensile dogbone (above) & stress-strain response (below)**: A grayscale image of a tensile dogbone specimen and a corresponding stress-strain plot showing a yield strength of approximately 1000 MPa and a strain to failure of about 10%.
 - thermal history during bi-directional metal deposition**: A 3D visualization of a dogbone specimen with a color-coded thermal history map.
 - 17-4PH dogbone porosity**: A 3D visualization of a dogbone specimen showing internal porosity distribution.



Wholistic Design Paradigm for AM











QUESTIONS?

Bradley Jared, PhD



bhjared@sandia.gov


505-284-5890





Austenite Spatial Variation





As-Polished Microstructures

As-printed (no HIP)




HIP (15 ksi, 1093°C, 6 hrs)






HIP (15 ksi, 1093°C, 6 hrs)
+ ambient pressure 1200°C, 2
hrs








Impact HIP on 17-4PH

- 33 tensile bars were sent to external vendor for HIP, 4hr @ 1110°C, 100 MPa
- impact
 - collapsed internal porosity
 - decreased largest void size by ~80%
 - improved Weibull characteristic strength by 13%





*data for
single layer
of a 10mm
cube sample*




Metrology

- Unique challenges for processes, equipment & parts
 - geometry depends on material, process, machine, orientation, supports, post-processing...
 - equipment accuracy generally exceeds process
- Challenges
 - metrology can be harder than fabrication
 - inferior surface quality
 - form deviations included in uncertainty analyses
 - GD&T applies, but less “traditional” surfaces
 - internal features
 - now worried about material, not just geometry




Ti-6Al-4V polyhedron & “Manhattan” artifacts





Ti “Manhattan” error map




17-4 PH “death” star




17-4 PH polyhedron texture anisotropy map






Outline

- Slow velocity line scans
 - address limited frame rate
 - on-plate
 - better temperature values?
 - need to look at dendrite arm spacing to get cooling rates
 - scatter vs. velocity, power on printed surface
- Melt pool response
 - shutter speed, sample rate
 - bead on plate, single powder layers
 - line & area scans
 - laser power, velocity, cross-feed
- Jon's data analysis – part leaning?



Motivation


- Optical systems are commonly constrained by size, weight & power
 - many “non-precision” applications are addressing using AM
- Opportunities exist for light-weight, reflective optics
 - geometrical complexity (i.e. integration, optimization)
 - new materials (& hierarchies)
 - rapid design & fabrication cycles
 - limits include
 - form accuracy
 - surface finish
 - material selection



topology optimized part designed using lattice structures



direct write printed alumina part




Integrated Mirror

■ Design


- 101.6mm diameter flat mirror
- light-weighted w/conventional ribbing
- alignment blade flexures integral w/monolithic structure

■ Fabrication


- printed in Ti6Al4V using laser-powder bed fusion
- 0.5mm electroless Ni plating applied to front & rear faces
- diamond turned mirror face
 - plating issues resulted in pitting, poor form & finish
- lead time reduced from 18 to 3 months



monolithic mirror structure design





AM Ti6Al4V mirror w/diamond turned electroless Ni coating




New Design Freedom

- Computational synthesis for optimal material use
 - adaptive topological (ATO) & shape optimizations (SO)
 - leverages “complexity is preferred”
 - constrained by performance requirements
 - bio-mimicry requires AM
 - design occurs concurrent w/simulation



solution for a bar in pure torsion resembles a cholla cactus



Sandia Analysis Workbench (SAW)

Cubit - Topology Optimization

File Edit Navigate Search Run Window Help

*Model Navigator Cubit Tree Power Tools

*Model View - TimeStep102

Command Panel Job Status Progress

Showing 3 jobs, 2 filters are active.

Job Name	Stage	Queue Status	Submit Date	Machine
Demo	Finished	Completed	2015-10-19 12:3...	redsky
Test	Finished	Completed	2015-10-19 11:4...	redsky
3DMitchell	Finished	Completed	2015-10-19 11:3...	redsky

Geometry/Mesh: 'TimeStep102'

Cub File C:/Users/bh Jared/PLATO/3D Mitchell/3DMitchell_files/TimeStep102_cubit/TimeStep1

Journal File C:/Users/bh Jared/PLATO/3D Mitchell/3DMitchell_files/TimeStep102_cubit/TimeStep1

Mesh File C:/Users/bh Jared/PLATO/3D Mitchell/3DMitchell_files/simulation/TimeStep102.g

Next Steps

Execute Geometry/Mesh Node

Console Cubit Command History Cubit Errors

<terminated> Demo [Job Submission] Demo - post-processing

Output file patterns:
iso.exo

Testing file pattern: iso.exo
No files matching pattern: iso.exo
Retrieving job properties file...
Remote job properties file not found.

||||| Post Processing completed normally |||||


1 item selected

Copying /C:/Users/b...emo/Demo.gen





TO w/Lattice Structures



Optimizing stiffness w/fixed mass




10% dense





50% dense




100% dense



Tailored geometry avoids "loose ends"







Engineered Materials

- Integrated Computational Materials Engineering (ICME)
 - materials analog to mechanical engineering
 - microstructure matters
- Voxel access introduces new opportunities for control & design
 - spanning multi-scales is difficult
 - metallurgical limits exist





AM Inconel 718 texture control demo by ORNL



"We can now control local material properties, which will change the future of how we engineer metallic components," R. Dehoff




strain field due to tension-torsion




continuum model

crystal plasticity model





LENS® functionally graded materials





Plausible Topology Optimization (PLATO)


- SIERRA implementation
 - available for government use
- Current capabilities
 - SAW user interface
 - elasto-static & thermal solutions
 - load cases
 - displacement, surface or body loads, CG, temperature, flux
 - anisotropic, multi-materials
 - lattices
 - parallel HPC processing
- Future work
 - stress optimization, UQ, material distributions, more multi-physics, increase efficiency, process awareness, user intervention




10%
dense



*lattice implementation
w/TO solutions*



CG Offset




CG Offset

minimum compliance w/fixed CG location



*conversion
to CAD*



Abstract

- Additive manufacturing (AM) offers unprecedented opportunities to design complex geometries and optimized topologies for performance gains inaccessible under conventional manufacturing constraints. However, to facilitate adoption in high consequence applications, fundamental questions regarding the intrinsic reliability and repeatable performance of additive metals must be answered. Distinct from traditional subtractive processes, component geometry and material are formed concurrently in additive processes and preclude an a priori knowledge of material performance from feedstock properties. Of interest are powder bed fusion processes where a laser scans across successive layers of metal powder to fuse material and generate a desired part geometry. Such layerwise processing enables access to volume elements, i.e. voxels, throughout every part with opportunities for material control but also defect formation.
- Predicting material performance is challenging for powder bed processes since it involves complex melting and solidification interactions, and is implemented on equipment with limited capabilities for process control and/or defect tracking. Consequently, material performance is commonly indeterminate and introduces unacceptable uncertainties for certifying and qualifying additive components. On-going research is working to reduce these uncertainties by exploring the process-structure-properties triad of stainless steel alloys. Material characterization and testing is identifying the nature of critical defects, quantifying their impact on material properties, correlating their presence with processing conditions, and developing a basis for understanding defect formation mechanisms. Thus, critical defect “signatures” will be presented to provide a predictive framework for quantifying material performance distributions using techniques that span in-situ process monitoring, post-process computed tomography, metallography and tensile testing.