

Operating a $^{171}\text{Yb}^+$ Microwave Ion Clock in a Continuous Mode

Peter D. D. Schwindt

International Frequency Control Symposium

May 24th, 2018

Acknowledgements



Sandia National Laboratories

Clock Physics

- Peter Schwindt
- Yuan-Yu Jau
- Thai Hoang

Micro Yb Source

- Matthew Moorman, Ron Manginell
- John Anderson, Loren Gastian, Lyle Menk



ACES Project

- PI: Richard Overstreet
- PM: Mark Trainoff, Sam Stein
- Xianli Zhang, Jonathan Tallant
- Jay Noble, Dwayne Taylor, Armand Martins, Nakri Dao, David Guan, Mike Silveira, Dan Boschen



369-nm Laser

- Prof. Russell Dupuis, Prof. Shyh-Chiang Shen, Prof. Paul Yoder, Dr. Theeradetch Detchprohm

AM Fitzgerald

- MEMS Design: Carolyn White, Alissa Fitzgerald

Funding:

- Defense Advanced Research Projects Agency (DARPA)
- Program: Atomic Clocks with Enhanced Stability (ACES)
- Project: Portable Ion Clock Technology (PICT)

This research was developed with funding from the Defense Advanced Research Projects Agency (DARPA). The views, opinions and/or findings expressed are those of the author and should not be interpreted as representing the official views or policies of the Department of Defense or the U.S. Government.

Sandia National Laboratories is a multimission laboratory managed and operated by National Technology and Engineering Solutions of Sandia, LLC, a wholly owned subsidiary of Honeywell International, Inc., for the U.S. Department of Energy's National Nuclear Security Administration under contract DE-NA0003525.

Outline

Introduction

Pulsed Mode Ion Clock

- Compact $^{171}\text{Yb}^+$ Ion Clock

Continuous Mode Ion Clock

- Light Shift
- Clock Performance

F-state and Yb-H^+ trapping

369-nm Vertical Cavity Surface Emitting Laser (VCSEL)


Miniature Yb Source

Conclusion

ACES Project Goals and Applications

Achieve Cs Beam Clock performance in a mass and power constrained package


- 50 cm³, 250 mW, 3×10^{-14} performance
- Low environmental sensitivity
 - $10^{-15}/\text{C}$, $10^{-13}/\text{g}$, $10^{-13}/\text{Gauss}$,



Applications--Excellent timing for:

- Rapid GPS acquisition, and GPS denied navigation and timing
- Nano/pico (cube) satellites
- Pulsed radio and spread spectrum communications

Microsemi
5071A





Trapped Ion Clock for Miniaturization

Trapped ion clocks are already compact while delivering excellent performance.

- Low mass, size, power
- Trapped ion lifetime: up to 10,000 hrs
- Coherence time: > 100 s

Other approaches for ACES:

- Miniature fountain clock
- Miniature optical clock



^{199}Hg Trapped Ion Clock from JPL



Portable Ion Clock Technology (PICT)

Microwave Optical Double Resonance Clock Operation (Continuous Mode)


- Lasers and microwaves are on for continuous feedback
 - Fast attack time for use with degraded local oscillators
- Elimination of optical shutter
- Challenges: Signal to noise, bandwidth, light shift

Technology


- Passively pumped vacuum package
 - Challenges: F-state and Yb-H⁺ trapping
- Optical pumping and detection VCSEL at 369 nm
 - Very challenging: Will be a first ever demonstration
- Low power, low phase noise microwave synthesis




Critical Elements of the $^{171}\text{Yb}^+$ Ion Clock



Pulsed Mode $^{171}\text{Yb}^+$ Ion Clock




Photons/ion
369 nm: 300 - 500
297 nm: 1.5 - 2.5




3 cm³ Vacuum Package and Ion Trap



Vacuum package w/ Detector



Ion-trap electrodes



1. Vacuum package
2. μ -metal shield
3. Copper pump-out tube
4. Yb oven appendage
5. Electrical feedthroughs
6. C-field coils
7. Laser port (sapphire)
8. Fluorescence collection window (sapphire)
9. Lens and filters tube




Jet Propulsion Laboratory
California Institute of Technology

- Nan Yu
- John Prestage
- James Kellogg

- Titanium body with sapphire windows.
- Linear Quadrupole RF Paul Trap
- Pinched off since April 25th, 2012
- Buffer gas cooling with He
- Getter Pumped.
- Trapped ion lifetime > 3 weeks.

Complete Physics Package (circa 2013)

Sandia
935nm VCSEL




Preciseley
MEMS Shutter



Integrated Optics



Vacuum Package





Physics Package Interface




369-nm Laser Package




Ondax
369 nm ECDL



Integrated Clock Performance: Pulsed Mode, 297 nm Fluorescence



$^{171}\text{Yb}^+$ Ion Clock Performance: Pulsed Mode, 369 nm Fluorescence




- Table top laser and vacuum system
- Clock cycle time, $T_C = T_R + T_{OP}$
- $T_R = 100$ ms, $T_{OP} = 35$ ms

D. R. Scherer et al., "Analysis of Short-Term Stability of Miniature $^{171}\text{Yb}^+$ Buffer Gas Cooled Trapped Ion Clock," arXiv:1802.04832, 2018.



David Scherer


Continuous Mode $^{171}\text{Yb}^+$ Ion Clock



Photons/ion

$F = 1 \rightarrow F' = 0$: $\alpha = 300 - 500$

$F = 1 \rightarrow F' = 1$: $\alpha = 3$



- Optical and microwave power broadening determine linewidth

$$FWHM = \frac{1}{\pi} \sqrt{\frac{\alpha}{2} \Omega^2 + \left(\frac{R_{369}}{2}\right)^2}$$

- R_{369} : optical pumping rate. Ω : microwave Rabi frequency.
- Clock interrogation time set by the FWHM and optical pumping time

$$T_{OP} = \frac{\alpha}{\pi FWHM}$$

Continuous Mode Optimization

Calculate stability at 1 s

- $\sigma_y = \frac{1}{Q \cdot SNR}$
- Assume photon shot noise and fixed FWHM

- $$FWHM = \frac{1}{\pi} \sqrt{\frac{\alpha}{2} \Omega^2 + \left(\frac{R_{369}}{2}\right)^2}$$


Broad linewidth

- Fast attack time for locking local oscillator and lasers

Narrow linewidth

- Better stability
- Smaller light shift

Calculation of Allan Deviation



Light Shift Characterization of the Clock Transition


Tabletop lasers and electronics with sealed 3 cm³ vacuum package

Experimentally measure the light shift



- FWHM = 30 Hz, $P_{369} = 220$ nW
- Ion temperature = 1140 K

Calculation of the AC Stark Shift

- Include 369-nm laser intensity, detuning, and polarization and ion temperature
- Assume FWHM = 30 Hz
- Manually adjust frequency shift and detuning offsets and ion temperature
 - Ion temp = 1050 K





Light Shift Sensitivity



Light shift coefficient = $1.09 \times 10^{-11}/(\text{GHz nW})$

- 1 Hz: 4.5 MHz laser stability for $\sigma_y = 10^{-13}$
- 30 Hz: 0.15 MHz laser stability for $\sigma_y = 10^{-13}$

Clock Linewidth Measurements




Continuous-Mode Clock Stability

Short-term stability

- 30 Hz: $1.3 \times 10^{-11}/\tau^{1/2}$
- 1 Hz: $3 \times 10^{-12}/\tau^{1/2}$

Long-term stability


- 30 Hz: light-shift limited
- 1 Hz: reference limited



F-State Trapping Problem


- Collisions of Yb ions in the $P_{1/2}$ and $D_{3/2}$ states with He will transfer Yb ions into the $F_{7/2}$ state.
- Noble gasses do not quench the $F_{7/2}$ state.
- Lasers at 760 nm, 638 nm, or 864 nm will clear the F-state.
 - Another laser is too complicated.
- Nitrogen is known to clear the $F_{7/2}$ state, but it is pumped by the getter.
- Methane is not pumped by the getter and is a molecular gas.

Photon signal (Counts/0.1s)



D. J. Seidel and L. Maleki, "Efficient quenching of population trapping in excited Yb⁺," Physical Review A, 51, R2699 (1995)

Time (sec)



F-State trapping in the 3 cm³ vacuum package.








FIG. 3. Quenching rate of ytterbium's trap state vs N₂ buffer-gas pressure. The curved line represents a least-squares fit of the data to the polynomial $\Gamma_{31} = aP + bP^2$; $a = 3.63 \pm 0.12 \times 10^4 / \text{s Pa}$ and $b = -7.45 \pm 1.15 \times 10^6 / \text{s Pa}^2$, while the straight line represents a linear least-squares fit to pressures $\leq 26.6 \times 10^{-5} \text{ Pa}$.

Testing Methane as a Quenching Gas




Jau, Y-Y., J. D. Hunker, and P. D. D. Schwindt. "F-state quenching with CH₄ for buffer-gas cooled 171Y b+ frequency standard." *AIP Advances* 5.11 (2015): 117209.

Effects of Methane on the Clock State

- Estimated methane pressure required for F-State quenching in ^{171}Yb
 - 10^{-8} to 10^{-7} Torr
- F-state Fraction
 - $< 20\%$


- Effects on the ^{171}Yb ground state
 - Frequency shift due to collisions
 - 10^{-14} to 10^{-13}
 - Relaxation and decoherence of ^{171}Yb ground state due to collisions
 - $T_2 = 1000$ to 100 s

Frequency Pulling of Methane



A. Bauch, D. Schnier, and C. Tamm, "Microwave Spectroscopy of $^{171}\text{Yb}^+$ Stored in a Paul Trap," Proceedings of the 5th Symposium on Frequency Standards and Metrology, pp. 387–388, 1995.

Decoherence Rate in ^{171}Yb Ground State




Evidence for YbH^+

- Implement Continuous Mode clock
- Observe evidence for formation of YbH^+ molecule
- Increasing methane pressure gives more YbH^+

369 nm Laser Only

State Populations : $F = 1$ to $F' = 0$

$P_{369} \sim 0.26 \text{ uW}$, $P_{\text{uW}} = -56 \text{ dBm}$, $P_{760} = 0 \text{ mW}$, $P_{935} = 0 \text{ mW}$




- Molecule formed out of the $D_{3/2}$ state
- Tuned to a YbH^+ dissociation transition at 369.482 nm and observe rapid signal recovery


369 nm and 935 nm Lasers

State Populations : $F = 1$ to $F' = 0$

$P_{369} \sim 0.26 \text{ uW}$, $P_{\text{uW}} = -56 \text{ dBm}$, $P_{760} = 0 \text{ mW}$, $P_{935} \sim 1.2 \text{ mW}$



Study of Packages Sealed since 2012




Populations with 935 nm Laser on

Package	S-State	F-State	YbH ⁺
JPL 2.2	31%	13%	56%
JPL 2.3	33%	43%	24%

Pulsed-Mode Clock

369 nm laser: $F = 1 \rightarrow F' = 1$, 10 μW




- IMPACT JPL Vacuum packages:
 - F-state and molecular state trapping present in both packages
- Continuous-Mode operation seems to suppress the trapped population likely due to low photon scattering rates

Populations with 935 nm Laser on

Package	S-State	F-State	YbH ⁺
JPL 2.2	57%	9%	34%
JPL 2.3	96%	4%	0%

Continuous-Mode Clock




369 nm laser: $F = 1 \rightarrow F' = 1$, 0.6/1.0 μW



Determining Rates (Preliminary Data)


Study rates into and out of the F-State and the YbH^+ molecule

Observe changes over time in a seals package




Estimating the State Populations from the Model

More F-state trapping before pinch-off



More YbH⁺ trapping after pinch-off





369-nm VCSEL

Vertical Cavity Surface Emitting Laser (VCSEL)





- Develop hybrid-mirror DBR (HM-DBR) VCSEL with top dielectric DBR (DDBR) and bottom epitaxial semiconductor DBR (SDBR)
- Semiconductor DBR uses air gaps for high index contrast
- Demonstrated optically pumped laser operation
- Primary challenges
 - Current Injection
 - Heat extraction

SEM of
Air-Gap DBR




Yb Source: Silicon Micro Hotplate

- Cup size: 0.7 mm and 0.9 mm diameter
- Evaporate Yb into the Si micro hotplates
- Heat base to 750 °C for 8 min in vacuum
- 30-50% is deposited into the Si micro hotplate: 0.2-0.6 mg
- Typical power for Yb evaporation: $1.5 \text{ V} \times 0.17 \text{ A} = 255 \text{ mW}$





Highly Miniaturized Vacuum Package: 1 cm³

- The vacuum package was pinched-off on Thursday, October 30th, 2014.
- Trapped ion lifetime is ~50 hours.
- Pulsed-mode clock
 - $T_{\text{microwave}} = 700 \text{ ms}$
 - $T_{\text{optical pumping}} = 300 \text{ ms}$
- Magnetic field correlations removed



Schwindt, Peter DD, et al. "A highly miniaturized vacuum package for a trapped ion atomic clock." *Review of Scientific Instruments* 87.5 (2016): 053112.

Pulsed-Mode Clock Stability



Conclusion

Clock performance determined by clock mode and fluorescence wavelength and collection efficiency

Compact clock with 369-nm fluorescence challenging

System	Clock Mode	Fluorescence Wavelength	Short-Term Stability	Clock Linewidth
Compact Clock	Pulsed	297 nm	$20 \times 10^{-12} \tau^{-1/2}$	1 Hz
Tabletop	Pulsed	369 nm	$1.6 \times 10^{-12} \tau^{-1/2}$	8 Hz
Tabletop	Continuous	369 nm	$3 \times 10^{-12} \tau^{-1/2}$ $13 \times 10^{-12} \tau^{-1/2}$	1 Hz 30 Hz

Continuous mode can give fast attack time and no optical shutter

- But light shift must be controlled

Continuous mode does not have a problem with F-state or YbH^+ trapping

Future work: VCSEL development, compact clock design and construction

