


Evaluating Parameters and Performance of a Metallized Spray-Deposition Process



Authors

Daniella McCade, Kevin Hoyt, and Zachary Stephens

Sandia National Laboratories, Albuquerque, NM, USA

29th Annual Solid Freeform Fabrication Symposium, Austin, USA


August 13, 2018



Sandia National Laboratories is a multi-mission laboratory managed and operated by National Technology & Engineering Solutions of Sandia, LLC, a wholly owned subsidiary of Honeywell International Inc., for the U.S. Department of Energy's National Nuclear Security Administration under contract DE-NA0003525.

- Purpose
- The Direct-Write System
- Setting Up Baseline
- What Impacts Line Width?
- Case Study: Needle Depth
- Thinking about the Bigger Picture

Explore the capability of a new tool
with the ultimate goal of creating a
Design Guide




Overview

- Direct-Write System
- Additive manufacturing techniques
- Automates coating processes

How it Works

1. Mixture is loaded into a syringe
2. Sono-tek head aerosolizes mixture
3. FlashCut 6 interfaced with multi-stage platform
4. Material spray-deposited onto substrate




The Direct-Write System

Features and Impact

- Minimize overspray
- Integrated mixer
- Micrometer head to measure needle depth
- Parts 3D printed in-house for customization


Syringe with Stir Bar in Water



Direct-Write System

Plastic 10mL Syringe and Integrated Stirrer

Sono-tek Spray Head



Program Constraints:

- Metallized ink of Ti/Mn in 1-butanol
- Sheath gas (nitrogen, 10psi)

Constants:

- Al_2O_3 ceramic plates
- Material solids loading (20% by weight)
- Stir speed
- Stage movement speed
- Needle gage size

Variables

- Sono-tek Power (%)
- Needle depth (mm)
- Z Height/Distance from substrate (inches)
- Deposition (μL /35mm travel)
- Line width (mm)

Common Issues


- Error alarms from Sono-tek controller
- Z height <.5" discontinuous lines
- High deposition flow can leave excess material on the pathway (non-uniform)
- Clogging or bleeding of material
- G-Code pathing

Baseline Settings


- Sono-tek Power: 60%
- Z Height: .5"
- Deposition: 5 μ L/35mm travel
- Needle depth from spray head: .5mm

Proposed Experiment

- 12 Trials
 - Sono-tek Power (3 Trials)
 - Z Height (3 Trials)
 - Deposition (3 Trials)
 - Needle Depth (3 Trials)
- 3 Replicates
- Line Width
 - Why it matters
 - How it was measured




9 Sono-tek Power Aerosolizes Material




- The “Power 60%” trial involves all baseline settings

Print Impact: Low




Increasing Z Height Increases Line Width




- Largest line widths of chosen variables
- Measuring line width for larger Z heights became difficult to differentiate

Print Impact: Moderate




Sheath Gas Influences Deposition




- Discontinuous lines caused by sheath gas

Print Impact: High




Needle Depth Must Remain Low




- High needle depth had trouble aerosolizing


Print Impact: High



Nominal Needle Depth (.5mm)





High Needle Depth (1.5mm)



- Explore relationship between sheath gas and material deposition
- Start changing variables previously held as constants
- Look into uniformity between prints, where spray tends to aggregate, etc.

What is a Design Guide?

- Freezes process for production
- Provides margin information
- Addresses performance



A Large “Thank you!” to:

Sita Mani, Judi Lavin, Shaun Whetten, Kristin Wilde,
Lauren Gartner, Nathan Acree, David Keicher,
Dan Kammler, Shawn Dirk, and Collin Donohoue

Questions?

Z. Stephens, SFF 2017

- Introduced direct-write hardware
- DOE: Uniformity and Pick-up Weight
 - Defect counts
 - Print Speed
 - Z Height

Previous Direct-Write System

