

Listening to Temperature: Ultrasonic Non-Destructive Identification of Material Phase and Temperature

By: Dr. David A. Jack (PI), Taylor Jeffrey (Graduate Research Assistant)

In support of the research stated in standard purchase order 1529335 between Baylor University and Sandia National Laboratories Nondestructive Evaluation Department.

Under the guidance of David G. Moore, Department 01522, Sandia Delegated Representative


Sandia National Laboratories is a multi-mission laboratory managed and operated by National Technology and Engineering Solutions of Sandia, LLC., a wholly owned subsidiary of Honeywell International, Inc., for the U.S. Department of Energy's National Nuclear Security Administration under contract DE-NA0003525.

Overview

- Research motivation
- Ultrasonic theory basics
- Material Selection and Characterization
- Experimental Setup
- Data Collection and Processing
- Results

Research Motivation

- Needing to know the temperature of a material without being able to see or touch it
 - Inability to use invasive techniques
- Applications
 - Refineries and power plants
 - Food industry
 - Polymer composites



Research Motivation

What others have done:


- Ultrasonics in gases
 - Temperature reconstruction in high-temperature applications, such as power plant boilers (Bramanti et al)
- Ultrasonics in food industry
 - Identifying the fat content of chocolate (Winkelmeyer)
- Ultrasonics in polymers
 - Measuring the degree of cure in epoxy resins found in fiber-reinforced composites (Lionetto and Maffezzoli)
 - Measure in-line melt temperature of a polymer melt in a single screw extruder (Brown et al)

Our goals:

- Two-phase application of ultrasonics
 - Solid/Liquid
- Phase identification
- Temperature identification
- 2D imaging of results


Ultrasonic Theory Basics

- Through transmission
- Ultrasonic parameters
 - Speed of sound of a material changes with temperature
 - Time of flight is recorded by data collection software
 - Attenuation varies with material temperature





Experimental Equipment

- EUT3160 8-Channel Pulsar/Receiver
- Olympus 0.5 MHz/1.0" Transducer
- Graphtec GL820 Data Acquisition Device




Material Selection and Characterization

- Amorphous and semi-crystalline wax
- Highly attenuative
- Very low coefficient of thermal expansion
 - Prevents loss of contact between container and wax when solidification occurs
- A-scan taken when wax is completely solid compared to an a-scan when wax is completely liquid
 - The time of flight is significantly different for the two temperatures




Material Selection and Characterization

- Using the time of flight at known temperatures, we can create a speed of sound master curve
- Speed of Sound curve
 - Significant slope change between 40 and 50 degrees Celsius suggests a phase change occurs in that temperature range
- DSC curve
 - Heat flow corresponds to the amount of energy needed to change temperature
 - Melt occurs at 46.5°C
 - Solidification occurs at 43.2°C




Material Selection and Characterization

- Using the time of flight at known temperatures, we can create a speed of sound master curve
- Speed of Sound curve
 - Significant slope change between 40 and 50 degrees Celsius suggests a phase change occurs in that temperature range
- DSC curve
 - Heat flow corresponds to the amount of energy needed to change temperature
 - Melt occurs at 46.5°C
 - Solidification occurs at 43.2°C




Experimental Setup

- 8 transducers aligned in 4 ultrasound paths
- Through-transmission
- Ultem between transducers and container
- Acoustic gel used to couple surfaces
- Thermocouple array of 9 thermocouples, including one which records the heater-block temperature




Data Collection

- LabVIEW Front Panel
 - View up to 2 ascan simultaneously
 - Able to change the ascan being plotted on-screen during the test
 - Countdown to next scan
 - Test run-time
 - Scan number
 - Array of transducer transmit/receiver pairs
 - Experiment parameters
 - Folder that data is stored in




Data Collection


- LabVIEW Code
 - Aborts if pulsar/receiver cannot connect
 - Transmit and receive transducer do not need to be the same number
 - Adjusts the gain for each channel separately
 - Logs and saves the gain data as the test progresses
 - Logs and saves the ascan data as the test progresses



**Signal
Saturated**




**Low Data
Resolution**



**Correct
S-N-R**


Data Processing

- Process ultrasonic data
- Examine gain data
- Analyze frequency spectrum
- Bscans




Data Processing

- Process ultrasonic data
- Examine gain data
- Analyze frequency spectrum
- Bscans



Data Processing

- Process ultrasonic data
- Examine gain data
- Analyze frequency spectrum
- Bscans




Data Processing

- Process ultrasonic data
- Examine gain data
- Analyze frequency spectrum
- Bscans


Effective Speed of Sound:

$$C_{wax} = \frac{X_{wax}}{TOF_{wax}}$$






Data Processing

- Process ultrasonic data
- **Examine gain data**
- Analyze frequency spectrum
- Bscans




Data Processing

- Process ultrasonic data
- Examine gain data
- **Analyze frequency spectrum**
- Bscans




Data Processing

- Process ultrasonic data
- Examine gain data
- Analyze frequency spectrum
- Bscans




Data Processing

- Process ultrasonic data
- Examine gain data
- **Analyze frequency spectrum**
- Bscans




Data Processing

- Process ultrasonic data
- Examine gain data
- Analyze frequency spectrum
- **Bscans**





Data Processing

- Process ultrasonic data
- Examine gain data
- Analyze frequency spectrum
- Bscans



Data Processing - Thermocouples

- Linear array of thermocouples across the container
- 8 thermocouples recording planar temperature of wax
- 1 thermocouple recording heater block temperature, which is below the thermocouple plane and the transducer plane
- Surface plot of extrapolated radial temperatures




Data Processing - Phase and Temperature

- Phase

- Three-step function for speed of sound
- Phase estimated using speed of sound

- Temperature

- Assumed temperature profiles
- Boundary conditions
- Temperature estimated




Data Processing - Phase and Temperature

- Phase

- Three-step function for speed of sound
- Phase estimated using speed of sound




- Temperature

- Assumed temperature profiles
- Boundary conditions
- Temperature estimated




Data Processing - Phase and Temperature

- Phase
 - Three-step function for speed of sound
 - Phase estimated using speed of sound
- Temperature
 - Assumed temperature profiles
 - Boundary conditions
 - Temperature estimated



Data Processing - Phase and Temperature


- Phase
 - Three-step function for speed of sound
 - Phase estimated using speed of sound
- Temperature
 - Assumed temperature profiles
 - Boundary conditions
 - Temperature estimated




Results

- Comparison of ultrasonic data to thermocouple data for validation


TC Temperature ($^{\circ}\text{C}$), Time 0.0 minutes.



Estimated Temperature, Color in $^{\circ}\text{C}$.



Phase Estimation




Results


- At 252 minutes into the test the heater is turned off
- Compare the photograph from that time to the three plots shown




TC Temperature ($^{\circ}\text{C}$), Time 252.4 minutes.



Estimated Temperature, Color in $^{\circ}\text{C}$.



Phase Estimation



Conclusions and Future Work

- Ultrasonics is a viable method for noninvasive phase and temperature identification
- Future work
 - Scaling experimental setup
 - 3D phase and temperature
 - Finite element modeling
 - Characterizing additional materials

Acknowledgements

- Industry Sponsor: Sandia National Laboratories
 - David Moore
- Graduate Advisor: Dr. David Jack

Questions?