

X-ray Excitation of Thermographic Phosphors



PRESENTED BY

Eric R. Westphal, Steven F. Son, Enrico Quintana, and Kathryn N. G. Hoffmeister


PURDUE
UNIVERSITY.

PERC
Purdue Energetics
Research Center




Sandia National Laboratories is a multimission laboratory managed and operated by National Technology & Engineering Solutions of Sandia, LLC, a wholly owned subsidiary of Honeywell International Inc., for the U.S. Department of Energy's National Nuclear Security Administration under contract DE-NA0003525.


- Temperature measurements can be challenging within combustion environments.
 - Thermocouple: invasive, suffers from thermal lag, point measurement.
 - Pyrometry: non-invasive, but requires knowledge of emissivity.
- Phosphor thermometry has been successfully applied to such environments.
 - Involves imaging the temperature-dependent phosphorescence emitted by thermographic phosphors.




- Thermographic phosphors: ceramic matrix doped with a transition or rare-earth metal.
- Typically excited via laser.
 - LED excitation recently explored.
- Two characteristics of the phosphorescence are temperature dependent:
- Lifetime
 - Plot shows the time constant of $\text{Mg}_4\text{FGeO}_6\text{:Mn}$ as a function of temperature.
 - Frames captured at 125 kHz.



- Thermographic phosphors: ceramic matrix doped with a transition or rare-earth metal.
- Typically excited via laser or LED.
- Two characteristics of the phosphorescence are temperature dependent:
- Intensity Ratio
 - Top images show signal captured from a YAG:Dy sample from different optical filters.
 - Temperature found using calibration curve.
 - Camera frame rate set to 10 Hz.




- Would like to use X-rays as the excitation source.
 - This would allow for simultaneous X-ray probing and surface temperature measurements of a reacting sample.
- Several phosphors exist which are known X-ray scintillators and have thermographic properties when excited by laser.
- Goal: Determine if the induced emission of one such phosphor remains thermographic under X-ray excitation.
 - $\text{Gd}_2\text{O}_2\text{S:Tb}$ used in this study.




6 Experimental Methods


- Sample excited using a Comet MXR-451HP/11 X-ray source.
- Phosphorescence collected and imaged using a spectrometer (Ocean Optics FX-XR1-ES).
- Hot plate heated the sample.
 - Temperature monitored using handheld thermocouple reader (Omega Engineering).
- Spectrometer calibrated using a Hg-Ne pencil style calibration lamp (Newport, model 6034)



- Average $\text{Gd}_2\text{O}_2\text{S:Tb}$ phosphorescence spectra at several temperatures.
 - 15 spectra averaged at 22 °C, 5 spectra at all other temperatures.




- Section of the spectra showing more detail.
- Shaded areas show spectral bands used when calculating intensity ratios (based on filters available from Edmund Optics).



- Intensity ratio calibration

- Results for X-ray excitation compared to those for UV excitation from Cates et al. 1990.



Data taken from: M.R. Cates, K.W. Tobin, D. Barton Smith, Evaluation of Thermographic Phosphor Technology for Aerodynamic Model Testing, 1990.

- Induced phosphorescence from $\text{Gd}_2\text{O}_2\text{S:Tb}$ remains thermographic under X-ray excitation.
- Spectrum shifts as temperature is varied.
 - Opposite trends seen for some peaks in the spectra
 - Taking the ratio between two such peaks increases the sensitivity of the intensity ratio calibration.
- Intensity ratio calibrations created using spectrometer data.
 - Compared to previously published results for UV excitation.
 - Similar trends seen for both excitation sources.
 - The differences in these calibrations are most likely due to variations in the experimental setups between the two studies.
- These results serve as a first step towards simultaneous X-ray probing and surface temperature measurements.


Acknowledgements

NASA Space Technology Research Fellowship grant No. 80NSSC17K0190 (E. R. Westphal)

US Office of Naval Research, Multidisciplinary University Research Initiatives (MURI) Program, Contract: N00014-16-1-2557. Program managers: Chad Stoltz and Kenny Lipkowitz. (S. F. Son)

Sandia National Laboratories is a multimission laboratory managed and operated by National Technology & Engineering Solutions of Sandia, LLC, a wholly owned subsidiary of Honeywell International Inc., for the U.S. Department of Energy's National Nuclear Security Administration under contract DE-NA0003525.

SAND2019-21756



Questions?