



Single Event Latchup Sensitive Volume Model for a 180-nm SRAM Test Structure

Peng Wang¹, Andrew L. Sternberg¹, Brian D. Sierawski¹, En Xia Zhang¹,
Andrew M. Tonigan¹, Rachel M. Brewer¹, Nathaniel A. Dodds², Gyorgy Vizkelethy²,
Scott L. Jordan³, Daniel M. Fleetwood¹, Robert A. Reed¹, and Ronald D. Schrimpf¹

1. EECS, Vanderbilt University, USA;
2. Sandia National Laboratories
3. Jazz Semiconductor Trusted Foundry

This work was partially supported by the Defense Threat Reduction Agency through its Basic Research program and by AFOSR and AFRL through the HiREV program.

Sandia National Laboratories is a multi-mission laboratory managed and operated by National Technology and Engineering Solutions of Sandia, LLC, a wholly owned subsidiary of Honeywell International, Inc., for the U.S. Department of Energy's National Nuclear Security Administration under contract DE-NA0003525. This paper describes objective technical results and analysis. Any subjective views or opinions that might be expressed in the paper do not necessarily represent the views of the U.S. Department of Energy or the United States Government.

Introduction


Pulsed laser testing, such as two-photon-absorption (TPA), is emerging as a powerful tool to study Single-Event-Latchup (SEL). Previous TPA data defined the location of SEL sensitive volumes.

The Monte Carlo Radiative Energy Deposition (MRED) simulation tool can create a weighted multiple sensitive volume model. Normal and angular heavy-ion data can help calibrate and improve the model.

In this work, a multiple sensitive volume model for a 180-nm SRAM test structure is developed based on experimental data, including:

- Empirical match between TPA and heavy-ion tests in SEL cross section curves.**
- Focused beam heavy-ion measurements.**
- Calibration of the MRED model with both normal and angular data.**

Application of TPA in SEL




1. P. Wang et al., *IEEE Trans. Nucl. Sci.*, vol. 65, no. 1, pp. 502-509, Jan. 2018.



Wang et. al. ---Single Event Latchup Sensitive Volume Model for a 180-nm SRAM Test Structure

MRED Multiple SV Model

--- Application in SEU analysis



$$Q_{coll} = \frac{1 \text{ pC}}{22.5 \text{ MeV}} \times \sum_{i=1}^N (\alpha_i \times E_{dep_i})$$




2. Brian D. Sierawski, et al., IEEE TNS, 56 (6), p3085, 2009

Wang et. al. ---Single Event Latchup Sensitive Volume Model for a 180-nm SRAM Test Structure

Device and Measurement Setup



VANDERBILT
UNIVERSITY




- The devices are fabricated in the Jazz Semiconductor CA18HD process, mimicking an SRAM structure.
- Thousands of arrays are bonded together (in parallel). Each array contains 22 p-n-p-n cells.
- Test Conditions:
 - Bias Voltage = 3.3 V
 - Current compliance = 50 mA

Wang et. al. ---Single Event Latchup Sensitive Volume Model for a 180-nm SRAM Test Structure

Normal Incidence Heavy-ion Test


--- Empirical match with TPA data



Broad beam heavy-ion data from LBNL.

$$E^2 = 4 \times \text{LET (empirical)}$$

with E in units of nJ and LET in units of MeV-cm²/mg.




Focused beam heavy-ion data from Sandia.

Cu⁸⁺ with LET = 46 MeV-cm²/mg

Wang et. al. ---Single Event Latchup Sensitive Volume Model for a 180-nm SRAM Test Structure

MRED Model



--- Model structure details




Wang et. al. ---Single Event Latchup Sensitive Volume Model for a 180-nm SRAM Test Structure

MRED Model

--- Comparison between single SV and multiple SVs




MRED Model





Wang et. al. ---Single Event Latchup Sensitive Volume Model for a 180-nm SRAM Test Structure

MRED Model



Angular heavy-ion measurements

--- Effective SEL cross section vs. effective LET





★ For high LETs, the roll = 0 direction, across the well, is more sensitive than roll = 90° direction, along the well. But for low LETs, the conclusion is reverse.

Wang et. al. ---Single Event Latchup Sensitive Volume Model for a 180-nm SRAM Test Structure



Angular heavy-ion measurements

--- Match with MRED model



Angular heavy-ion measurements

--- Match with MRED model



Conclusions



We combined ion-induced latchup data and previous laser-induced latchup data to define a multiple, nested sensitive-volume model using the Monte Carlo Radiative Energy Deposition tool. A self-consistent description of the results of the full data set is obtained.

★ Heavy-ion Test

- A linear, empirical equation is derived to calibrate the energies from laser and heavy-ion.
- The SV location from TPA is consistent with the focused beam heavy-ion test.
- The direction across the well is more sensitive to SEL than the direction along the well.

★ MRED Multiple SV Model

- A simple set of concentric sensitive volumes can be used for SEL for IC well designs.
- It is possible to combine focused pulsed-laser and broad-beam ion-induced SEL data to define the sensitive-volume model for SEL. This process allows SEL to be incorporated into existing reliability assessments.