



This paper describes objective technical results and analysis. Any subjective views or opinions that might be expressed in this paper do not necessarily represent the views of the U.S. Department of Energy or the United States Government.



SAND2019-8818C



## Advanced Calibration of Decomposition Kinetics Models

Ellen B. Le Wagman

Sarah N. Scott, Ari Frankel, Ryan Keedy, Victor Brunini, Brent Houchens, Terry Johnson  
USNCCM15 AUSTIN, TX  
July 29, 2019

7/25/19



laboratories is a multimission laboratory managed and operated by National Technology & Engineering Solutions of Sandia, a wholly owned subsidiary of Honeywell International Inc., for the U.S. Department of Energy's National Nuclear Security Administration under contract

# Intro: Organic material decomposition


Organic materials are everywhere,  
unfortunately they burn



- A downside - decompose @  $\sim 250^\circ\text{C}$
- Motivation: Fire safety
  - Temperatures  $> 1000^\circ\text{C}$  in building fires, jet-fuel fires
- **Thermal decomposition:** Material  $\rightarrow$  Char + Gas


# TGA data: Mass loss history

- Thermogravimetric Analysis (TGA): Mg size sample, isolates chemical kinetics
- Record **mass loss history**  $M(T(t))$ , time, temperature





# Derivative data: Mass-loss derivative with respect to temperature

- Finite-differenced **mass-loss derivative** history  $\frac{dM}{dT}$



# Derivative data: Mass-loss derivative with respect to temperature

- Finite-differenced **mass-loss derivative** history  $\frac{dM}{dT}$
- Easier to see separate reactions



# Objective

- Given
  - TGA data
  - A proposed kinetics mechanism
  - State-of-the-art calibration methods

Part 1. **Q: How can we improve calibration results?**

# Objective

- Given
  - TGA data
  - A proposed kinetics mechanism
  - State-of-the-art calibration methods

Part 1. **Q: How can we improve calibration results?**

Part 2. **A: Exploit mathematical properties for fast, robust,  
deterministic calibration**

# Objective


- Given
  - TGA data
  - A proposed kinetics mechanism
  - State-of-the-art calibration methods

Part 1. **Q: How can we improve calibration results?**

Part 2. A: Exploit mathematical properties for fast, robust,  
**deterministic calibration**

Part 3. A: Gain UQ insights using **Bayesian calibration**

# Uncertain parameters to calibrate





$$\frac{dM_i}{dt} = -A_i \exp\left(-\frac{E_i}{RT}\right) M_i^{n_i}$$

- Total of 9 parameters to calibrate
  - $(A_i, E_i, n_i)$  for each reaction  $i$
  - $(\text{Prefactor, activation energy, order})$
  - Initial mass fractions
  - Char rate coefficient  $v_c$
- Method: Globalized Newton-type (`optpp_fd_newton, 'trust_region'; rol`)
- **Data is synthetic**—Assess results against a “truth set” of synthetic parameters

# How to quantify goodness of fit

- Need a **data misfit** metric
- Objective function choices: Which data/features to prioritize fitting?



**(100-0) Mass** loss misfit objective

$$f_1(m) = \sum_{t_i} (M(m) - M_i)^2$$


**(0-100) Mass-loss derivative** misfit objective

$$f_2(m) = \sum_{t_i} \left( \frac{dM(m)}{dT} - \left( \frac{dM}{dT} \right)_i \right)^2$$


**(50-50) Hybrid** misfit

$$f_3(m) = \lambda f_1 + (1 - \lambda) f_2, \quad \lambda = 0.5$$



# An unintuitive result: Derivative objective does not lead to the best derivative data fit





# Optimization history with derivative misfit



# Comparison of fit value history, different objective functions, same IC




# Contour slices: Why derivative misfit is worse



- Both objective functions have the same minimum
- But, mass misfit convex on a wider interval
- **Advanced methods shine when objective function is bowl-like.**


# Parameter UQ w/ Bayesian calibration

# Why and how: Bayesian UQ with DRAM



- Important differences—no truth, subjective prior, simplicity
- TGA: Characterize uncertainty around parameter choices (from deterministic calibration)
- Bayes theorem:  $\text{Posterior} \propto \text{Prior} \times \text{Likelihood}$
- New in Dakota: DRAM for Bayesian calibration



# Bayesian calibration: Data reduced the uncertainty



Prior: What we thought the range / probability for  $E_1$  was.

Posterior: (After 750,000 samples) – What we can infer now about  $E_1$ , using Bayes theorem (incorporate information in prior, data, model likelihood)

# Usefulness beyond posterior pdfs, application-dependent



- Is risk management the UQ goal?
- Posterior credibility envelopes contain a snapshot of **current state of knowledge**
- E.g., probability of Organic Material X losing mass before 150°C is 1%.

# Conclusions: TGA calibration with advanced methods

## ■ Deterministic calibration

- Recommend fitting mass data, *even if fitting derivative data is the objective*
- More convex objective function

# Conclusions: TGA calibration with advanced methods

## ■ Deterministic calibration

- Recommend fitting mass data, *even if fitting derivative data is the objective*
- More convex objective function

## ■ Bayesian calibration

- A new/different UQ tool
- Understand uncertain parameters for fire safety analysis

# Conclusions: TGA calibration with advanced methods

- **Deterministic calibration**

- Recommend fitting mass data, *even if fitting derivative data is the objective*
- More convex objective function

- **Bayesian calibration**

- A new/different UQ tool
- Understand uncertain parameters for fire safety analysis

- Fire safety application: Sometimes, a large gap between advanced tools and their use in engineering...
- ...Also means there are a lot of opportunities!