



Self-assembled growth of epitaxial III-V quantum dots

Sadhvikas J. Addamane, John L. Reno

Center for Integrated Nanotechnologies, Sandia National Laboratories Albuquerque, NM

U.S. DEPARTMENT OF
ENERGY
Office of Science
cint.lanl.gov

Introduction

• Motivation

Quantum dots (QDs) are semiconductor nanostructures that exhibit quantum confinement of carriers in all three spatial dimensions, resulting in atom-like discrete energy states. Specifically, III-V epitaxial QDs realized by self-assembly have been the subject of intensive research for several years and have proven to be a versatile system with various applications including for:

➤ Lasers ➤ Second-harmonic generation ➤ Solar cells etc.

More recently, their use as **sources of single and entangled photons for quantum applications** has motivated interest in high-quality epitaxial growth of these QDs.




Figure 1: Single QD integrated with Distributed Bragg Reflectors (DBRs) in a microcavity for a single photon source. (Wikiwand)

• Approach

Growth of the QDs shown here is carried out using solid-state **molecular beam epitaxy (MBE)**. Three different approaches are explored towards realizing high-quality QDs :

- **Stranski-Krastanov (S-K) growth mode**
- **Local droplet etching (LDE) method**
- **Submonolayer (SML) QDs**

MBE capabilities at CINT

- AlInGaAs MBE growth ; Si for n-doping and C for p-doping
- High purity and high mobility materials
- High precision control of thickness and composition

• Contact information

John L. Reno – jlreno@sandia.gov (Phone: 505-844 9677)

Sadhvikas Addamane – saddama@sandia.gov (Phone: 505-845 9755)

• S-K growth mode

- Strain between the epitaxial layer (QD) and the substrate drives 3-dimensional island formation. Eg: InAs on GaAs (7.16% mismatch)
- QD size, density and consequently emission wavelength can be tuned by modifying growth conditions. (shown in Fig. 2)
- Dimensions: Height – ~8nm ; Width – 50nm (Fig. 3)
- Room-temperature photoluminescence (PL) observed at ~1150nm from samples capped with GaAs.




Figure 3: AFM analysis of InAs QDs showing profile and size of typical QDs

• SML QDs

- Cycled deposition of submonolayer InAs in a GaAs matrix (2-4ML).
- Compared to SK QDs, submonolayer QDs show:
 - High areal density → high probability of carrier capture
 - Wider emission wavelength tunability (900-1300nm)
 - Lower linewidth



Figure 5: Schematic showing difference between S-K (left) and SML (right) QDs

• LDE method

- QD formed by etching of substrate to form a nanovoid, followed by filling.
- Dot dimensions (emission wavelength) can be tuned based on growth conditions and thicknesses. (700—900nm)
- Ideal for single photon emitters.

¹Gurioli, Massimo, et al. "Droplet epitaxy of semiconductor nanostructures for quantum photonic devices." *Nature materials* (2019):

Results &




Figure 2: 1 X 1 μm AFM scans showing ability to tune QD size and density by modifying growth conditions such as temperature, growth rate and III-V ratio




Figure 4: RT PL from capped InAs QDs showing emission around




Figure 6: Cryogenic PL results from SML QDs (Pump: 500nm)




Figure 7: Evolution of LDE method (left); AFM analysis of nanovoids formed by LDE (right)

LA-UR or SNL number



This work was performed, in part, at the Center for Integrated Nanotechnologies, an Office of Science User Facility operated for the U.S. Department of Energy (DOE) Office of Science. Sandia National Laboratories is a multimission laboratory managed and operated by National Technology and Engineering Solutions of Sandia, LLC., a wholly owned subsidiary of Honeywell International, Inc., for the U.S. DOE's National Nuclear Security

