




# Bubble Bifurcation in a Vibrated, Closed, Liquid-filled Cylinder



*Engineering Sciences Center – Sandia National Laboratories*

Dayna Obenauf, Benjamin Halls, and John Torczynski

*72<sup>nd</sup> Annual Meeting of the American Physical Society Division of Fluid Dynamics*

*Seattle, Washington, Nov. 23-26, 2019*



Sandia National Laboratories is a multimission laboratory managed and operated by National Technology & Engineering Solutions of Sandia, LLC, a wholly owned subsidiary of Honeywell International Inc., for the U.S. Department of Energy's National Nuclear Security Administration under contract DE-NA0003525.

- Breakup of interface – entrains bubbles below surface
- Complex physics from forces acting on bubbles




- $F_{Bjerknes} = \langle -V(t)\nabla P \rangle$

- $V(t)$  = bubble volume
- $\nabla P$  = pressure gradient

Primary Bjerknes – bubbles move down


Secondary Bjerknes – bubbles attract/repel



- Breakup of interface – entrains bubbles below surface
- Complex physics from forces acting on bubbles
- $F_{Bjerknes} = \langle -V(t)\nabla P \rangle$ 
  - $V(t)$  = bubble volume
  - $\nabla P$  = pressure gradient

Primary Bjerknes – bubbles move down


→ Bubble motion in a vibrating enclosed cylinder



## Experimental Apparatus



- Partially-filled cylinder undergoing vertical vibration
  - Cylinder height: 100 mm
  - Cylinder diameter: 12.5 mm
  - Liquid: PDMS Oil (20 cSt)
  - Fill: 50-90%
- Frequencies: 40-70 Hz
- Acceleration: 30 g



Nikon  
85 mm

Phantom  
VEO 640S

## Effects of frequency variation (with 70% fill)




40 Hz



50 Hz




60 Hz





70 Hz

# Effects of frequency variation (with 70% fill)





# Effects of frequency variation (with 70% fill)



## Effects of void fraction (at 50 Hz)




50%



60%



70%




80%




90%




## Effects of void fraction (at 50 Hz)




# Effects of void fraction (at 50 Hz)





50%



70%



90%



# Questions?

This presentation describes objective technical results and analysis. Any subjective views or opinions that might be expressed in the paper do not necessarily represent the views of the U.S. Department of Energy or the United States Government. Sandia National Laboratories is a multimission laboratory managed and operated by National Technology & Engineering Solutions of Sandia, LLC, a wholly owned subsidiary of Honeywell International Inc., for the U.S. Department of Energy's National Nuclear Security Administration under contract DE-NA0003525.