

Material Assurance in Metal Additive Manufacturing for High Consequence Systems



PRESENTED BY

Bradley Jared

Outline

Sandia overview

- motivations
- processes
- qualification
- computational tools
- characterization / metrology

Process optimization

- machine metrology
- mapping

Process control

- critical defects
- artifacts
- in-situ monitoring

Sandia National Laboratories

A National Security Science & Engineering Laboratory

- “Exceptional service in the national interest”

Nuclear Weapons

Defense Systems & Assessments

Energy & Climate

International, Homeland, & Nuclear Security






SNL's Additive Interests

Reduce risk, accelerate development

- simplify assembly & processing
- prototypes, test hardware, tooling & fixturing


Add value

- design & optimize for performance, not mfg
 - complex freeforms, internal structures, integration
- engineered materials
 - gradient compositions
 - microstructure optimization & control
 - multi-material integration
 - “print everything inside the box, not just the box”





316L SS lattice part


metal




part on plate







Cu-Al plasma sprayed graded density coating



plasma arc wire-feed

3" diameter
Ti-6-4 cylinder

direct write

aerosol
jet
printing
to 10 μ mceramic-thermoplastic 3D
(CT3D) printing aluminaroom temperature cure of
conductive traces on polymer filmNanoscribe two-photon
lithography

energetic materials

Material Assurance

Material formation concurrent w/geometry


- want to predict part/material performance
 - feedstock certs inadequate for performance
- **how to ID a bad part?**
 - complexity isn't "free"
 - requires significant design margins and/or rigorous post-process inspection / validation

Quantify critical material defects & useful signatures


- D-tests, NDE, process monitoring, mod-sim, ?

Understand mechanistic impacts on properties


- build process-structure-property relationships to predict margins & reliability
- characterize stochastic response to design for **uncertainties**
- provide scientific basis for qualification of AM metals for high consequence applications



17-4PH dogbone fracture surface




17-4PH dogbone porosity



17-4PH dogbone stress-strain response

Foundational Elements of Qualification




Qualification Tomorrow



“Changing the Engineering Design & Qualification Paradigm”

- leverage AM, in-process metrology & HPC to revolutionize product realization
- accelerating design to production



9 PLATO Design Platform



End-user environment for physics-based design using topology optimization

HPC-enabled: physics, optimizers, services, ...

Interactive design feedback and user control

Smooth, print-ready designs




Extensible architecture



Website: www.sandia.gov/plato3D

Github: <https://github.com/platoengine/platoengine>

email: plato3D-help@sandia.gov




*Interactive design feedback
and user control*

Optimization-Based Design for Manufacture


“Manufacturability” objectives: integrate manufacturing process awareness into optimization-based design tools to enable manufacturability and performance

- static loads, stress constraints, thermomechanics, residual stress
- mass, compliance, thermomechanical minimizations


Concurrent shape and topology optimization: deliver an optimization-based concurrent component/system design tool to reduce design iteration cycle time




coupled thermo-mechanics TO geometry generation, maximized stiffness & heat conduction



residual stress prediction from high-fidelity process simulation



Models Bridging Length Scales




LAMMPS

ARIA


ADAGIO

SPPARKS


Solidification Scale Thermal
M. Martinez, B. Trembacki, D. Moser




Build Scale Thermal + Mechanics
K. Johnson, K. Ford, L. Beghini, M. Stender & J. Bishop




Powder Spreading
D. Bolintineanu




Powder Behavior
M. Wilson



Mesoscale Texture/Solid Mechanics
T. Rodgers, J. Brown, K. Ford



Build Scale Microstructure
T. Rodgers, J. Madison




10^{-6}

10^{-3}


1

Length Scale (m)


High Fidelity Process Models Provide Resolution at Each Laser Pass




304L Two Pass LENS Thin Wall Build Study Examining Baseplate Preheating Effects




von Mises Stress Along Wall Centerline






Stress_XX Along Wall Centerline




High Fidelity Models Inform Reduced Order Models



Enlarged Heat Source* and Layer
Thickness
100 cpus
6 hrs (~real time)




Mechanical Inherent Strain
60 cpus
30 minutes




* Similar to Hodge et al. 2014 and 2016, Ganeriwala et al. 2019

Microstructure Prediction in Stochastic Parallel PARTicle Kinetic Simulator (SPPARKS)



Thermal Simulation from
Sierra/Aria (Thermal/Fluid Solver)




Single Continuous Build





Double Build
(8 second delay in
between layers)

304L Tube, Johnson et al. *Computational Mechanics* 2018




Stainless Steel Thin Wall Texture Prediction





All simulations performed with nucleation densities of 8e13

316L Stainless Steel Column


16 Predicting Part Performance




representing porosity as initial damage



SNL/NM prediction for 3rd Sandia Fracture Challenge




material response changes w/voids
& surface roughness



Growing interest for designers in applications

Challenges


- design to requirements
- representative material properties
- metrology & inspection




latticed tube simulation



latticed part in 316L SS



Zeiss Xradia 520 Versa μ CT of struts & node




Ti6Al4V CT data from Nikon 450, red = missing struts, green = nominal, purple = oversized


Monitoring Powder Reuse

Tracking powder size, morphology & EDS composition w/reuse

- satellites & agglomerates increase
- observe highly spherical, ferrite particles
- increase in fines & reduction in larger particles
- collected over 30 reuses w/powder under Ar





Virgin: 7.90 g/cm^3
Reused: 7.81 g/cm^3



Material properties remain stable

316L SS is a robust material for processing & properties



High Throughput Testing - Alinstante

Properties... In an instant

- commonly resource constraint

Automation & robotics

Consistent, rapid, & efficient

Properties

Tensile strength
Ductility
Toughness
Hardness
Wear & friction
Permeability
Thermal expansion
Reactivity/corrosion
Electrical conductivity
Resonance
etc.

Structure


Geometry
Roughness
Porosity
Chemistry
Phase content
Grain Size
Crystal Texture
Residual stress
Dislocation content
etc.

Process


Surface remediation
Heat treatment
Subtractive machining
Coating
Joining
Integration
etc.



robotic work cell for material characterization



316L SS dogbone
array with 25
dogbones, 1x1mm
gauge



Calibration Testbed for IR Sensors


Using passive microwave radiometry to measure emissivity & temperature

- measures %R of 137 GHz radiation from surface
- 20-1500 ° C, 2 Torr in Ar chamber
- expected uncertainty ~10°C
- Initial use is IR Camera calibration
- Extreme dynamic range (cryogenic temperatures to millions of Kelvin)
- Linear relationship between radiated power and temperature enabling *single-point black body calibration*.
- Thermal Return Reflection (TRR) technique enables real-time measurement of emissivity.


MIT collaboration




vacuum chamber




1500 °C furnace in operation




metrology testbed layout




mm-wave radiometer system schematic





radiometric temperature from receivers showing freeze/melt cycles of 316L SS

computed tomography


dimensional inspection




porosity assessments

pulse-echo ultrasound

Gate 1 signal



Gate 2 signal



CT images of 98% (left), 96% (center) & 93% (right) dense Al10SiMg dogbones (left) & attenuation of 10MHz ultrasonic backwall reflections (right)


Resonant Ultrasound Spectroscopy

Swept sine wave input from 2-point transducer


- spectrum = 74.2 kHz to 1.6 MHz
- intent is to identify outliers, variations, process limits, defects

Identified 19 resonance peaks


- Z-score compares peak frequency w/average & std. dev.
- no strong trends across 17-4PH dogbone population



resonance response spectra



dogbone Z-score data spread







Measuring complex topologies is non-trivial

- access
- slopes
- surface roughness
- data management & analysis

Significant part distortion

- build plate & part
 - top surface of legs parallelism to center plane
 - on plate = 25-100 μm
 - off plate = 280-300 μm
- will part mate assembly
- where are proper datums?
 - surface finish exacerbates (printing, supports)



Motion Stage Errors

100mm ball screw drives

- supply piston – controls powder dosage
- build piston – controls layer thickness

Measurements

- LJ-V7200 laser profiler
 - range: $\pm 48\text{mm}$
 - Z repeatability: $1\mu\text{m}$

Build piston testing



- simple linear motion
- step errors $\sim$ powder size
- errors increase w/step size



supply piston drive (left) & build piston drive (right)





Keyence LJ-V7200 focused onto build plate



Build Process Errors

Replicate build process


- 30 μ m layers, layer then laser melting locations
- step errors $\sim$ powder size
- problem?
- process exhibits some “self-healing”




26 Laser Power @ Build Plate

Want power @ powder layer, not machine setting

- required for accurate & repeatable process optimization




Ophir L50(300)A-LP1 power meter on the build plate




Beam Profiling

Measured



- diameter along optical axis
- variation w/laser power
- temporal response
 - heating & cooling
- original & upgraded f-theta optics



*Ophir Beam Gage
software interface*





*Ophir SP 928 profiler on the
build plate*




Original F-Theta Diameter Variation w/Time & Stage Position

Thermal lensing obscures optimal focus for a realistic build cycle

- introduces challenges & uncertainties to part & material generation



nominal focus offset





4mm focus offset

F-Theta Upgrade Diameter Variation w/Time & Stage Position

Dramatic reduction in thermal lensing & improved repeatability / consistency




Critical to on-going process optimization efforts



F-Theta Upgrade Focal Distance

How critical is build plate location relative to laser focus?

- “optimal” process appears to be +1mm from “focus”
- presumably plasma plume impacts optimal offset




Process Optimization

AM metal qualification remains a challenge for high consequence systems

- machine metrology is a critical
- what are process tolerances & margins?
- does a truly optimal process state exist?
- can optimization be performed faster & cheaper?


Explore process maps

- parameters
 - laser power (10-240W), velocity (50-2800mm/sec)
 - powder layer thickness (30, 40 μ m), average powder diameter (15.0, 25.0 μ m), laser focus offset (-1.5 to +3.5mm)
- performance metrics
 - surface finish, form error, density, tensile properties, Charpy toughness, microstructure
- experiment forms
 - line scans, area pads, density cubes, HTT tensile, Charpy



Kruth et al, (2008) "Application of dimensional analysis to selective laser melting", Rapid Prototyping Journal, Vol. 14 Issue: 1, pp.15-22


Process Maps: Line Scans, Area Pads & Density Cubes




100 W, 250 to 2500 mm/s on pad




melt pool on plate, 100W, 1500 mm/s




area pads



density cubes



Material Microstructures, 30 μ m Layer Thickness



High-Throughput Tensile

1x1x4mm gauge section, 10 or 25 dogbones per array




- five build plates
- varied power & velocity near process plateau

>500 dogbones tested


- density (Archimedes)
- surface roughness
- mechanical properties
 - UTS, YS, modulus, ductility

process “plateau” depends on requirements

- density isn't a definitive process metric
- properties & manufacturability trades
 - how do properties scale w/feature & geometry?



Tensile Map



max YS: 489 Mpa

◦ @ 200 W, 2200 mm/s







max UTS: 621 Mpa

◦ @ 200 W, 2000 mm/s

max ductility: 66%

◦ @ 120 W, 1000 mm/s

AM Material Defects Represent Multiple Failure Modes



defect dominated failure, 2% elongation, 17-4PH


Stochastic Response

Defect dominated failure


- 3-parameter Weibull informs design threshold
- ductile dimples & shear rupture planes
- voids & lack-of-fusion boundaries are likely crack nucleation sites

Extensive performance variations


- can inter-build performance be predicted?



material performance fit to 3-parameter Weibull distributions




110 stress-strain curves for 17-4 PH after SHT+H900




failure at 2% elongation, SHT+H900

AM vs. Wrought 17-4PH



H900 data for vendor 1 (top left), vendor 2 (top right) & wrought (bottom)
w/corrected stress area



Lack of Control Produced Material Uncertainty in Early AM Metals

17-4PH parts requested from external vendor in 2015



- analysis confirmed 17-4PH composition, but unexpected microstructure

Sandia did not know or control



- feedstock pedigree, machine, build environment, process inputs or post-processing steps

Not-surprisingly, extensive material variability observed


nominally 17-4PH high throughput tensile (HTT) sample w/120 dogbones, 1x1mm gage x-section, printed by an external vendor



unexpected microstructure with 43% austenite, 57% martensite



Difficulties Predicting I7-PH Behavior



high throughput test sample w/120 dogbones,
1x1mm gage x-section



Material uniformity

- microstructure gradients
- porosity
- surface roughness
- unknown feedstock & process inputs
- residual stress / part deformation


Simple geometry

- uniform axial tension

Measurement inconsistency



dogbone B,16 CT surface image (left), porosity map (right)



dogbone C,16 CT surface image (left), porosity map (right)

Process Knowledge & Control Reduces Material Variability

316L stainless steel

- more robust material

3D Systems ProX 200


- process space mapped & machine performance characterized

controlling & logging every part, build & powder cycle



- feedstock pedigree, build environment, process inputs, post-processing
- printing & testing artifacts w/build cycles
- storing feedstock, process & printed material data in GRANTA
- capabilities for in-situ machine & process monitoring



build plate w/process artifacts






baseline 316L SS
microstructure



316L SS Tensile Data Over Time

High-throughput tensile data

- 25 & 10 dogbones per build plate
- 1x1x4mm gauge section
- two powder lots
- same composition and ave. powder diameter
- transitions correspond to machine, powder or process changes




Property Distributions



Must consider material performance distributions

Explicit material correlations can be established

Inter-build variation can exceed intra-build variation



data spans five different power settings over 50W



Gross Defect Failure Remains a Concern

316L SS tensile dogbone

- 1x1x10mm gage section
- Fein Focus 225kV
 - 12.6 μ m voxels

Gross defects observed




- equivalent diameter scales
 - red: $\sim 190\mu$ m
 - green: $\sim 140\mu$ m
 - blue: $\sim 80\mu$ m

Failure initiated near largest pore

- pore deformation observed

Identifying gross defects is reasonable

- establishing tolerances remains challenging



Process Monitoring – Multiple Signatures are Available

Thermal

- Stratronics ThermoViz two-color pyrometer
- IR cameras: FLIR C2, A310 & SC6811

Optical

- Photron PhotoCam Speeder V2 high speed cameras
- blue light illumination
- Ocean Optics LIBS2500plus spectrometer
- Keyence LJ-V7020 & LJ-V7200 laser line scanners

Acoustic

- audio microphone, acoustic emission

3D Systems Open Protocol platform


- PSU multi-spectral sensor

Managing & analyzing data streams is crucial

- large
- non-linear correlations



ThermaViz installed in the ProX 200




FLIR A310, laser on plate, ~100W, 1.4m/sec, 125μm hatch, 100μm beam dia.



Photron high speed optical melt pool video

Real-Time Machine Monitoring Reveals Process Perturbations




ARCS output for a simple test pattern

- Archive, Research, Control, Synchronization (ARCS)
- Penn State, 3D Systems collaboration
- motion @ 100kHz

*desired
motion*

*galvo
errors*



Two Color Pyrometry Melt Pool Monitoring

Stratonics Therma-Viz two-color pyrometer

- CMOS imagers, $\sim 20\mu\text{m}/\text{pixel}$
- 750 & 900nm filters (short & long)
- $T_{\text{pixel}} \cong \text{func}(I_1/I_2)$

Fixed field, angled side viewing




- FOV: 80 x 65 pixel (1.6 x 1.3mm)
- frame rate: 6-7kHz
- exposure: 90 μsec

Challenges

- data rate
- image resolution & registration
- emissivity variation across melt pool
 - unquantified temperature uncertainties



ThermaViz installed in the 3D Systems ProX 200



ThermaViz raw intensity data (left), radiance data (center) & melt pool temperature (right)

Pyrometry Signal Analysis


Registration tied to process layers

Melt pool metrics


- peak temperature, centroid location, area, length, width, kurtosis, skewness

Two approaches

- process experiments
 - Matlab, Stratonic CSVs, 10s-100s images
- porosity column builds
 - Python scripts, Stratonic 'raw.viz' files, 100k images quickly (minutes)
 - compute pool properties using contour data




layer 155 melt pool temperature, Matlab analysis of Stratonic software output



melt pool motion, nominal settings, Python script analyzing raw image data


Melt Pool Metrics

Process parameter line scans, Laser power = 25%, 35%, Melt pool metrics, Layer 179



Which are most important / indicative of void structures?

Material Reconstruction



Tools developed for material reconstruction & mapping pore locations to diagnostic signals

- data analytics & processing streams are crucial, complex and not optimized

Intentional Porosity Structure

Design

- 1-10 layer thickness
 - 30-300 μm
- 1x1x5.25mm column
 - 175 layers
 - 87,500 T-V frames per part

Fabrication


- 316L stainless steel
- 3D Systems ProX 200 laser powder bed fusion

Material characterization


- Zeiss Xradia 520 Versa μCT
- voxel resolution $\sim 2\mu\text{m}$

Data analysis

- pore size detection limit
- seek to correlate spatial sensor data (X,Y,Z,time) to material porosity (X,Y,Z)
- non-trivial effort




captured holes structure design



1x1x5mm 316L SS column w/support walls



captured defect holes part CT image



porosity map generated using DREAM.3D near the 10 & 20 μm pores


Process-Structure Correlations

Exploring correlation of μ CT voids w/thermal signatures


- sizes
 - μ CT: $2 \times 2 \times 2 \mu\text{m}$
 - pyrometer: $20 \times 20 \times 30 \mu\text{m}$
 - multiple μ CT voxels map to one pyrometer voxel
- registration is first step before correlating statistical measures
 - μ CT & pyrometer data reveal part warpage $\Rightarrow$ data sets are misaligned
- binning & scaling of pyrometer data produces best registration
 - layerwise implementation appears best

Correlating voids to melt pool response


- where are signatures found?
 - same layer, above, below?



μ CT bitmap





melt pool temperatures






1 mm

μ CT reconstruction





pyrometer data
reconstruction

Registration & Feature Detection







comparison of intentional defect volumes, large voids are relatively easy to identify

Correlating Process Signatures w/Material Structures




melt pool outliers
via *machine learning* correlate
local void porosity






Questions?

Bradley Jared, PhD, bhjared@sandia.gov, 505-284-5890




Deterministic



Non-Deterministic

Mass Minimization



- Objective: Mass
- Scenario: Load w/ Stress Constraint



Stress constrained mass minimization formulation
courtesy of Prof. Glaucio Paulino, Georgia Tech.


Compliance Minimization

- Objective: Compliance
- Scenario: Multiple mechanical loads



Thermomechanical Compliance

- Objective: Internal Elastic Energy
- Scenario: Load w/ Thermal Strains



Metrology

Unique challenges for processes, equipment & parts


- geometry depends on material, process, machine, orientation, supports, post-processing...
- equipment accuracy generally exceeds process

Challenges

- *metrology can be harder than fabrication*
- inferior surface quality
- form deviations included in uncertainty analyses
- GD&T applies, but less “traditional” surfaces
- internal features
- now worried about material, not just geometry




Ti-6Al-4V polyhedron & “Manhattan” artifacts





Ti “Manhattan” error map



17-4 PH “death” star



17-4 PH polyhedron texture anisotropy map



Corrosion

Exploring


- performance of PBF stainless steels relative to conventional materials
- linkages to processing-microstructure

Case study: commercial PBF 17-4 PH vs. conventional wrought


- inferior performance of AM material
- passivity compromised by porosity in material
- sets up favorable (crevice-like) conditions for pitting corrosion

Underway


- performance characterization of 304L and 316L
- impact of varied process conditions & surface finish on passivity



conventional wrought and AM 17-4PH coupons
after B117 salt fog corrosion test



polished AM 17-4PH surface
exhibiting corrosion product build-
up over pore after 7 day immersion
in 0.6 M NaCl



micro-electrochemical
measurements in 0.6 M NaCl
reveal AM 17-4 porosity
compromises stainless nature

Rosenthal Model

Predicts heat distribution from a moving heat source during welding


- Provides an estimated melt geometry

$$T_f - T_0 = \frac{q}{2\pi k R} e^{-\frac{v(w+R)}{2\alpha}}$$

- Modified (“Prediction of lack-of-fusion porosity for powder bed fusion” Tang et al)

$$W = 2 \sqrt{\frac{2q}{e\pi\rho C_p(T_f - T_0)v}}$$

- W – width of melt pool
- q – laser power * absorptivity of material
- v – laser velocity
- T_f – melting temperature




Line Scans

Substrates: bare plate, powder layer on 20 layer AM pad

- 60 lines on each substrate 1.0 cm long

Establish relevance of simple Rosenthal model


- capturing melt pool geometry via metallography
- useful to define nominal process boundaries







100 W, 250 to
2500 mm/s
on pad





melt pool on plate, 100W, 1500 mm/s



Line Scans: Plate vs. Powder Layer on Pad




Experimental Results – Line Scans on Plate




Experimental Results – Line Scans on Powder on AM Pad

1500 mm/s Velocity

125 W




175 W




125 W Power


500 mm/s




1000 mm/s




1500 mm/s



2000 mm/s



HTT Sample Density Map



I7-4PH Inter-Build Study

Exploring as alternate to 304L


- higher strength w/multiple strengthening mechanisms

Monolithic build w/110 dogbones



- custom design per ASTM
- external vendor w/constant process
 - Concept Laser M2
- SHT + H900 HT @ Sandia

High-throughput testing

- digital image correlation (DIC)
- custom dogbone per ASTM
- necessary to rapidly capture material distributions
- applicable for the lab & production



high throughput test sample w/120 dogbones,
1x1mm gage x-section



Material Characterization


NDE before testing

- *detect defects, performance correlations*
- density (Archimedes)
- resonant ultrasound spectroscopy (RUS)
- optical surface measurements
- computed tomography (CT)


Post mortem after testing

- *inform performance & failure mechanisms*
- fractography
- metallography
- composition
- XRD

Do reasonable defect signatures exist which tie to part performance?



17-4PH dogbone porosity



fracture surface

Implicit Part Correlations




Archimedes density

Surface finish


No significant trends observed



17-4PH dogbone surface roughness








Defect Characterization



- Total volume of defects (V_{tot})
- Pore volume fraction (V_{fract})
- Spatial location of pores (x, y, z)
- Total number of defects (N)
- Total defects/length (N/L)
- Average defect volume ($V_{avg.}$)*
- Average equivalent spherical diameter ($ESD_{avg.}$)*
- Average cross-sectional area ($CSA_{avg.}$)*
- Average nearest neighbor distance ($NND_{avg.}$)*

How do we *best* represent the defect populations present?

Simple Statistical Correlations Are Inadequate



Measure	R^2
No. of Defects	0.50
Avg. NN Distance (mm)	0.40
Avg. ESD (mm)	0.36
Max CSA Redux (mm^2)	0.38
Total Pore Volume (mm^3)	0.27
Avg. Defect Vol. (mm^3)	0.25
Max CSA Redux (%)	0.24
Maximum Pore Size	0.07
Seven factor multivariate regression	0.60



Global Void Projections vs. Performance

Reconstruct dogbones into printed array geometry

Top down void projection through each gauge section

- squares represents each dogbone in its printed location

17-4PH high
throughput
test sample





Global Void Projections vs. Performance

Reconstruct dogbones into printed array geometry

Top down void projection through each gauge section

- squares represents each dogbone in its printed location

17-4PH high
throughput
test sample






Fracture Location

Can forensic trends be identified?

CT data analysis

- calculate cross-section per layer
- gage sections are rough & porous
- fractures can correspond to minimum areas
- general trend remains weak




Fractography


Defect dominated failure observed

Increasing data fidelity & integration

- overlay fracture surface w/porosity map using DREAM.3D
- roughness inhibits registration accuracy
- fracture surface may correlate to large pore



B2, fracture surface optical image by structured light scanning




B2, fracture surface topography by structured light scanning

Microstructure Examination



Compositional analysis identified no anomalies

XRD revealed unexpected austenite variation in X-Y

- what about Z?
- further complication to dogbone performance
- source = powder, atmosphere?



XRD analysis of dogbones across the build sample



material performance variation w/ austenite phase fraction

Wrought 316L


1/16 Hard

- solution annealed @ 1080°C, water cooled & hot rolled plate


Specifications, minimums

- 1/16 hard: 310MPa yield, 585MPa UTS, 35% elongation
- 1/8 hard: 380MPa yield, 690MPa UTS, 25% elongation


Equiaxed grain structure



annealed 316L SS grain structure, Vander Voort, 2011



dogbone array end view, machined from wrought 316L SS



wrought 316L SS stress-strain response, 20 samples

As-Printed


Nominal parameters

- 103W, 1400mm/sec, 50 μ m cross feed, 100 μ m beam diameter


Rapid solidification produces higher yield strength

- consistent microstructure observed across process & feedstock changes
- laser-wise process structure clearly evident

Significant surface roughness




as-printed 316L SS grain structure, D. Susan



dogbone array end view, as-printed 316L SS



as-printed 316L SS, $S_a = 26.8\mu\text{m}$



as-printed 316L SS, 50 samples


Machined

Intent


- eliminate surface finish influence
- explore print orientation
 - vertical strength < horizontal, 45° orientations

Increases strength, reduces ductility




- see more “traditional” fracture surface



machined 316L SS, $S_a = 2.1\mu\text{m}$



machined 316L SS, fracture surface



build plate orientation, as printed in the ProX 200

Build Plate Coupons

Charpy



- density
- hardness @ 4 spots
- Charpy impact toughness

High-throughput tensile


- modulus
- strength – yield, ultimate
- ductility




build plate w/process artifacts



Temperature Maps Developed Per Layer




||



max temperature value @ each pixel across all frames

,



sum all temperature values @ each pixel across all frames