



This paper describes objective technical results and analysis. Any subjective views or opinions that might be expressed in the paper do not necessarily represent the views of the U.S. Department of Energy or the United States Government.

SAND2020-1123C

STT-MRAM For Radiation Hard Environments

Sanjeev Aggarwal

Sandia National Laboratories is a multimission laboratory managed and operated by National Technology & Engineering Solutions of Sandia, LLC, a wholly owned subsidiary of Honeywell International Inc., for the U.S. Department of Energy's National Nuclear Security Administration under contract DE-NA0003525.

Everspin: MRAM Technology Pioneer

Everspin is a Leading Provider of Non-volatile Memory Technology and Products to Mission-Critical **Data Center, Industrial** and **Auto/Transportation** Applications

- Origins in Motorola/Freescale
- Publicly traded : MRAM
- Independent since 2008
- Long-served tier-1 customers

600+

Customers across many markets

110M+


Units shipped

600+

Patents and applications WW

Our products bring the unique benefits of MRAM to our customers where Performance, Persistence, Endurance and Reliability are critical

MRAM Brings Native Persistence to Memory Workloads



**MRAM COMBINES
PERFORMANCE OF MEMORY
WITH PERSISTENCE
OF STORAGE**

- **Non-Volatile:** Maintains data without power or refresh
- **Fast:** Read/write similar to DRAM
- **Endurance:** Handles memory workloads


Data Center OEM Qualifies Everspin's 1Gb STT-MRAM Solution



[HOME](#) [SERVICES](#) [NEWS](#) [EDUCATION](#) [ABOUT US](#)

Everspin Achieves Data Center OEM qualification of its 1Gb STT-MRAM Solution

With this customer design win qualification, Everspin also announces production shipments of the 1Gb STT-MRAM



The Data Center OEM name is not being disclosed as they have not yet announced their end product(s).


Everspin's 1 Gb STT-MRAM Component (Photo: Business Wire)

December 11, 2019 08:00 AM Eastern Standard Time

<https://www.businesswire.com/news/home/20191211005184/en/Everspin-Achieves-Data-Center-OEM-qualification-1Gb>


STT-MRAM – Easy to Integrate with Standard CMOS

On Axis Integration, 1Gb





Spin-Transfer Torque (STT) Switching

- AP to P switching




- P to AP switching



Must separate bit-to-bit distributions in the array


Separation of distributions is key for working memory

MB memory $\Rightarrow >12\sigma$ separation



- Separation of V_C & V_{BD}
 - V_{write} must be well above V_C and well below V_{BD}
 - Tight switching distributions
 - Tunnel barrier reliability
- Separation of V_{read} & V_C
 - Avoid read-disturb errors
 - Bigger issue for smaller bits, lower I_C
- Separation gets worse with:
 - Shorter write pulses
 - Smaller bits
 - Extrinsic switching or breakdown behavior


1Gb STT-MRAM Endurance across Temperature




- TDDDB BER with ECC off vs. cycles shows linear breakdown distributions from -35°C to 85°C
 - Weibull plot at different temperature are horizontally offset for clarity
- No indication of a deviation due to early breakdown of extrinsic defect bit observed
- The TDDDB beta parameter is relatively similar across the temperature range

Extended Temperature Range: Data retention for 1Gb STT-MRAM

Example die



Projected Data Retention



- Baked typical die over 110 – 160 °C for 1 hr to 9 weeks
- Fitted to project data retention; Time-to-failure (TTF) is extracted from the fit

STT-MRAM Radiation Hard Testing

Everspin Technologies Contributors


Fred Mancoff
JiJun Sun
Sanjeev Aggarwal

Sandia National Laboratory Contributors


Marinella, Matthew
Manuel, Jack E
Bielejec, Edward S
Jacobs-Gedrim, Robin B
Xiao, Tianyao
Hughart, David
Arghavani, Reza
Bennett, Christopher
Buchheit, Thomas

Heavy Ion Exposure Map

- MTJs have metallic top/bottom electrodes, but no CMOS transistors
- 5 reticle shots at wafer center exposed to heavy ions
- Doses varied from 10^9 to 10^{13} ions/cm²
- Remaining reticle shots served as unexposed control MTJs




5 exposed
reticle shots




Rmin: Post vs. Pre-Exposure (Single MTJ Structures)

Short flow
1 point = 1 bit




- Exact same MTJs were measured after exposure (y-axis) vs. before exposure (x-axis)
- Increasing dose is plotted left to right starting at dose = 0 (unexposed reticle shots)
- Rmin remains unchanged by exposure up to 10^{13} ions/cm²
 - However, 10^{13} ions/cm² shows significant magnetic change to MTJ: See next slides

MR: Post vs. Pre-Exposure (Single MTJ Structures)




- MR is almost unchanged by exposure up to 10^{11} ions/cm²
- Mild MR decrease at 10^{12} ions/cm² indicates some effect
- Loss of MR at 10^{13} – 10^{14} ions/cm² indicates more significant damage

Hc: Post vs. Pre-Exposure (Single MTJ Structures)



- H_c is unchanged by exposure up to 10^{11} ions/cm²
- Mild H_c decrease at 10^{12} ions/cm² indicates some effect
- No data plotted at 10^{13} – 10^{14} ions/cm² because they have no MR so H_c cannot be defined
- H_c -correlation plots are noisier than for R_{min} and MR due to thermal-activated, random switching in MTJs: This is inherent to MTJs and seen also at dose = 0

Vc: Post vs. Pre-Exposure (Single MTJ Structures)



- V_c is unchanged by exposure up to 10^{11} ions/cm²
- 10^{12} ions/cm²: Slight increase in magnitude and spread of V_c
- No data plotted at $10^{13} - 10^{14}$ ions/cm² because they have no MR, so V_c cannot be defined

Summary

- Everspin has successfully transitioned STT-MRAM from R&D to volume manufacturing
 - 256Mb and 1Gb in production at Everspin
 - R&D roadmap to higher densities planned
- Examined magnetic field and spin torque voltage switching before/after heavy ion exposure
 - Negligible changes up to dose of 10^{12} ions/cm²
 - 10^{13} - 10^{14} ions/cm² significantly affect MTJ behavior
- No significant change after exposure up to dose of 10^{12} ions/cm² for:
 - Magnetic-field switching: R_{min} , MR, and H_c
 - Spin-torque voltage switching: V_c

Acknowledgements

- Colleagues at Everspin Technologies:
 - H. Almasi, M. DeHerrera, B. Hughes, S. Ikegawa, J. Janesky, H. K. Lee, H. Lu, F.B. Mancoff, K. Nagel, G. Shimon, J.J. Sun, T. Andre, S. M. Alam

Sandia National Laboratories is a multimission laboratory managed and operated by National Technology & Engineering Solutions of Sandia, LLC, a wholly owned subsidiary of Honeywell International Inc., for the U.S. Department of Energy's National Nuclear Security Administration under contract DE-NA0003525.

Thank you.

