

MBE-based growth of self-assembled III-V quantum dots


PRESENTED BY

Sadhvikas J. Addamane
John Reno



SAND#

This work was performed, in part, at the Center for Integrated Nanotechnologies, an Office of Science User Facility operated for the U.S. Department of Energy (DOE) Office of Science. Sandia National Laboratories is a multimission laboratory managed and operated by National Technology and Engineering Solutions of Sandia, LLC., a wholly owned subsidiary of Honeywell International Inc. for the U.S. DOE's Office of Biological and Environmental Research. Project number: SAND2020-1896PE.




Overview of capabilities





- III-V sources
 - Ga
 - In
 - Al
 - Valved As cracker
- High-mobility system
- Si for n-doping and C for p-doping

QDot growth summary




- Growth mechanism
- Control over areal density / size
- Emission wavelength
- Preliminary device results

S-K QDs : InAs / GaAs




1 X 1 μm AFM scan

InAs QDots
Height: 7-9 nm
Width : 40-50 nm




TEM image of InAs QD



Areal density and emission λ



$5 \times 10^{10} \text{ cm}^{-2}$





$1 \times 10^9 \text{ cm}^{-2}$




- Areal density controlled by growth conditions - coverage or growth T
- Size/shape will also tune emission wavelength.
- Grown with InGaAs QWs as a Dots-in-a-well structure - 1.3 μm and beyond.

S-K QDs: InAs / InP




1 X 1 μm AFM scan

QDashes
Height: 2 - 3 nm
Length: 50-200 nm
Width: 20 nm



Preliminary single-photon results



- At 4K, narrow QD PL observed at multiple wavelengths (930-1030nm)
- Low-density QDs preferred for single-photon measurements


Submonolayer InAs/GaAs (SML) QDs



Schematic showing difference between S-K and SML QDs




- Stacked alternating deposition of InAs (SML) and GaAs
- Compared to S-K QDs:
 - No wetting layer
 - Higher areal density
 - Adjustable height - tuning emission wavelength
 - Better confinement




Local droplet etching (LDE) QDs


- Recent evolution of droplet epitaxy technique - overcomes low T limitation
 - Defect and impurity-free nano-patterning
 - Properties:
 - High symmetry
 - Low areal density
 - Surface mounds
 - Choice for QD material
- } Ideal for single-photon emitters



LDE QDs – AFM



2 X 2 μm AFM scans




Line profile from AFM

- Nanovoid formation by Ga-droplet etching on AlGaAs surface
- Low areal density $\sim 1 \times 10^8 / \text{cm}^2$

Void dimensions:

- Depth: $\sim 30 \text{ nm}$
- Width: $\sim 150\text{-}200 \text{ nm}$

LDE QDs –AFM




- Nanovoid in-filled with GaAs QDot - nanovoid depth decreases ~10nm
- Capped samples grown for PL



Backup slides



QDs shape/size control



- Metamorphic buffer used to step up lattice constant of substrate
- Step-graded AlGaAsSb buffer with increasing Sb%

