

At-Speed Defect Localization by Combining Laser Scanning Microscopy and Power Spectrum Analysis

Mary A. Miller, Edward I. Cole, Jr., Garth M. Kraus
and Perry J. Robertson

Sandia National Laboratories
Albuquerque, NM USA

Sandia National Laboratories is a multimission laboratory managed and operated by National Technology & Engineering Solutions of Sandia, LLC, a wholly owned subsidiary of Honeywell International Inc., for the U.S. Department of Energy's National Nuclear Security Administration under contract DE-NA0003525.

This presentation describes objective technical results and analysis. Any subjective views or opinions that might be expressed in the paper do not necessarily represent the views of the U.S. Department of Energy or the United States Government.

Purpose

- **Describe a new method for localizing at-speed defects**
- **Combine local thermal stimulation and Power Spectrum Analysis (PSA)**
 - **Leverages PSA sensitivity and frequency selection**
- **Big data, high-speed problem into a DC signature**

Outline


- **Motivation for development**
- **Failure description and experimental approach**
- **Imaging results**
- **Conclusions**

Need for a New Method

- **At-speed defect localization is difficult**
 - Simultaneous GHz operation and detection
- **SDL (Soft Defect Localization) and LADA (Laser-Assisted Defect Analysis) effective**
 - Pass/fail detection can be difficult at speed
- **General detection method has inherent advantages**
- **Need for detection scheme encountered on a particular functional failure**
 - Heat sensitive, intermittent failure
 - Real-time pass/fail detection difficult
 - PSA an attractive alternative to existing FA methods

PSA (Power Spectrum Analysis)

- **Displays device frequency components under dynamic stimulus**
 - Can be a very complex tapestry
- **Leverages advancements in spectrum analyzers**
- **Extremely sensitive to changes in target sample properties**
 - Highlighted by normalization
- **Multiple applications**
 - Counterfeit detection, attribution, aging, defect detection, etc.¹



Example PSA spectrum


1. P. Tangyonyong, E.I. Cole, Jr., G.M. Loubriel, J. Beutler, D.M. Udoni, B.S. Paskaleva, and T.E. Buchheit, "Power Spectrum Analysis (PSA)," in *Proc. From the 43rd International Symposium for Testing and Failure Analysis*, 2017, pp. 73-78.

PSA and Local Laser Stimulus

- Failure condition has a unique PSA signature
 - Normalization emphasized difference spikes with heating
- Individual frequency(ies) isolated and “zero-spanned”
 - Zero-spanning: power only at a given frequency
- Zero-span power used to modulate image contrast
- PSA power amplitude map formed with local laser scanning
 - Similar to SDL/LADA/LIVA, etc.
 - At-speed digital pass/fail detection NOT required

Normalized PSA Spectrum

- Normalized data highlights differences in conditions
- Zero-spanning of power at a given frequency only




Failure Description and FA Approach

- **Si PLL (phase-locked loop) missed counts at elevated temp**
 - Well within operating specs
 - Multiple devices displayed failure
- **No LIVA/TIVA faults detected, although multiple signals appeared in maps**
- **SDL considered**
 - Pass/fail instrumentation difficulties
- **PSA spectra collected during PLL counting**
 - Observed different signatures under passing and failing conditions
 - Zero-spanned on a pass/fail frequency
 - Analog output of spectrum analyzer utilized

Failure Description and FA Approach


- Device powered and heated to just below failure (44.8°C)
- Zero-spanning on a specific frequency generates F_i power amplitude maps
 - Acquired in 1-2 minutes with averaging
 - Laser stimulus at wavelengths above and below Si indirect bandgap




Experimental Results

F_0 Amplitude Map:
Image contrast generated at frequency F_0

- Identified by PSA with global heating
- 1340 nm used for local heating
- **Dark contrast indicated increased failure**
 - Lower F_0 peak power




1340 nm
Reflected Light Image




F_0 Amplitude Map

Pre-Scaler Area

- **Imbalance between sides not expected**
 - Should be matched pairs
 - Not clear if symptom or cause
- **Regulator signals not of interest**
 - Expected variations with exposure







1340 nm
Reflected Light Image



F_0 Amplitude Map

F_0 Amplitude Image at 532 nm

- Only regulators seen
- Higher mag of analog regulator shows varactor
 - Photocurrents dominate
 - Weak signal from heating?
 - Consistent asymmetry
 - Not failure cause



Reflected Light Images


F_0 Amplitude Maps

Moving to a Different PSA Frequency


- Initial F_0 selected from global heating
- Refined frequencies determined by local heating
 - Laser spotted in F_0 amplitude maps
 - New spectra collected and new zero-spanned frequencies identified
 - Zero-spanned images collected at the identified frequency, F_1
- Goal to identify/differentiate global and local heating effects

F_1 Amplitude Map Identified Divide-by-2 Counter

- Potential failure source
 - Not seen in F_0 amplitude maps







1340 nm Reflected Image



F_1 Amplitude Map

F_1 Amplitude Images at 532 nm: Analog Amp and Divide-by-2 Circuitry

- New areas not seen in F_0 maps
- Better spatial resolution in divide-by-2 area
 - Shorter λ



Reflected Images


F_1 Amplitude Maps

Selecting Another Zero-Span Frequency


- **Methodology to select F_1 from F_0 images used to select a new F_2**
 - Generated from F_1 images
- **F_2 zero-span images further indicated the divide-by-2 counter circuitry**
 - Additional F_2 frequencies also highlighted the divide-by-2 counter

F_2 532 nm Amplitude Map of Divide-by-2 Circuitry

- Arrow indicates most thermally sensitive area



Reflected Light Image



F_2 Amplitude Map

Divide-by-2 Circuitry Identified as Failure Site

- Multiple frequency iterative process showed same site
- Failure site validated with circuit simulation
- Imbalance seen earlier was NOT the cause of failure
 - Result of imbalanced output loading
- Divide-by-2 localization satisfied customer needs

Conclusions

- **New methodology described to localize at-speed failures**
- **Approach based on combining two techniques:**
 - 1) **PSA for frequency detection sensitivity**
 - 2) **Local laser stimulus**
- **Selection of zero-span frequency initially from global effects**
- **Subsequent chosen frequencies from localized effects**
 - Iteratively selecting new frequencies facilitated localization
- **Combined approach filters a big data problem into a single frequency**
 - High speed failure into a DC signature