



**ASME 2020 ES**  
14th International Conference on  
Energy Sustainability

This paper describes objective technical results and analysis. Any subjective views or opinions that might be expressed in the paper do not necessarily represent the views of the U.S. Department of Energy or the United States Government.

**VIRTUAL CONFERENCE**  
**JUNE 17 – 18, 2020**  
SAND2020-5541C

# High-Temperature Particle Flow Testing In Parallel Plates for Particle-to-Supercritical CO<sub>2</sub> Heat Exchanger Applications

Concentrating Solar Technologies, Sandia National Laboratories

**Presenter: Henk Laubscher**  
**Co-authors: Kevin Albrecht, Clifford Ho**



Sandia National Laboratories is a multimission laboratory managed and operated by National Technology & Engineering Solutions of Sandia, LLC, a wholly owned subsidiary of Honeywell International Inc., for the U.S. Department of Energy's National Nuclear Security Administration under contract DE-NA0003525.



## Overview

- Introduction
- Motivation
- Objectives
- Experimental Design
- Experimental Testing
- Results
- Conclusion








## Introduction


- Moving packed bed heat exchanger
- Ceramic based particles
- sCO<sub>2</sub> power cycle integration
- Parallel plate test block
- Flow visualization, quartz window
- High temperature testing, 650 °C
- 4 different channel spacings






## Motivation: Heat exchanger layout and geometry

Moving packed bed heat exchanger; integration with sCO<sub>2</sub> layout





## Motivation: Heat transfer coefficient correlation








## Objectives

- Measure flow distribution across channels (flow variation)
- Finding optimal channel width
- Identify particle bridging conditions
- Temperature dependence of flow in narrow channels
- Identify boundary effects



## Experimental Design

- Standard sheet metal sizes
- Interchangeable spacers
- Variable mass flow
- Modify existing test infrastructure
- High temperature filler mechanism




Standard sizes	Decimal [inch]	Decimal [mm]
1/4"	0.25	6.35
3/16"	0.1875	4.76
12 GA	0.105	2.66
1/16"	0.0625	1.58



## Experimental Testing

- Experiments done at 650 °C and 25 °C for comparison
- Heat up the test block (15 h)
- Fill test block at high temperature
- Record video of flow test
- Measure mass flow
- Calculate flow variation

- $$\text{Flow variation (\%)} = \frac{V_{\max} - V_{\min}}{V_{\max}} \times 100$$









## Experimental Testing : filler mechanism

- Filler mechanism used to fill test block at high temperature
- Shown in the open and closed positions






## Experimental Testing : hot flow testing


- 650 °C
- 6.35 mm spacing




TIME: 0 SEC




TIME: 9 SEC



TIME: 18 SEC



TIME: 27 SEC



TIME: 37 SEC

- 650 °C
- 4.76 mm spacing




TIME: 0 SEC




TIME: 12 SEC



TIME: 19 SEC



TIME: 26 SEC



TIME: 33 SEC






## Experimental Testing : hot flow testing

- 650 °C
- 2.66 mm spacing



TIME: 0 SEC



TIME: 5 SEC



TIME: 10 SEC



TIME: 15 SEC



TIME: 20 SEC

- 650 °C
- 1.58 mm spacing



TIME: 0 SEC



TIME: 3 SEC



TIME: 6 SEC



TIME: 9 SEC



TIME: 12 SEC





## Results: flow variation

### Flow distribution results for 25 °C testing

Channel Spacing	Mass Flow Variability [%]	Mass Flow [kg/s]	Flow velocity [mm/s]
1/4"	5.69	0.146	6.14
3/16"	8.95	0.147	6.77
12 GA	16.4	0.148	10.8
1/16"	18.53	0.150	18.57


### Flow distribution results for 650 °C testing

Channel Spacing	Mass Flow Variability [%]	Mass Flow [kg/s]	Flow velocity [mm/s]
1/4"	7.75	0.146	5.3
3/16"	11.94	0.147	6.2
12 GA	15.32	0.146	9
1/16"	20.08	0.149	13.2




## Results: flow variation

- Flow variation comparison
- Case 1 to 4; 6.35 mm to 1.58 mm
- Slower flow at high temperature
- High temperature cause more flow resistance




Mass flow variation




Flow velocity variation



## Results: bridging



Photograph of particle bridge: 1.58 mm channel



Voids and bridges forming on quartz window surface





## Conclusion

- Lessons learnt; high temperature filler mechanism needed
- Temperature dependence of flow distribution
- 15% flow variation at chosen channel size of 2.66 mm
- 12 GA = 0.105 inch (2.66 mm) was the best channel size
- Particle bridging is not an issue if channel is more than 5 times a particle diameter.
- Boundary effects of the experimental setup were identified and disregarded in the calculation



## Acknowledgements

Sandia National Laboratories is a multimission laboratory managed and operated by National Technology & Engineering Solutions of Sandia, LLC, a wholly owned subsidiary of Honeywell International Inc., for the U.S. Department of Energy's National Nuclear Security Administration under contract DE-NA0003525.

This work was funded in part or whole by the U.S. Department of Energy, Solar Energy Technologies Office under Award Number 34211. SAND2020-5541C



Sandia National Laboratories is a multimission laboratory managed and operated by National Technology & Engineering Solutions of Sandia, LLC, a wholly owned subsidiary of Honeywell International Inc., for the U.S. Department of Energy's National Nuclear Security Administration under contract DE-NA0003525.