

# Properties of Cold Sprayed and Controlled Atmosphere Plasma Sprayed High Entropy Alloy (CoCrFeMnNi) Coatings






PRESENTED BY

Jacob Mahaffey

Andrew Vackel, Andrew Kustas


1. Overview of Thermal Spray processing
2. Background of High Entropy Alloys
3. Initial processing results – Air plasma spray
4. Characterization of Controlled Atmosphere Plasma Spray (CAPS) and Cold Spray coatings
5. Conclusions



# Thermal Spray Processing Conditions for High Entropy Alloy Film Deposition




Impact 5/11  
Cold Spray  
System at  
Sandia



SG100 Torch  
used for  
CAPS at  
Sandia

Cold Spray and plasma spray deposition rely on fundamentally different mechanisms to form coatings which cover a wide area of process conditions (Temperature and Velocity)



- Thermal Spray technologies encompass a wide range of particle processing temperatures and velocities
- Two of the largest differences are between plasma spray and cold spray
- Plasma spray relies on melting of particles and droplet quenching
- Cold Spray relies on high velocity – low temperature impacts to induce plastic deformation


\*Adapted from plots by R.C. McCune, Ford Motor Co. & A. Papyrin, Ktech Corp.




# Background of High Entropy Alloys



Atomic representations of (a) conventional alloy and (b) HEA/RHEA



Miracle, et al. Acta, 2017




- High Entropy Alloys (HEAs) are loosely defined as alloys containing five or more constituents at roughly 5-35 at. % each
  - Alloys with four or more constituents interchangeably called HEAs or complex concentrated alloys (CCAs)
- The chemistry results in high configurational entropy which is theorized to stabilize single-phase solid solutions
  - HEAs can be multiphase
- CCAs/HEAs have properties exceeding most conventional alloys, plus resistance to phase precipitation

# As-Received Powder Properties (Cantor Alloy – CoCrFeMnNi)




- Powder was high pressure gas atomized (hpga), AMES Laboratory: 45um powder
- Despite promising properties, there are challenges with conventional processing methods (i.e., casting): defects and insufficient mixing of constituents.
- Example below: CoCrFeMnNi HEA – microsegregation of Mn and Cr, microshrinkage porosity.


Channeling Contrast SEM of HEA Powder



Micro-shrinkage porosity:



Micro-segregation of Mn:



\*Kustas, Andrew, et al. "Advanced Manufacturing of High Entropy Alloys." TMS, 2019.

Composition (wt%)	Al	C	Co	Cr	Fe	Mn	Ni	N	O	S
HEA Powder	0.003 ± 0.00045	0.005 ± 0.00075	20.91 ± 0.42	18.46 ± 0.37	20.14 ± 0.40	19.06 ± 0.38	21.34 ± 0.43	0.002 ± 0.00026	0.064 ± 0.0096	0.008 ± 0.0012



# RESULTS









# 7 Air Plasma Sprayed High Entropy Alloy



Samples sprayed using Triplex APS system using Argon processing gas

- Inhomogeneous distribution of alloying constituents with depleted and enriched regions throughout coating thickness
- Significant oxygen content interwoven within coating (processed in air)
- Chromium rich oxides present throughout the film
- Porosity =  $6.0 \pm 0.6\%$



Can We Produce Coatings With Same Composition As Starting Powder?


# SEM/Image Analysis of Controlled Atmosphere Plasma Spray and Cold Spray HEA




- Significant microstructural differences observed in the CAPS vs Cold Spray films
- Image analysis using Python was used to determine area fraction of porosity
  - Averages and St. Dev determined using three images at two magnifications
  - Porosity is significantly reduced when using Cold Spray processing

Backscatter SEM Imaging:

Controlled Atmosphere Plasma Spray coatings contained several un-melt particles



Density =  $89.3 \pm 1.2\%$



Density =  $97.2 \pm 0.4\%$



# Phase and Composition Analysis of Sprayed High Entropy Alloy




- No evidence of change in concentration of oxygen, nitrogen, or hydrogen from spray processing
- XRD shows phase retention of as-received powder for CAPS and Cold Spray coatings

- APS films show oxide peaks: EDS of Mn and Fe

Composition determined by  
IGF – LECO ONG836


	Oxygen [wt%]	Nitrogen [wt%]	Hydrogen [ppm]
	Average	Average	Average
<b>Powder</b>	0.14±0.01	Not Quantifiable	16±1.1
<b>Cold Spray</b>	0.17±0.03	0.008±0.003	20±8.7
<b>CAPS</b>	0.16±0.03	0.003±0.003	17±4.7

XRD Spectral Results for Thermal Sprayed HEAs



Phase analysis conducted on a  
Bruker D2-Phaser using a Cu K $\alpha$  source

# Manganese Evaporation in Plasma Spray Processing of High Entropy Alloy






- Electron Probe Micro-Analyzer (EPMA) used to measure Mn composition
- Observable Mn depletion along splat boundaries
- Boiling Point of Mn is in range of expected in-flight particle temperatures (especially boundary layer)
- Large vapor pressure compared to other constituents indicates faster evaporation rate
- Manganese vapor pressure at 1280-1349°C is  $\sim 10^{-3} - 10^{-4}$  \*

\*Mackowiak, J., Physical chemistry for metallurgists, Allen & Unwin, 1965, p. 214

# Manganese Evaporation in Plasma Spray Processing of High Entropy Alloy – EPMA Line Scans



- Manganese depletion observed along boundaries in Plasma Sprayed samples (Right)
  - Due to differences in vapor pressure of the individual constituents
- Low temperature of kinetic processing prevents manganese evaporation
- Cold Spray Mn composition is 19.86% compared to the average CAPS composition of 17.74%
- Powder Mn composition is 19.06%
- Dips in CAPS Mn reach 10%, indicating significant localized depletion of Mn
- Manganese depletion could result in differences in inter-splat bonding, corrosion, and mechanical properties
  - Changes in diffusion
  - Increase in pure chromium oxides
  - Reduced twinning








- Mechanical properties were measured using micro-tensile bars of coating which was electrical discharge machined to size
- CAPS HEA coatings were sprayed on aluminum (Al) and 316 steel substrates (SS)
  - Coatings on aluminum delaminated, but were thick enough to cut tensile bars
- Cold Spray coatings on aluminum substrates
- Large deviation in measured mechanical properties indicates no statistical evidence of differences between the processes
- Vickers hardness data shows significant work hardening of the Cold Spray

## Vickers Hardness

Data:	Powder (10 values)	CAPS (25 values)	CS (25 values)
Average	163	196	351
St Dev	19	18	32



## Tensile Bar Summary:

	Cold Spray	CAPS - SS	CAPS - Al
UTS [Mpa]	245 ± 78	297 ± 58	293 ± 43
Ductility [%]	0.13 ± .06	0.23 ± 0.06	0.16 ± 0.03
Modulus [Gpa]	180 ± 58	116 ± 15	160 ± 20

# Summary of Thermal Spray Processing of Cantor HEA



- Severe oxidation was present in the APS coating, with no oxidation observed for CAPS and Cold Spray coatings
- The density of Cold Spray was considerably higher than CAPS (~8%)
- No compositional or phase changes occurred in Cold Spray coatings
- Reduction of Mn composition in CAPS coatings which was attributed to evaporation due to the low vapor pressure of Mn compared to the other constituents
- Plastic deformation during Cold Spray processing resulted in significant cold working which increased hardness by ~200%, while only a slightly higher hardness was observed for the CAPS coating relative to the feedstock powder
- Coatings from both CAPS and Cold Spray exhibit very low ductility before brittle fracture during tensile testing, with lower UTS and YS compared to bulk values

