



Exceptional service in the national interest

# Studies of Alternative Ventilation Configurations to Mitigate Airborne Exposure Risks in Office Spaces

Casiano Armenta PE, CEM, GBE

Nicole Naber EIT

I2SL Annual Conference and Technology Fair  
Pittsburgh, PA

October 18, 2022 Session G1 3:30-4:00 PM



Sandia National Laboratories is a multission laboratory managed and operated by National Technology and Engineering Solutions of Sandia LLC, a wholly owned subsidiary of Honeywell International Inc. for the U.S. Department of Energy's National Nuclear Security Administration under contract DE-NA0003525.

Sandia National Laboratories is a multission laboratory managed and operated by National Technology and Engineering Solutions of Sandia LLC, a wholly owned subsidiary of Honeywell International Inc., for the U.S. Department of Energy's National Nuclear Security Administration under contract DE-NA0003525.



# Learning Objectives



- Reducing airborne exposure for office occupants should not only be viewed for the COVID-19 Pandemic, but also for common cold & flu season to create a safer and healthier office space year-round.
- Modification of size and location of return air grilles & changing directional flow of supply diffusers can be simple & offer a low-cost solution to reduce airborne exposure for occupants, given most general office areas have Heating, Ventilation, and Air Conditioning (HVAC) design of ducted supply & plenum return.
- Implementation of Computational Fluid Dynamics (CFD) can be used from a safety point of view for not only laboratory spaces but also common office areas & conference rooms.
- Validating the CFD model can be achieved with simple visual tools & purchase of expensive anemometers may not be required.



# Agenda

- Learning Objectives
- Model
- Test
- Results
- Discussion



# Model

Conference Room #1




# Approach

- Simulate steady state conditions using realistic boundary conditions
- Simulate expelled aerosol plume dispersion using water vapor
- Different configurations and scenarios were used to compare exposure risks
  - Social Distancing
  - Plexiglass Barriers
  - Redirect supply Airflow
  - Relocate/Centralize Return




Conference Room #1


# Model Configurations




**7 Occupants, Baseline**



7 Occupants, Plexiglass Barriers




Full Occupancy



**7 Occupants, Modified Central Return**




# 7 Occupants, Baseline



Simulated steady state temperatures and velocity in 2-D




# Pathogen Simulation



Simulated pathogen distribution after several minutes with original ventilation configuration during steady-state airflow and temperature


# Modified Central Return



Simulated steady state temperatures and velocity in 2-D



# Results





# Test

Conference Room #2

# Approach

- Analyze conference room HVAC configuration
- Determine test methods
- Select instrumentation and tools
- Generate test plan
- Prepare for test day



Conference Room #2




Diffuser Modifications




Test Setup

# Test Configurations



Original Configuration




Modified Configuration



# Anemometer Testing


- Anemometers placed to gather velocity data for comparison with model (9 Locations)
- Documented airflow readings at each diffuser
- Crucial tool for model validation



Anemometer Placement



Airflow Measurements



Anemometers in Action

# “Calibrated” Tissue Test

- Easy visual aid
- Verification of air movement
- Direction of airflow “Flag in the Wind”



Tissue Test, Redirected Supply



Tissue Test, Modified Return

# Smoke Emitter Test

- Smoke Emitters
  - 90 second
  - 4 minute
- Visualize direction of airflow throughout the room



Smoke Emitter in Action



Smoke Emitter Placement



# Fog Purge Test

- Puffs of smoke
  - Observed airflow currents
  - Obvious draw to the return air vents
  - Visualized room conditions
- Fog out conditions
  - Filled room with smoke
  - Fog dissipation over 12 minutes
  - Noticeable changes between configurations
  - Observations were complete with 6+ people
- Best visualization tool



Fog Machine in Action



# Results



Empirical vs. Model Data

# Model Validation

- Empirical data were placed in CFD Model
  - Airflow and velocities at supply and return
- Simulated measurements at locations similar to anemometer test (9 Locations)
  - Velocities were within 6% of actual original and 0.2% for modified
- Compared air speeds provided confidence in model and simulation methods



# Fog Purge Timelapse

0 min

4 – 5 min

11 – 12 min

Original  
Configuration



Modified  
Configuration





Time lapse photos during fog purge testing using smoke machine



# Fog Purge Simulation



Original

3.00min




Modified

3.00min



CFD Simulations of Fog Purge



Reported time to  
“clear out” fog-filled  
room with modified  
vents ~12.5 minutes

Reported time to “clear  
out” fog-filled room  
with original vents ~13-  
14 minutes


Fog purge simulation uses water vapor as the fog medium

# Discussion

Observations and Lessons Learned

# Observations

- Small modifications improve ventilation effectiveness
  - Can be applied to future space designs
  - Sweeping airflow may improve air exchange
  - Effective to minimize risks of transmission
- CFD Simulation
  - Characterized the general airflow patterns and exposure risks
  - Compare against tests from measured air velocities and air-change effectiveness




Simulated steady-state flow field in room Conference Room #1



# Lessons Learned

- Do not assume drawings match in-field installation
  - Place cameras/people strategically for testing
    - Beneficial to discern airflow in the space
- Validate supply & return airflow rates
  - Field airflow measurements were contrary to building design criteria
  - Test & balance is an important validation tool



## Studies of Alternative Ventilation Configurations to Mitigate Airborne Exposure Risks in Office Spaces

*By: Casiano Armenta, Roberto Armijo, John Garcia, Clifford Ho, Nicole Naber*

Technical Report: <https://www.osti.gov/biblio/1827490>

# Questions?

Casiano Armenta: [ccarmen@sandia.gov](mailto:ccarmen@sandia.gov)

Nicole Naber: [nnaber@sandia.gov](mailto:nnaber@sandia.gov)