

Towards the Measurement of Ablation Products in Hypersonic Boundary Layers

Current & Upcoming Ground Testing Efforts in Sandia's Diagnostic Sciences Department

Joshua Hargis, Kyle Daniel, Kyle Lynch, Sean Kearney, Justin Wagner

Diagnostic Sciences Department, Sandia National Laboratories, Albuquerque, NM


12th Ablation Workshop

Lexington, Kentucky

November 9-10, 2022



Motivation: Ablation & Gas-Surface Interactions



Hypersonic flow, high gas temperature, and elevated surface temperatures are critical to enacting the proper physical/chemical mechanisms

Shock Layer (Gas Chemistry)


- Species dependent thermodynamic nonequilibrium
 - Vibrational temp \neq rotational temp ($T_v \neq T_R$)
- Dissociation produces atomic N and O and formation of nitric oxide (NO)

Surface Chemistry

- N and O interact (adsorb) with surface.
- Oxidation and nitridation
- CN, CO, CO_2 production.

Boundary Layer


- Diffusion of oxidation products
- Air chemistry
- Vibrationally excited species (N_2 , O_2)



How can we replicate these physics in a ground test facility?


Air-Carbon Ablation Model Considerations

- Various literature models available
 - Park, et al. (1976)
 - MURI (2015)
 - Prata (2022)
- Differences in model formulation
 - Number of reactions
 - Active surface site treatment
 - Model formulation data
- Model Comparisons (US3D)
 - Which is correct?
- Need speciation data for validation



Thanks to Erin Mussoni (SNL) for performing these simulations

Established Methods for TPS Characterization




Summary

- Each method produces the realistic heating over run times of several minutes.
- These facilities cannot reproduce flight velocity, aerodynamic heating and the correct air chemistry concurrently.

We desire to conduct experiments and observe ablation products in a coupled aero-thermal environment

A Compliment to Traditional Material Characterization Facilities: Sandia Hypersonic Shock Tunnel (HST)



Tunnel Specifications


- Nozzle Exit Dia. = 0.36 m
- Test section diameter 0.5 m
- Run times of 1-2 milliseconds

| U_{∞} (m/s) | H_0 (MJ/kg) | T_0 (K) | P_0 (MPa) |
|--------------------|---------------|-----------|-------------|
| 2850 | 4.6 | 3400 | 12 |
| 4060 | 9 | 6000 | 17 |

Target applications include high-temperature surface chemistry and hypersonic thermochemistry.



Survey of Upcoming Experiments in HST

- HST introduces flow complexities
 - Stagnation region gases react
 - Gas rapidly expanded through nozzle
 - Result: thermal non-eq., N-O added
- Free-stream characterization necessary
 - Temperature: CARS for heteronuclear molecules
 - Velocity: NO LIF
- Examine boundary layer products
 - Speciation/temperature of CO
 - Laser absorption
 - CARS (Coherent Anti-Raman Stokes)






Free-Stream Characterization: Temperature

- Free-stream conditions
 - Major source of uncertainty in shock tunnels
 - Temperature non-eq. in nozzle is expected
- Simulation of nozzle temperatures
 - Significant T_v differences between species
 - N_2 has highest degree of non-eq
- Characterizing temperature non-eq. in HST
 - Use CARS to measure T_{vib} , T_{rot} for N_2
 - Further improvement needed for T_{rot}
 - Next: O_2 CARS temp. measurements




Free-Stream Characterization: Velocity

- NO is present in shock tunnel flow ($X_{NO} \sim 4-5\%$)
- Tracer for flow visualization
- Nitric Oxide Tagging Velocimetry
- Long fluorescence lifetime, >100 ns
 - $U_\infty = 3 \text{ km/s} = 3 \mu\text{m/ns}$, $\Delta t \sim 100 \text{ ns} \rightarrow \Delta x \sim 300 \mu\text{m}$
 - Track NO fluorescence at high image magnification



Impulse Facility Material Testing Considerations

- Generate free-stream condition in HST
- How to achieve realistic T_w ?



- Impulse facilities
 - Short test time
 - Unable to achieve realistic T_w
 - Must preheat model

- Resistively heat models
 - Joule heating: $T \propto I_{\text{supply}}^2 R_{\text{Mat'l}}$
 - *Hot Wall Re-entry Testing in Hypersonic Facilities*, Zander et al. 2013 (others)
- Graphite Coupons
 - Good surrogate for wall mat'l.
 - Easily scalable





Tunnel Experiments: Mounting and Pyrometer

- Model Mounting Within HST

- High-temperature 3D printed plastic
 - Electrical isolation of electrodes



- Mirror mounted within test section to provide better viewing angle of model front surface





- Pyrometer (Prior to Experiment)

Lower Temp \sim 800-1000 K, no filters




Higher temp w/filters: \sim 2550 C \approx 2825 K




Extension to Larger Test Model Geometry

- Original TPS Geometry Was Proof-of-Concept
 - Subject to 3D flow effects
 - Insufficient probe volume for diagnostics
- Modify TPS Geometry to Simulate 2D Flow
 - Utilize same cylindrical cross-section
 - Elongate span from 10 mm to 100 mm
- Measure boundary layer products (CO, etc)
 - Laser absorption spectroscopy
 - CARS (for temperature, concentrations)





Complimentary Measurements in UT ICP

- Collaboration with UT
 - Used CARS to measure
 - N_2 temperatures
 - CO/N_2 mass ratios
 - Utility
 - High resolution
 - Near-surface detection
 - Challenges:
 - High luminosity/temp



- Next: Measurements in SNL HST
 - Pulseburst CARS in TPS boundary layer
- Compare HST/ICP CARS data w/models





Conclusions

- Ablation modeling
 - Predictions vary between models
 - Validation needed
 - Sparse literature data
- Utilize HST in TPS characterization
 - Replicate hypersonic flow
 - Thermo-chemical
 - Velocity
- Free-stream characterization needed
 - N_2 CARS, $T_{\text{rot, vib}}$
 - NO PLIF, U_∞
- Impulse facility test times
 - Model preheating required
 - Use pyrometer to measure T_w
- Stay Tuned: Boundary Layer Data
 - Laser Absorption measurements (CO)
 - CARS measurements of temp., relative concentrations
 - More UT Plasma torch measurements

Questions?

Surface Temperature Characterization: Pyrometry

- How to Measure T_w ? : Thermal Radiation
 - Some real surfaces (like graphite) are similar to a blackbody
 - Ratio of signal from discrete wavelengths: $\frac{s_{\lambda_1}}{s_{\lambda_2}} = f(T_{object})$
 - Unique to a particular BB temperature
 - Also true if emitter is a gray body (constant emissivity)
 - Measuring 2 discrete wavelengths is challenging
 - Measure wavelength bands instead (more signal, better for cameras)
 - Use color camera (Phantom V1212)
 - Increase temp. sensitivity with tri-color filter



Pyrometry Calibration


- Calibration Source:

- Use blackbody source for calibration
- Temperature range 1200 C – 2700 C
 - Same as that of model T_w

- Ratio Calibration:


- Data (*) of R/G and R/B ratios compare well to theoretical values (line) for calibration range
 - 1250 C – 2000 C shown at right
- Additional calibration data up to 2700 C recorded

$$I_{ratio} = \frac{\int_0^{\infty} E(\lambda, T_{obj}) \tau_{filt} \tau_{lenses} S_{\lambda_1, cam} d\lambda}{\int_0^{\infty} E(\lambda, T_{obj}) \tau_{filt} \tau_{lenses} S_{\lambda_2, cam} d\lambda}$$



Benchtop Testing & Pyrometer Validation


- Testing and Validation:



Benchtop heating using
Color Pyrometer:





$$t_{0,video} = t_{0,current}$$



- Video: pyrometer cannot capture entire heat-up duration
 - Not enough visible signal at lower temps and near-saturation at higher temps
 - Pixels with intensity < 5% of saturation or >86% of saturation are removed from analysis
- Average 100 pixels at center of color pyrometer frame vs time
 - T_{rg} : temp from the R/G ratio T_{rb} : temp from the R/B ratio
 - 2D pyrometer compared to IR point pyrometer




Handheld pyrometer focuses on a point
at center of strip



Tunnel Experiments: High Speed Video & Schlieren


- High Speed Video (Run HST-277)

- Model has no preheating for better viewing of shock layer








- Schlieren (Run HST-272)

- Prior to backlighting, model is visible in the frame due to high temperature
- Shock standoff ~2.8mm (with / without heating



Free-Stream Characterization: N₂ CARS Temperature



Free-Stream Boundary Conditions : A Major Source of Uncertainty in Shock-Tunnel Measurements



- Next Steps
 - Improve sensitivity to T_{rot}
 - Repeat N₂ measurements
 - Measure O₂ temperatures

Free-Stream Characterization: Velocity

- NO is present in shock tunnel flow ($X_{NO} \sim 4-5\%$)
- Tracer for flow visualization
- Nitric Oxide Tagging Velocimetry
- Long fluorescence lifetime, >100 ns
 - $U_\infty = 3 \text{ km/s} = 3 \mu\text{m/ns}$, $\Delta t \sim 100 \text{ ns} \rightarrow \Delta x \sim 300 \mu\text{m}$
 - Track NO fluorescence at high image magnification



Phantom 7510 with IRO

