


Optical Fiber Sensors Capable of Monitoring Hydrogen in the Subsurface Hydrogen Storage Environment



Daejin Kim
NETL Support Contractor

SPIE Defense + Commercial Sensing
April 23, 2024



Disclaimer




This project was funded by the United States Department of Energy, National Energy Technology Laboratory, in part, through a site support contract. Neither the United States Government nor any agency thereof, nor any of their employees, nor the support contractor, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.

Daejin Kim^{1,2,*}; Alexander Shumski^{1,2}; Kara Tinker^{1,2}; Djuna Gulliver¹; Ruishu Wright¹

¹National Energy Technology Laboratory, 626 Cochran Mill Road, Pittsburgh, PA 15236, USA

²NETL Support Contractor, 626 Cochran Mill Road, Pittsburgh, PA 15236, USA

Subsurface Hydrogen Storage



Monitoring H₂ concentration to ensure the integrity and safety of underground H₂ storages.

High
pressure
(~100 bar)

High humidity
(~100% RH)

High
temperature
(~40-80 °C)

Microbiology


Optical Fiber Hydrogen Sensors

➤ Advantages:


- Immune to electro-magnetic interference
- Resistant to high temperatures and pressures
- Chemically inert
- Small and light weight
- Suitable for remote and in-situ sensing

➤ Disadvantages:

- Susceptible to physical damage
- Interference with humidity
- Unproven under microbial environments




Optical Fiber Hydrogen Sensors




(Shen et al. Review of the Status and Prospects of Fiber Optic Hydrogen Sensing Technology, Chemosensors 2023, 11, 473)


Evanescent Field-Based Optical Fiber H₂ Sensor



SEM Images of the Pd/SiO₂ and Filter Layers



With and Without Filter Layers at 99% RH (Room Temp.)





Dry gas **without** the filter layer

Wet gas **with** the filter layer

Wet gas **without** the filter layer

Subsurface Sensor Development Reactor (SSDR)





- **Automation** with LabVIEW
- High-temperature high-pressure:
450 °C, 4,500 psi
- **Multi-phase:** aqueous, gas
- **Gas:** H₂, CO₂, CH₄, N₂, Air

Experimental conditions:
~ 80 °C, 1,000 psi, 99% RH

H₂ sensor installed inside
the vessel

Calibration of the H₂ Sensor at 80 °C, 1,000 PSI, 99% RH


➤ Transmission %




- Calibrated **up to 10% H₂** which is the maximum H₂ concentration the SDR allows.

- 1) **Abiotic** SoCalGas samples and **100% CH₄** for 1, 3, and 7 days
- 2) **Biotic** SoCalGas samples and **100% CH₄** for 1, 3, and 7 days
- 3) **Abiotic** SoCalGas samples and **20% H₂/80% CH₄** for 1, 3, and 7 days
- 4) **Biotic** SoCalGas samples and **20% H₂/80% CH₄** for 1, 3, and 7 days

Abiotic vs. Biotic, 20% H₂+80% CH₄ vs. 100% CH₄, 1 Day




- The **biotic** sample has a **higher effect** on hydrogen sensing than the **abiotic** sample.




- The **CH₄** alone **did not affect** H₂ sensing with the biotic sample for 1 day.

H₂ Concentration vs. Time for the 1 Day Tests




- H₂ concentration has **decreased** by ~2% with the **biotic** sample for 1 day.

Abiotic vs. Biotic Samples in 20% H₂ + 80% CH₄ (3 Days)




- The **biotic** sample has shown much **higher impact** on H₂ sensing for 3 days.

H₂ Concentration vs. Time for the 3 Day Tests




- H₂ concentration has **decreased** for **3 days** by about **2%** and **4%** with the **abiotic** and **biotic** sample, respectively.

Abiotic vs. Biotic, 20% H₂+80% CH₄ vs. 100% CH₄, 7 Days




- The **biotic** sample has shown much **higher impact** on H₂ sensing for 7 days.




- The **biotic** sample with **H₂ gas** has shown much higher impact on H₂ sensing for 7 days.

H₂ Concentration vs. Time for the 7 Day Tests




- **H₂ concentration** has **decreased** for **7 days** by about **5%** and **7%** with the **abiotic** and **biotic** sample, respectively.


1, 3, 7 Days with a Biotic Sample in 20% H₂+80% CH₄




1, 3, 7 Days with an Abiotic Sample in 20% H₂+80% CH₄




Real-Time H₂ Sensing in Subsurface Storage Conditions



Abiotic Reaction



Biological Reactions:



- The optical fiber sensor developed at NETL was able to detect H₂ concentration **at high temperatures** and **pressures** with **biological samples**.
- The **biotic sample** has more **significant impact on H₂ sensing** than the abiotic sample.
- The H₂ sensing responses indicate that **H₂ is consumed with both abiotic and biotic samples** under the subsurface storage environment.
- **Further analysis** on the quantification of **hydrogen consumption** detected by the H₂ sensor will be performed with more accurate calibration and gas chromatography.
- The developed H₂ sensor has demonstrated the **potential** of monitoring H₂ in the subsurface storage reservoirs.

NETL RESOURCES

VISIT US AT: www.NETL.DOE.gov



@NETL_DOE



@NETL_DOE



@NationalEnergyTechnologyLaboratory

CONTACT:

Daejin.Kim

Daejin.Kim@netl.doe.gov

412-386-7425

