

# H<sub>2</sub> Sensing with an Optical Fiber Sensor in the Subsurface H<sub>2</sub> Storage Conditions



***Daejin Kim***

*Research Scientist, NETL Support Contractor*



***2024 AIChE Annual Meeting***

***Oct. 30, 2024***



# Disclaimer

---




This project was funded by the United States Department of Energy, National Energy Technology Laboratory, in part, through a site support contract. Neither the United States Government nor any agency thereof, nor any of their employees, nor the support contractor, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.

**Daejin Kim<sup>1,2</sup>; Alexander Shumski<sup>1,2</sup>; Kara Tinker<sup>1,2</sup>; Djuna Gulliver<sup>1</sup>; Ruishu Wright<sup>1</sup>**

**<sup>1</sup>National Energy Technology Laboratory, 626 Cochran Mill Road, Pittsburgh, PA 15236,  
USA**

**<sup>2</sup>NETL Support Contractor, 626 Cochran Mill Road, Pittsburgh, PA 15236, USA**

# Subsurface Hydrogen Storage



Monitoring H<sub>2</sub> concentration to ensure the integrity and safety of underground H<sub>2</sub> storages.


High pressure  
(~100 bar)

High humidity  
(~100% RH)

High  
temperature  
(~40-80 °C)


Microbiology

# Capacity of Subsurface Hydrogen Storage



Three different types of underground gas storage.

(energyinfrastructure.org)




Volumes of different media require to store 100 TWh of H<sub>2</sub> energy.

(Epelle et al. Sustainable Energy & Fuels, 6 (2022) 3324-3343)


# Optical Fiber Hydrogen Sensors

- **Advantages:**
  - Immune to electro-magnetic interference
  - Resistant to high temperatures and pressures
  - Chemically inert
  - Small and lightweight
  - Suitable for remote and in-situ sensing
- **Disadvantages:**
  - Susceptible to physical damage
  - Interference with humidity
  - Unproven under microbial environments






# Evanescent Field-Based Optical Fiber H<sub>2</sub> Sensor




# SEM Images of the Pd/SiO<sub>2</sub> and Filter Layer





# Hydrogen Sensing at 99% RH (100% to 10% H<sub>2</sub>)




Dry gas **without** the filter layer

Wet gas **with** the filter layer

- The filter layer reduced the effect of water vapor on H<sub>2</sub> sensing.


Wet gas **without** the filter layer

# CO<sub>2</sub> and CH<sub>4</sub> in Subsurface Storage Wells



- The subsurface gas storage is filled with a **cushion gas** such as CO<sub>2</sub> or N<sub>2</sub> to guarantee a minimum reservoir pressure.
- The abandoned **natural gas** can be used toward the **cushion gas** requirement.


# H<sub>2</sub> Sensing in the Presence of CO<sub>2</sub>



- Humidity: **99% RH**
- Shows the negligible impact of **CO<sub>2</sub>** on H<sub>2</sub> sensing under the humid condition.





# H<sub>2</sub> Sensing in the Presence of CH<sub>4</sub>



- Humidity: **99% RH**
- Shows the negligible impact of **CH<sub>4</sub>** on H<sub>2</sub> sensing under the humid condition.

# Subsurface Sensor Development Reactor (SSDR)




- **Automation** with LabVIEW
- **High-Temperature High-Pressure:** 450 °C, 4,500 psi
- **Multi-phase:** aqueous, gas
- **Gas:** H<sub>2</sub>, CO<sub>2</sub>, CH<sub>4</sub>, N<sub>2</sub>, Air

Experimental conditions:  
~ 80 °C, 1,000 psi, 99% RH

**H<sub>2</sub> sensor**  
installed inside the vessel

# SSDR Tests with Biological Samples

- **Biotic Samples**: procured from Playa del Rey (PDR) in CA
- **Abiotic samples**: filtered from the biotic samples




## SSDR Test Conditions:

- 1) **Abiotic** PDR samples and **100% CH<sub>4</sub>** for 1, 3, and 7 days
- 2) **Biotic** PDR samples and **100% CH<sub>4</sub>** for 1, 3, and 7 days
- 3) **Abiotic** PDR samples and **20% H<sub>2</sub>/80% CH<sub>4</sub>** for 1, 3, and 7 days
- 4) **Biotic** PDR samples and **20% H<sub>2</sub>/80% CH<sub>4</sub>** for 1, 3, and 7 days




# H<sub>2</sub> Sensing with Biological Samples for 1 Day

## Biotic vs. Abiotic




- The **biotic** sample has a **higher effect** on hydrogen sensing than the **abiotic** sample.

## 20% H<sub>2</sub>+80% CH<sub>4</sub> vs. 100% CH<sub>4</sub>




- The **CH<sub>4</sub>** alone **did not affect** H<sub>2</sub> sensing with the biotic sample for 1 day.

# Monitoring H<sub>2</sub> Concentration Change for 1 Day




- H<sub>2</sub> concentration has **decreased** by ~2% with the **biotic** sample for 1 day.

# H<sub>2</sub> Sensing with Biological Samples for 7 Days




- The **biotic** sample has shown much **higher impact** on H<sub>2</sub> sensing for 7 days.



- The biotic sample with **H<sub>2</sub> gas** has shown much higher impact on H<sub>2</sub> sensing for 7 days.




# Monitoring H<sub>2</sub> Concentration Change for 7 Days





- H<sub>2</sub> concentration has **decreased** for **7 days** by about **5%** and **7%** from 20% with the **abiotic** and **biotic** sample, respectively.

# Real-Time H<sub>2</sub> Sensing in Subsurface Storage Conditions




- Monitoring H<sub>2</sub> concentration with the optical fiber H<sub>2</sub> sensor at 80 °C, 1,000 psi, and 99% RH.

## Abiotic Reaction



## Biotic Reactions:



(Ram Gupta, et al., Compendium of Hydrogen Energy: Volume 2. Hydrogen Storage, Distribution and Infrastructure, Elsevier, 2015.)



- The **optical fiber hydrogen sensor** was capable of detecting  $H_2$  concentration **at high temperatures** and **pressures** in the presence of **biological samples**.
- The  **$H_2$  concentration** has **decreased** more with the **biotic sample** than the abiotic sample.
- The  $H_2$  sensing responses indicate that  **$H_2$  is consumed with both abiotic and biotic samples** under the subsurface storage environment.
- **Further analysis** on the quantification of hydrogen consumption detected by the  $H_2$  sensor will be performed **with gas chromatography**.
- **Repeatability** of hydrogen sensing at different temperature and pressure will be carried out in near future.

# NETL RESOURCES

---

VISIT US AT: [www.NETL.DOE.gov](http://www.NETL.DOE.gov)



@NETL\_DOE



@NETL\_DOE



@NationalEnergyTechnologyLaboratory

CONTACT:

Daejin Kim

[daejin.kim@netl.doe.gov](mailto:daejin.kim@netl.doe.gov)

412-386-7425

