

# Fabrication and Scale-Up of Porous Polybenzimidazole (PBI) Supports for Gas Separation Composite Membranes



*Lingxiang Zhu*

*Research Scientist*



*2025 North American Membrane Society Annual Meeting*

*May 20, 2025*

# Disclaimer



This project was funded by the United States Department of Energy, National Energy Technology Laboratory, in part, through a site support contract. Neither the United States Government nor any agency thereof, nor any of their employees, nor the support contractor, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.


*Lingxiang Zhu<sup>1,2</sup>; Fangming Xiang<sup>1,2</sup>; Thien Tran<sup>1,2</sup>; Victor A. Kusuma<sup>1,2</sup>; David P. Hopkinson<sup>1</sup>*

*<sup>1</sup>National Energy Technology Laboratory, 626 Cochran Mill Road, Pittsburgh, PA 15236, USA*



*<sup>2</sup>NETL Support Contractor, 626 Cochran Mill Road, Pittsburgh, PA 15236, USA*

- Importance of porous membrane supports
- Membrane fabrication via phase inversion
- Membrane characterization
  - Gas permeance
  - Surface pore structure
  - Chemical and thermal stabilities
- Supporting performance in composite membranes
- Scale-up fabrication
- Conclusions
- Acknowledgments

# Gas Separation Often Relies on Thin Film Composite (TFC) Membranes




**Flat-sheet**



**Hollow fiber**





Koros et al, *Nature Materials*, 2017, 16, 289.

# Promising Porous Membrane Supports



- **High (effective) porosity (>10%)** - to provide sufficient permeance
- **Small pore size (10-50 nm)** - to ease pore penetration effect
- **Chemical stability** - to tolerate aggressive coating solvents
- **Thermal stability** - to withstand harsh drying conditions


# Membrane Supports in the Market and Other Labs




Materials	Glass Transition Temp.(°C)*	Solvent Resistance (R: Resistant/N: Not resistant )				
		Alcohol (ethanol)	Ketone (acetone)	Aromatic (toluene)	Cyclic ether (tetrahydrofuran)	Halogenated (chloroform)
<b>Polyacrylonitrile (PAN)</b>	82 to 145	R	R	R	R	R
<b>Polyethersulfone (PES)</b>	158 to 228	R	N	N	N	N
<b>Polysulfone (PSF)</b>	179 to 194	R	N	N	N	N
<b>Polyvinylidene fluoride (PVDF)</b>	-67 to 5	R	N	R	N	N
<b>Polystyrene-block-poly(4-vinylpyridine) (PS-<i>b</i>-P4VP)</b>	100 to 148	R	N	N	N	N

\* [www.polymerdatabase.com](http://www.polymerdatabase.com), accessed on 10/20/2019; #Peinemann et al, *Nature Materials*, 2007, 6, 992.

# Polybenzimidazole (PBI) as a Support Material




PBI powder




PBI solution

- High glass transition temp.: 425 °C
- Dissolution in very few polar solvents under heat: dimethylacetamide (DMAc)
- Membrane applications: hydrogen separation, organic solvent nanofiltration
- PBI solution: commercially available

# Phase Inversion to Prepare PBI Supports



# Pore Morphology Determined by Solvent Exchange Process







- Vigorous DMAc(solvent) - water exchange leads to pore formation
- **PBI dope concentration (DMAc content)** and **water quench bath temperature** significantly affect the solvent exchange process







# Varying Quench Bath Temp. and PBI Conc. to Achieve Different Pore Morphologies

Sample	PBI (wt.%)	DMAc (wt.%)	Quench Bath Temp. (°C)	Alternative Name
PBI-S1	15	85	20	PBI-15%-20C
PBI-S2	15	85	40	PBI-15%-40C
PBI-S3	15	85	60	PBI-15%-60C
PBI-S4	12.5	87.5	60	PBI-12.5%-60C
PBI-S5	11	89	60	PBI-11%-60C
PBI-S6	10	90	60	PBI-10%-60C
PBI-S7	9	91	60	PBI-9%-60C




# Effect of Bath Temp. on CO<sub>2</sub> Permeance and Pore Structure



# Effect of PBI Conc. on CO<sub>2</sub> Permeance and Pore Structure




# PBI Supports vs. Commercial PAN Supports




	PBI-S6	PAN-S1 (ULTURA™)	PAN-S2 (Synder®)
CO <sub>2</sub> permeance <sup>1</sup> (kGPU)	260 ± 20	138 ± 13	53 ± 1
Pore size (dia, nm)	5 - 42	≤ 20	≤ 22
Surface porosity (%)	22 ± 2	6 ± 1	8 ± 1

1. Determined at a pressure drop of 1 bar and 22 °C.


# Effect of Solvent Immersion on Gas Permeance




Prior to gas permeance test, each sample was immersed in a given solvent for 1 hour, followed by room temperature drying.






# Effect of Thermal Exposure on Gas Permeance



Prior to gas permeance test, each sample was thermally treated for 1 hour at a given exposure temperature.



# PBI Supports vs. Commercial PAN Supports








	PBI-S6	PAN-S1 (ULTURA™)	PAN-S2 (Synder®)
CO <sub>2</sub> permeance <sup>1</sup> (kGPU)	260 ± 20	138 ± 13	53 ± 1
Pore size (dia, nm)	5 - 42	≤ 20	≤ 22
Surface porosity (%)	22 ± 2	6 ± 1	8 ± 1
Operation temperature (°C)	≤ 200	≤ 75	≤ 75
Solvent resistance	Excellent <sup>2</sup>	Good <sup>3</sup>	Good <sup>3</sup>

1. Determined at a pressure drop of 1 bar and 22 °C. 2. Neither dissolved or swollen in common thin film coating solvents like acetone, tetrahydrofuran (THF), and chloroform. 3. Not dissolved but swollen in common solvents.

# Supporting Performance in Two-Layer Composite Membranes


Polydimethylsiloxane (PDMS) knife-casting




References:

- (a) Nanoscale, 8 (2016) 8312;
- (b) J. Membr. Sci., 499 (2016) 191;
- (c) J. Membr. Sci., 541 (2017) 367;
- (d) Energy Environ. Sci., 9 (2016) 434;
- (e) Sep. Purif. Technol., 239 (2020) 116580;
- (f) ACS Appl. Mater. Interfaces, 7 (2015) 15481.


# Supporting Performance in Two-Layer Composite Membranes





Ultra-thin PDMS film prepared by a modified coating method.






# Scale-Up Fabrication via a Roll-to-Roll Process



2020: 40 cm<sup>2</sup>



2021: ~200 cm<sup>2</sup>



2023: 30 cm-wide rolls

- Developed **scalable** PBI supports with:
  - High porosity (up to ~20%)
  - Tunable pore size (13 to 42 nm)
  - Excellent thermal stability and solvent resistance
  - Demonstrated highly permeable and ultra-thin film coatings on PBI supports
  - **Minimum waste treatment cost:** Our polymer dope only consists of PBI and DMAc, so the generated waste water (from quench bath) only contains DMAc contaminant.
- Scaled up PBI support fabrication from the bench-scale hand casting to roll-to-roll continuous production

# Acknowledgments

---



David Hopkinson  
Victor Kusuma  
Thien (James) Tran  
Fangming Xiang  
James Baker

This work was performed in support of the U.S. Department of Energy's (DOE) Office of Fossil Energy and Carbon Management's Point Source Carbon Capture Program and executed through the National Energy Technology Laboratory (NETL) Research & Innovation Center's Point Source Capture Multi-Year Research Plan.

# NETL RESOURCES

---

VISIT US AT: [www.NETL.DOE.gov](http://www.NETL.DOE.gov)



@NETL\_DOE



@NETL\_DOE



@NationalEnergyTechnologyLaboratory

CONTACT:

Lingxiang Zhu  
[lingxiang.zhu@netl.doe.gov](mailto:lingxiang.zhu@netl.doe.gov)

David Hopkinson (Team Lead)  
[david.hopkinson@netl.doe.gov](mailto:david.hopkinson@netl.doe.gov)

