

DRAGON PROJECT USE ONLY

Eric H. Voice
D. P. REPORT 343

O.E.C.D. HIGH TEMPERATURE REACTOR PROJECT

DRAGON



Dragon Project Report

**GRAPHITE SPECIMENS IN THE UPRATED
ELEMENT, FIRST CHARGE POSITION 3/1**

by

ERIC H. VOICE

A.E.E. Winfrith, Dorchester, Dorset, England

May, 1965

GRAPHITE SPECIMENS IN THE UPRATED ELEMENT,
FIRST CHARGE POSITION 3/1

by

ERIC H. VOICE

ABSTRACT

It is proposed to include in the Dragon core a large number of small graphite specimens to assess their irradiation behaviour and their possibilities for a future power reactor. Several series of fuel elements containing such specimens will be withdrawn after different intervals, providing various neutron doses and degrees of damage.

This report describes the specimens in the first of these elements, giving details of the nature of the graphites, the sample positions, the temperatures and fluxes anticipated, the pre-irradiation data, the methods of flux monitoring, and the post-irradiation measurements required.

CONTENTS

	<u>Page No.</u>
1. THE ELEMENT AND ITS FACILITIES	5
2. THE GRAPHITE SPECIMENS	6
2.1 Aspects of Interest	6
2.2 The Shrinkage Specimens	7
2.3 The Creep-Strain Specimens	11
3. THE CERAMIC PELLETT MONITORS	12
4. POST-IRRADIATION MEASUREMENTS	15
5. REFERENCES	16

TABLE

1. Rod No. 1	} The Pre-Irradiation Measurements	19
2. Rod No. 2		21
3. Rod No. 3		23
4. Rod No. 4		25
5. Rod No. 5		27
6. Rod No. 6		29
7. Rod No. 7		31

LIST OF ILLUSTRATIONS

FIGURE

1. Plan of Element 3/1 Showing Numbering of the Rods and their Orientation in the Reactor.
2. Detail Drawing of the Specimens and Containers.
3. Disposition of the Specimens and Monitors with an Estimate of the Temperatures and Fluxes.
4. Disposition of Specimens in the Top Three Spine Sections of Rod No. 5.
5. The Pellet Flux Monitor.
6. The Length Comparator.

7. The Mean Coefficient of Thermal Expansion of PGA and Dragon Grade 9 from 20^o C.
8. The Creep-Strain Components.
9. The Assembled Spines in Transport Box.

GRAPHITE SPECIMENS IN THE UPRATED ELEMENT,

FIRST CHARGE POSITION 3/1

by

ERIC H. VOICE

1. THE ELEMENT AND ITS FACILITIES

For the first fifty days of operation at power the Reactor Experiment will be maintained at a level of 10 MW, confirming the hot-running behaviour before attaining the final designed power level. However, two elements in the core will have an increased fuel loading, generating in their interior conditions of temperature and flux approximating to those in the peripheral hot channels of a reactor operating at 20 MW. These uprated elements will be withdrawn after relatively short periods to assess damage and the progress of dimensional change, and to provide a prediction for the increase to 20 MW [1].

One such element is in position 3/1, about halfway between the core axis and periphery. In a uniformly-loaded reactor the fast (damage-producing) flux would fall radially with a uniform negative curve [2]. With the uprated element in position the fast flux would continue approximately constant from the axis outwards until the centre of the new element, after which a rapid fall would occur to the average reactor level at this radius. Temperatures, on the other hand, would be generally unaffected, rising a little only in the six outer rods of the uprated element and more in the centre rod. Hence the temperature profile is symmetrical over the complete uprated element but strongly asymmetrical across each of the six outer rods, whereas the fast flux is approximately uniform over the five rods nearest to the core axis (which includes the centre rod) but falls steeply across the two outermost rods.

The plan of the uprated element is shown in Fig. 1, with estimates of the spine temperatures and fast neutron flux (>0.1 MeV) levels at the left-hand side of Fig. 3. In the six outer rods temperatures increase upwards from 600°C to a maximum of about 1320°C , while in the centre rod the range is from 650 - 1650°C . Very approximately, the fast flux in the five rods nearest to the core axis ranges from 2.5 to $7.7 \times 10^{13} \text{ n cm}^{-2} \text{ s}^{-1}$, and in the two outermost rods (Nos. 3 and 4) from 2.2 to $6.8 \times 10^{13} \text{ n cm}^{-2} \text{ s}^{-1}$. An irradiation for fifty days, for example, will allow a maximum fast neutron dose of $3 \times 10^{20}/\text{cm}^3$. The gamma flux will be at the general core level of about 2 watts release per cubic centimetre of graphite.

This element, having a wide range of temperature and neutron flux and being withdrawn for examination after a comparatively short period, is ideal for the experimental irradiation of a variety of graphite samples. Down the centre of each rod within the column of fuel rings is a solid graphite spine. Each spine section is six inches long, and a little smaller in diameter than the fuel ring to allow a gas purge flow over the inside of the fuel. To accommodate the various specimens each spine section is drilled out and provided with a cap to form a container, as shown in Fig. 2A. Each container is of course a specimen in itself, measured and weighed before and after irradiation. In all cases the material is Pile Grade A parallel to

extrusion: the identification numbers appearing in the second column of Tables 1-7 give the precise origin of this graphite and are defined in [3]. The use of such containers allows easy routine element assembly, permits a large number of small otherwise - easily-lost specimens, and should help in preventing excessive fission product contamination of the contents.

Each rod normally contains ten spines. In this element nine in each rod were used as containers and the tenth cut into two portions to give a short solid spine at top and bottom. The lower piece raises the container spines to the point where they are symmetrically placed within the core, (i.e., the same excess fuel length of 2.82 in above and below the containers) and the top piece gives a solid mass to take up any excessive corrosion due to the incoming purge gas.

In Tables 1-7 the precise positions of the spines are shown in the third column with reference to the datum. This datum is the surface of the graphite disc upon which both the bottom fuel compact and the solid short spine rest. Subsequent columns in the tables also give the positions of the centre points of every specimen and of the pellet monitors with reference to this datum.

The thermocouple arrangement, AF(b), allows only one within the fuel, axially in the bottom solid spine A of Rod No. 1. There are four other thermocouples in the element, all in slots on the outer surface of Rod No. 7, as shown in Fig. 1: two at the top end, one in the middle and one at the bottom end. The distances of the hot junctions above the datum are:

Top surface thermocouple	61.1 in
Middle surface thermocouple	31.0 in
Bottom surface thermocouple	0.8 in
Spine No. 1A thermocouple	1.2 in.

Fig. 1 also shows the position of the outer metal neutron flux monitors. These are small pieces of nickel and cobalt wire each encapsulated in silica sheaths and held in long crimped stainless steel tubes lying in grooves up the outsides of Rods No. 2, 5 and 7. The precise vertical positions of these monitors are given in [4].

2. THE GRAPHITE SPECIMENS

2.1 Aspects of Interest

At the moment the outstanding problems of graphite technology concern irradiation shrinkage, especially where thermal gradients generate differential stresses, and accompanying creep. Hence dimensional changes due to radiation, creep caused by stress under irradiation and, to a lesser extent, changes in thermal expansion, are of prime interest.

In this element are two series of experiments,

- (a) 2.2 to measure simple dimensional changes with irradiation, and
- (b) 2.3 to measure creep-strain under applied stress and irradiation.

In the first case, three graphites of greatest past and present interest to the Dragon Reactor Experiments, Pile Grade A, P  chiney G5 and Morgan's CYX 165 (G9), are widely distributed over the temperature and flux range for detailed examination and as control for other materials. Specimens of other graphites are then interpolated: Figs. 3 and 4 display the arrangement in more detail.

For the creep-strain measurements two series of differentially-shrinking assemblies occupy the full length of two fuel rods.

2.2 The Shrinkage Specimens

For the measurement of dimensional change with irradiation but with no mechanical constraint a series of rods cut alternately parallel and at right-angles to the extrusion axis is arranged to receive as wide a range of fast neutron flux and temperature as possible. Figs. 1, 3, 4 and Tables 1-7 are relevant.

The standard specimen size is:

Length 2.625 \pm 0.001 in

Diameter 0.220 \pm 0.002 in

A few, supplied by Messrs. Nukem for THTR [5], are 1.28 in long by 0.197 in diameter, with some smaller pieces from Compagnie P  chiney, but in future all specimens should be of the standard size.

Pre-irradiation measurement of length was performed on the transducer comparator shown in Fig. 6. The instrument is the Parnum Electronic Gauge Unit [6]. A selection switch has four ranges, giving full-scale deflections from 0.015 in to 0.0005 in; the transducer spring-load is 60 g.

The position of the measuring head and the zero adjustment were set using an Invar rod of the standard specimen size. This rod has polished end faces parallel to 0.00001 in and was found to have a length of

2.62489 \pm 0.00001 inch at 20^oC

using a Leitz-Strassmann Universal Measuring Machine. The comparator transducer heads are offset from the centre of the V-block supports so that both standard and specimens are measured at a radius of 0.050 in from the axis. The lengths given for the specimens in Tables 2, 4, 6 and 7 are the extremes indicated on rotating the specimens in the V-grooves. Room temperature during measurement varied between 18^oC and 20^oC.

The only other measurement made before irradiation was of weight, shown in the Tables to the nearest milligramme. If it became desirable to perform post-irradiation measurements of other properties such as thermal expansion and conductivity or Young's modulus, duplicate unirradiated samples are available as a control. All handling during the machining, the measuring and the final assembly, was carried out wearing cotton gloves.

The graphites used for the shrinkage specimens are as follows.

PGA - Pile Grade A

In Rods No. 4, 6 and 7 each container (nine per rod) holds one specimen of each orientation. The material is of British Acheson Electrode (BAEL) manufacture from an extruded block, Heat No. A 7010 (3.86 barns, density 1.75). This has one pitch impregnation.

Rod No. 2 has a similar series but using PGA specimens cut from the same small extruded block used for the second and third capsules irradiated at RCN, Petten. This material was manufactured by Anglo Great Lakes (AGL), with two pitch impregnations.

G5 - A Dragon-Péchiney Graphite

G5 is a fine-grained graphite made by Péchiney from reground French E.D.F. graphite, with two pitch impregnations: the composition is given in [7]. Note that the designation "G5" is of Péchiney origin and does not refer to Dragon Grade 5.

Specimens were cut in each orientation from a 3.25 in diameter bar of the first batch of fuel rod material for the Dragon Second Charge. This bar had been rejected for surface spalling and fissures.

Two specimens are in all containers of Rods No. 4, 6 and 7, and in the lower six containers of Rod No. 2.

G9 - Dragon Grade 9

Morgan's CYX 165, graphitised and purified at Compagnie Péchiney. Specimens were cut in both orientations from a 3.25 in diameter unimpregnated bar, part of the material used for the Dragon First Charge. Specimens are in all containers of Rods No. 2, 4, 6 and 7.

It should be noted that this material is unimpregnated, whereas the G9 used in the first and second Petten Capsules for shrinkage specimens had been impregnated with furfuryl alcohol.

IG - Improved Graphite

This is a new graphite developed to a UKAEA specification, with a greater isotropy and an improved radiation stability in the range of interest to the advanced gas-cooled reactor. The properties of this material and the considerations leading to its development are given in [8].

Specimens of two orientations from a large extruded hollow rod are in alternate containers of Rods No. 2, 4, 6 and 7.

CL - Carbone-Lorraine Type 2239

This is a high-strength pressed graphite used for the Dragon fuel element top blocks: the characteristics are detailed in Table 25 of [7].

Specimens cut from a spare top block pressing, in each orientation, are in alternate containers of Rods No. 2, 4, 6 and 7. There are also eight small specimens (1.28 in x 0.197 in), four in each orientation, distributed in the three top containers of Rod No. 5: see Fig. 4. These were supplied ready machined by Messrs. Nukem for THTR.

Carbone-Lorraine Type 3780

Another graphite supplied as small rods by Nukem. Six specimens of each orientation are distributed over the top three containers of Rod No. 5 (Fig. 4).

PC1 - 36 N.P. - A P  chiney Graphite

Reference C.D. 28839.

A pressed graphite supplied as machined samples of the following characteristics:

Thermal expansion coefficient (20-500  C) $6.55 \times 10^{-6}/^{\circ}\text{C}$ //

Thermal expansion coefficient (20-500  C) $2.07 \times 10^{-6}/^{\circ}\text{C}$ \perp

Density 1.884 (1.906) g/cm³

Samples of each orientation are in three spaced containers in the lower part of Rod No. 5.

PC1 - 37 P.3 - P  chiney

Reference C.D. 30708.

A pressed graphite supplied as machined samples with:

Thermal expansion coefficient (20-500  C) $6.65 \times 10^{-6}/^{\circ}\text{C}$ //

Thermal expansion coefficient (20-500  C) $2.11 \times 10^{-6}/^{\circ}\text{C}$ \perp

Density 1.921 (1.914) g/cm³

Samples of each orientation are in three alternate containers of Rod No. 5.

PG1 - 26 - A Pechiney Sample

Reference C.D. 26395, No. 26.

A pressed graphite. One specimen, cut parallel to the direction of pressing is in the top container of Rod No. 5 (Fig. 4). Measurements on this piece at Pechiney gave:

Thermal expansion coefficient (20-500°C) $9.79 \times 10^{-6}/^{\circ}\text{C}$ //
Density 1.98 g/cm^3

Siemens-Plania AMT

A fine-grained graphite supplied ready machined by Messrs. Nukem for THTR. The samples were cut from a pressed block of the following characteristics:

	//	⊥
Thermal expansion, $\times 10^{-6}/^{\circ}\text{C}$	2.5	3.5
Thermal conductivity, cal/cm s $^{\circ}\text{C}$ (25°C)	0.32	0.22
Bending strength, kg/cm ²	320	290
Compressive strength, kg/cm ²	650	630
Density, g/cm ³		1.73
Ash, ppm		<50

Ringsdorff Werke K.R. 67

Another fine-grained pressed material supplied machined by Nuke. for THTR. The characteristics of the pressing are given as follows:

	//	⊥
Thermal expansion, $\times 10^{-6}/^{\circ}\text{C}$	2.6	3.0
Thermal conductivity, cal/cm s $^{\circ}\text{C}$ (25°C)	0.26	0.22
Bending strength, kg/cm ²	280	250
Compressive strength, kg/cm ²	580	580
Density, g/cm ³		1.73
Ash, ppm		<50

2.3 The Creep-Strain Specimens

Graphite shrinkage during irradiation may be counteracted by an applied tensile stress, superimposing a neutron dose-dependent creep. This is of importance not only where structural reactor graphite is subjected to a static load but also where differential temperatures and fluxes cause different rates of shrinkage combined with differential stresses.

No experiment has yet been devised for Dragon in which a constant static load is imposed on a specimen in the core. The only feasible methods utilise the known radiation behaviour of a comparatively large piece of graphite to stress a specimen of a size sufficiently small to have no effect on the dimensional change of the larger piece. Such a method has been described by Losty [9] and Jackson and Hart [10], and a variant has been used by J. H. W. Simmons in the Dounreay Fast Reactor. A modification for use at RCN, Petten, is described in [11].

The arrangement of the components for the specimens in the present element is shown in Fig. 8, with the detail drawings in Figs. 2B and 2C. A "dumb-bell" of G9 graphite (Morgan's CYX 165, the unimpregnated fuel rod material of the first reactor charge) has around the central rod a cylinder or sleeve of Pile Grade A (manufactured by British Acheson Electrodes Ltd.), split in two for assembly. The whole fits into one of the standard spine containers (Fig. 2A).

The G9 shrinks more with irradiation than the PGA and the central rod will thus be in tension. The contact area of the ends of the PGA sleeve is eight times the cross-sectional area of the central rod, giving sufficient tension without undue reaction on the PGA shrinkage. To attain the longest period under stress the relative lengths of dumb-bell and sleeve are such that the thermal expansion, which is greater for PGA, causes the faces to meet at reactor temperature but not to exert an excessive stress which might break the rod before irradiation creep could occur. The use of a PGA sleeve cut transversely to the extrusion axis gives the greatest thermal expansion and allows the pieces to separate without damage at the end of the experiment.

Nine creep-strain specimens occupy the full length of each of Rods No. 1 and 3. Fig. 3 shows the estimated fast neutron fluxes and temperatures and Tables 1 and 3 give the positions and precise dimensions of the components. The dumb-bells were measured internally on a Leitz-Strassmann Universal Measuring Machine and Tables 1 and 3 give the length to the nearest 0.00001 in at two diametrically-opposed points on each dumb-bell: most of the faces are parallel on this diameter to within 0.0003 in. The sleeves were measured separately using a transducer comparator: the tables show the length of each half to the nearest 0.0001 in.

The lengths actually required for the components to meet precisely at the anticipated temperatures according to their position in the core were determined from the thermal expansion plot in Fig. 7. Because of unavoidable machining tolerances it is desirable to calculate the actual

initial stress from the actual measured lengths. The following table shows the specimen number, the anticipated temperature, and the estimated initial stress, using the thermal expansion plot in Fig. 7 and assuming a Young's modulus of 1.83×10^6 psi [12].

The Calculated Initial Dumb-bell Stresses			
Specimen Number	Anticipated Temperatures °C	Initial Gap at Temperature*	Resulting Initial Stress psi
1J	1125	-0.00050	300
1I	1200	+0.00016	-
1H	1275	-0.00122	740
1G	1325	+0.00069	-
1F	1275	-0.00009	55
1E	1200	+0.00051	-
1D	1075	+0.00037	-
1C	900	+0.00072	-
1B	700	+0.00061	-
3J	1125	-0.00036	220
3I	1200	+0.00041	-
3H	1275	-0.00006	37
3G	1325	+0.00047	-
3F	1275	-0.00003	18
3E	1200	+0.00042	-
3D	1075	-0.00058	350
3C	900	+0.00093	-
3B	700	+0.00092	-

*In column three, + indicates sleeve shorter than dumb-bell, i.e., a positive gap, whereas - indicates that the dumb-bell is stretched by this amount.

3. THE CERAMIC PELLET MONITORS

It has been mentioned in Section 1 that three of the fuel rods (Nos. 2, 5 and 7) have stringers of nickel and cobalt flux monitors held in grooves on the outer surfaces (Fig. 1). For a more detailed examination of the neutron flux pattern a monitor is also held in each of the 63 spine containers: in Figs. 2A and B the transverse monitor hole can be seen in the cap.

These monitors are of the ceramic pellet type developed at Harwell and lately improved in sensitivity. A small amount of the natural metal oxide (Fe, Co or Ni in this case) is mixed with pure alumina and pressed and sintered into cylindrical pellets 2 mm diameter by 2 mm long. A number of these pellets is then briefly irradiated together with a weighed piece of pure metal wire and the activity of wire and pellets counted separately. Simple proportion gives the weight of metal in each pellet, which can then be re-irradiated in the neutron flux to be measured and the activity re-determined. This method of calibration is more accurate than the earlier procedure where the metal content was assumed from the initial mix, neglecting any volatilisation during sintering.

Several difficulties can be foreseen in using such a monitor in a high temperature/graphite/pure helium environment:

- (a) At the highest temperatures of the uprated element (up to 1650°C) reduction and volatilisation of the metal could occur.
- (b) Since a small proportion of carbon monoxide can be anticipated, but no dioxide, the alumina itself will be unstable at high temperature.
- (c) Similarly both the metal oxide and the alumina will be unstable in contact with graphite.
- (d) Fission product contamination is probable during irradiation, and possible during post-irradiation dissection, seriously affecting the monitor activity count.

To overcome these difficulties the pellets for the uprated element are encapsulated in silica. Carried out in a small oxy-hydrogen flame, carefully avoiding heating of the pellet, this probably provides the pellet with an oxidising environment at perhaps half an atmosphere pressure. Of course, reactor conditions of 1650°C and 20 atm will quickly collapse the envelope on to the pellet but this does not matter as the envelope need never be removed. Any fission product contamination should be removable by washing before counting.

However, it has been observed that prolonged contact of silica with graphite at high temperatures causes devitrification, sometimes with a collapse to a powder, so to isolate the silica each capsule is wrapped in a niobium foil sheath. Niobium was chosen for its low neutron absorption cross-section (1.1 barns in the thermal region and continuing over the whole energy range at about this level, with the exception of a few peaks rising to several tens of barns between 30 and 1,000 eV), its high melting point of 2468°C , its high temperature stability in non-oxidising atmospheres, and its ductility in sheet form. In contact with graphite at high temperature a carbide will be formed: although this causes brittleness, the form is maintained and in practice the brittleness might be of advantage in allowing easy post-irradiation removal from the silica.

Fig. 5 shows, from left to right, the alumina pellet, the pellet in the silica envelope, the niobium foil, the foil wrapped around the envelope, and the graphite cap with transverse hole. In reality the nickel and cobalt

pellets were a mottled blue in colour before irradiation and the iron a creamy-white: they were handled throughout using tweezers.

The alumina of the pellets is Johnson & Matthey "Spec-Pure," the silica is thermal syndicate transparent fused silica, and the niobium was shown spectrographically to be practically pure. The total weights of these impurities added to the fuel element are:

66 pellets = 1.98 g of alumina

66 silica envelopes = 2.64 g of silica

66 pieces of foil = 10.80 g of niobium

The metal contents of the pellets are of course very small, totalling for the whole element:

Iron	18 mg	} present as Johnson & Matthey "Spec-Pure" Oxides
Cobalt	7 mg	
Nickel	7 mg	

Fig. 3 shows diagrammatically the location of the pellet monitors in the fuel rods.

Rods No. 2, 3, 5 and 6 have an iron pellet monitor in each container. Fe-54 (present at 5.9% in natural iron) has the reaction Fe-54 (n, p) Mn-54, with an energy threshold of about 2.8 MeV. A count of the gamma emitting Mn-54 ($T_{1/2} = 291$ days), isolating the 0.842 MeV line, gives a measure of the fast neutron flux.

This neutron energy threshold of 2.8 MeV is rather high, "fast damage flux" for graphite usually being taken as >0.05 MeV, and a reaction of lower threshold is desirable. Rods No. 1, 4 and 7 therefore contain nickel and cobalt pellets. Ni-58 (present at 68.0% in natural nickel) has the reaction Ni-58 (n, p) Co-58, with an energy threshold of about 1.5 MeV, and a count of the gamma-emitting Co-58 ($T_{1/2} = 71$ days) gives the fast neutron flux. However, Co-58 has a high thermal neutron capture cross section, giving the stable Co-59. To correct for this loss it is necessary to know the thermal flux, and this is conveniently determined by simultaneously irradiating a cobalt specimen having the reaction Co-59 (n, γ) Co-60 and counting the Co-60 gamma activity ($T_{1/2} = 5.2$ years).

Obviously it is necessary to irradiate the nickel and cobalt pellets in close proximity, subjected to the same spectrum. Since one pellet only is in each container, alternate containers in Rods No. 1, 4 and 7 are inverted as indicated in Fig. 3, bringing the two pellet types within 0.7 in of each other. An odd nickel pellet is now in the top container of each rod and to match this the top solid spines 1K, 4K and 7K are fitted with false caps containing cobalt pellets.

The last four columns of Tables 1-7 show the type of monitor, the reference number identifying the calibration batch, the calibrated metal content in micrograms, and the precise position in the Reactor with reference to the datum line defined in Section 1. (For the nickel no metal content figure is yet available.) The first column of the tables, giving the spine number, also indicates by an arrow the cap end of the container. Neither the pellets nor their sheaths have any marking and can be identified only by their position in the fuel rod.

4. POST-IRRADIATION MEASUREMENTS

On removing from the Reactor the fuel element will be dissected in a hot cell. At one stage the fuel tubes will be cut near the ends and the fuel compacts pushed out with the spines inside, taking care not to misplace any spine container caps which may be loose.

From this point the procedure has not been defined in detail, depending much on the levels of activity of the various components. For the time being, as each spine appears it will be photographed if necessary and weighed to the nearest milligram. The overall length of each spine (including the cap) will be measured to the nearest 0.001 in.

In the case of Rods No. 2, 4, 5, 6 and 7, after each spine has been measured and weighed its cap will be pulled off and the encapsulated monitor pushed out into a suitable small container marked with the spine number. If the niobium activity is high it might be desirable to remove the foil sheath at this point. The graphite specimens will then be carefully tipped out into another marked container.

Rods No. 1 and 3 contain the creep-strain experiments. In these cases the caps should be pulled out slowly and gently, lying on a flat surface, to check whether the dumb-bell is broken. When the sleeves have separated, the monitor can be pushed out as before and the three graphite pieces carefully put into a container.

It is assumed that these marked containers of the encapsulated monitors, the shrinkage specimens and the dumb-bells and sleeves are of sufficiently low activity to be removed from the hot cell for further examination.

Each shrinkage specimen will be weighed to the nearest milligram and the length measured, probably using the same comparator device as for the pre-irradiation measurements. The monitors will be passed to the Dragon Operations Group for counting, with preliminary washing if required.

Other measurements on the shrinkage specimens are at present uncertain but may include Young's modulus by velocity of sound, thermal expansion, and thermal conductivity by the method of Kohlrausch, using versions of the apparatus developed at RCN, Petten.

For the creep-strain experiments it will be necessary to:

- (a) Measure the lengths of the separated sleeves and the internal lengths of the dumb-bells. (If of sufficiently low activity this

would be conveniently carried out by the Winfrith Standards Section, as for the pre-irradiation measurements.)

- (b) Determine the coefficient of expansion of the dumb-bell centre section up to, say, 600°C: extrapolation may be made beyond this to the temperature of irradiation.
- (c) Estimate the Young's modulus for the dumb-bell centre section at the temperature of irradiation. This can be done by calculating the strain from the lengths of the sleeves and their known coefficients of expansion, and the lengths of the dumb-bells and their measured coefficients. The specimen would then be loaded mechanically to give this strain and the necessary stress measured: it is possible that this could be carried out with sufficient accuracy at room temperature.

5. REFERENCES

- * [1] R. A. Saunders, "The Uprated Fuel Element," Dragon Internal Document, DPCWP/D.33.
- * [2] H. Gutmann, "Investigations Concerning Radiation Damage in Graphite in the Dragon Core," Dragon Internal Document, DPRDD/1326.
- * [3] L. W. Graham, "Numbering System to be Used for Fuel Element Spines for the First Charge of Dragon," Dragon Internal Document, DPRDD/1106.
- * [4] J. Millshire, "Notes on the Manufacture of the Flux Monitor Assemblies," Dragon Internal Document, DPRDD/1360.
- [5] Nuklear-Chemie und-Metallurgie, GmbH, Wolfgang bei Hanau (Main), West Germany. Contractors to THTR-Projektleitung.
- [6] Parnum Gauges Ltd., Bracknell, Berkshire, England.
- [7] L. W. Graham and M. S. T. Price, "The Fuel Element Graphite," D.P. Report 146, Table 4.1, Page 77.
- [8] J. M. Hutcheon and R. P. Thorn, "Improved Graphite for Nuclear Purposes," Society of Chemical Industry, Second Industrial Carbon and Graphite Conference, April, 1965.
- [9] H. H. W. Losty, et al., "The Irradiation-Induced Plasticity in Graphite," Proceedings of the Fifth Conference on Carbon, Pennsylvania, 1961.
- [10] Jackson and Hart, "An Irradiation-Actuated Device for Measuring the Strain Limit of Graphite," HW-SA-3737.
- *[11] L. W. Graham and E. Smith, "Design of an Experiment to Investigate the Effects of Restraining the Irradiation-Induced Shrinkage of Graphite," Dragon Internal Document, DPRDD/1211.

- [12] L. W. Graham, "The Development of Low Permeability Graphite for the Dragon Reactor Experiment," D.P. Report 40.
- *[13] W. L. Zyp and H. J. Nolthenius, "Neutron Metrology in the HFR," RCN-Int-6 3-062.

*NOTE: Many of the documents referred to are not available for general distribution. Any requests for further information should be addressed to The Chief Executive, O.E.C.D. High Temperature Reactor Project (Dragon), AEE, Winfrith, Dorchester, Dorset, England.

Table 1
Rod No. 1

Spine number (marked on spine dumb-bell and sleeve)	Other numbering on spine	Position of spine versus datum	Nature of specimens	Position of centre point of dumb-bell versus datum	Measured dumb-bell inner length in inches	Measured sleeve length in inches	Total weight and length of assembled spine dumb-bell sleeve and monitor etc., before irradiation	Pellet Monitors			
								Type	Identification numbers	Weight of metal μ S	Position versus datum
1K ↓ ↑	15/2/1	65.90" 60.18"	Solid spine of PGA(AGL) parallel, 5.72" long, (includes cap and monitor)				69.535 g 5.716"	Co	42935	432	60.5"
1J ↑	16/2/5	60.18" 53.80"	One creep-strain dumb-bell	56.9"	3.00042 3.00059	2.9965 2.9966	79.879 g 6.378"	Ni	X	X	59.9"
1I ↓ ↑	15/3/1	53.80" 47.43"	One creep-strain dumb-bell	50.7"	3.00012 3.00032	2.9950 2.9952	80.195 g 6.379"	Co	42943	438	47.7"
1H ↑	18/2/5	47.43" 41.05"	One creep-strain dumb-bell	44.2"	3.00005 3.00043	2.9959 2.9959	81.318 g 6.378"	Ni	X	X	47.1"
1G ↓ ↑	16/3/1	41.05" 34.68"	One creep-strain dumb-bell	37.9"	3.00042 3.00047	2.9937 2.9938	80.431 g 6.380"	Co	42930	487	35.0"
1F ↑	15/2/1	34.68" 28.30"	One creep-strain dumb-bell	31.4"	3.00012 3.00018	2.9946 2.9948	80.872 g 6.380"	Ni	X	X	34.4"
1E ↓ ↑	15/2/5	28.30" 21.93"	One creep-strain dumb-bell	25.2"	3.00010 3.00019	2.9949 2.9949	80.912 g 6.377"	Co	42933	484	22.2"
1D ↑	16/4/1	21.93" 15.56"	One creep-strain dumb-bell	18.7"	3.00016 3.00034	2.9957 2.9958	81.041 g 6.377"	Ni	X	X	21.6"
1C ↓ ↑	18/4/5	15.56" 9.19"	One creep-strain dumb-bell	12.4"	3.00047 3.00054	2.9967 2.9969	80.485 g 6.380"	Co	42942	447	9.5"
1B ↓ ↑	17/4/1	9.19" 2.82"	One creep-strain dumb-bell	5.9"	3.00064 3.00079	2.9981 2.9981	81.299 g 6.377"	Ni	X	X	8.9"
1A	-	2.82" 0.00"	Solid spine of PGA(AGL) parallel, 2.82" long, (includes axial hole 2.5" deep (upwards) for thermocouple				35.580 g 2.814"				

Table 2
Rod No. 2

Spine number (marked on spine)	Other numbering on spine	Position of spine versus datum	Nature of specimens	Orientation of specimen axes	Identification number on specimens	Position of centre point of specimens versus datum	Nominal dimensions of specimen	Measured length of specimen before irradiation, inches	Weight of specimen before irradiation, grammes	Total weight and length of assembled spine including specimens and monitor, etc., before irradiation.	Pellet Monitors			
											Type	Identification number	Weight of metal, µg	Position versus datum
2K	15/1/5	65.90" 60.18"	Solid spine of PGA(AGL), parallel, 5.72" long							73.602 g 5.719"				
↑	2J	15/4/3	PGA(AGL) G5 G9 IG	// // // //	2J1 2J2 2J3 2J4	58.0"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6249-2.6253 2.6237 2.655 2.6244-2.6249	2.880 2.905 2.941 2.583	64.009 g	Fe	F457	419	59.9"
↓														
↑	2I	15/4/1	PGA(AGL) G5 G9 CL	// // // //	2I1 2I2 2I3 2I4	51.6"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6247-2.6250 2.6254 2.6255 2.6248	2.562 2.958 2.903 2.903	65.668 g	Fe	F462	419	53.5"
↓														
↑	2H	16/1/3	PGA(AGL) G5 G9 IG	// // // //	2H1 2H2 2H3 2H4	45.2"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6251-2.6253 2.6252-2.6254 2.6255-2.6256 2.6248-2.6250	2.602 2.930 2.908 2.899	64.130 g	Fe	F456	418	47.1"
↓														
↑	2G	15/1/5	PGA(AGL) G5 G9 CL	// // // //	2G1 2G2 2G3 2G4	38.8"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6258-2.6260 2.6250-2.6251 2.6254-2.6255 2.6256-2.6257	2.578 2.922 2.868 2.912	64.911 g	Fe	F468	461	40.7"
↓														
↑	2F	18/3/1	PGA(AGL) G5 G9 IG	// // // //	2F1 2F2 2F3 2F4	32.5"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6248-2.6251 2.6256 2.6256-2.6257 2.6250-2.6251	2.539 2.947 2.883 2.888	64.937 g	Fe	F458	472	34.4"
↓														
↑	2E	16/3/1	PGA(AGL) G5 G9 CL	// // // //	2E1 2E2 2E3 2E4	26.1"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6251-2.6253 2.6245-2.6246 2.6256 2.6255-2.6256	2.567 2.970 2.929 2.898	65.744 g	Fe	F469	393	28.0"
↓														
↑	2D	15/4/3	PGA(AGL) G5 G9 IG	// // // //	2D1 2D2 2D3 2D4	19.7"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6246-2.6249 2.6254 2.6258 2.6244-2.6246	2.589 2.929 2.908 3.008	64.259 g	Fe	F470	388	21.6"
↓														
↑	2C	15/4/3	PGA(AGL) G5 G9 CL	// // // //	2C1 2C2 2C3 2C4	13.4"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6247-2.6250 2.6243-2.6246 2.6252 2.6249-2.6251	2.587 2.946 2.898 2.868	64.968 g	Fe	F471	451	15.3"
↓														
↑	2B	18/1/5	PGA(AGL) G5 G9 IG	// // // //	2B1 2B2 2B3 2B4	7.0"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6250-2.6254 2.6247 2.6251 2.6247-2.6250	2.568 2.962 2.913 2.885	65.018 g	Fe	F548	377	8.9"
↓														
2A	15/2/5	2.82" 0.00"	Solid spine of PGA(AGL), parallel, 2.82" long							36.682 g 2.820"				

Table 3
Rod No. 3

Spine Number (marked on Spine, dumb-bell and sleeve)	Other numbering on spine	Position of spine versus datum	Nature of specimens	Position of centre point of dumb-bell versus datum	Measured dumb-bell inner length in inches	Measured sleeve length in inches	Total weight and length of assembled spine, dumb-bell, sleeve and monitor, etc.,	Pellet Monitors			
								Type	Identification Numbers	Weight of metal, μg	Position versus datum
3K	15/4/1	65.90" 60.18"	Solid spine of PGA (AGL) parallel, 5.72" long				72.856 g 5.720"				
↑ 3J	17/3/5	60.18" 53.80"	One creep- strain dumb-bell	56.9"	2.99994 3.00014	2.9959 2.9961	80.919 g 6.379"	Fe	F455	447	59.9"
↑ 3I	15/2/3	53.80" 47.43"	One creep- strain dumb-bell	50.6"	3.00022 3.00029	2.9948 2.9949	79.358 g 6.380"	Fe	F463	425	53.5"
↑ 3II	16/4/1	47.43" 41.05"	One creep- strain dumb-bell	44.2"	3.00021 3.00037	2.9947 2.9948	80.325 g 6.380"	Fe	F464	450	47.1"
↑ 3O	17/3/1	41.05" 34.68"	One creep- strain dumb-bell	37.8"	3.00028 3.00056	2.9939 2.9940	81.670 g 6.380"	Fe	F472	446	40.7"
↑ 3P	15/1/5	34.68" 28.30"	One creep- strain dumb-bell	31.4"	3.00037 3.00048	2.9948 2.9950	79.623 g 6.378"	Fe	F545	427	34.4"
↑ 3E	18/3/3	28.30" 21.93"	One creep- strain dumb-bell	25.1"	2.99992 2.99998	2.9948 2.9948	79.719 g 6.379"	Fe	F539	437	28.0"
↑ 3D	15/4/3	21.93" 15.56"	One creep- strain dumb-bell	18.7"	3.00017 3.00042	2.9967 2.9968	79.257 g 6.377"	Fe	F473	455	21.6"
↑ 3C	17/3/1	15.56" 9.19"	One creep- strain dumb-bell	12.3"	3.00033 3.00049	2.9964 2.9966	81.331 g 6.380"	Fe	F476	455	15.3"
↑ 3B	16/4/5	9.19" 2.82"	One creep- strain dumb-bell	5.9"	3.00023 3.00057	2.9975 2.9975	79.936 g 6.375"	Fe	F475	414	8.9"
3A	18/2/1	2.82" 0.00"	Solid spine of PGA (AGL), parallel, 2.82" long				36.645 g 2.820"				

Table 4
Rod No. 4

Spine Number (marked on spine)	Other Numbering on Spine	Position of Spine versus Datum	Nature of Specimens	Orientation of Specimen axes	Identification Number on Specimens	Position of Centre Point of Specimen versus Datum	Nominal Dimensions of Specimen	Measured length of Specimen before Irradiation, inches	Weight of Specimen before Irradiation, grammes	Total Weight and Length of Assembled Spine including Specimens and Monitor, etc., before Irradiation	Pellet Monitors				
											Type	Identification Number	Weight of Metal, µg	Position versus Datum	
4K	15/1/1	65.90" 60.18"	Solid spine of PGA(AGL) parallel, 5.72" long (includes cap and monitor)						-	-	72.304 g 5.730"	Co	42936	470	60.5"
4J	15/4/3	60.18"	PGA(BAEL) G5 G9 IG	/// /// /// ///	4J1 4J2 4J3 4J4	58.0"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6251-2.6253 2.6253-2.6254 2.6254-2.6255 2.6249-2.6251	2.828 2.934 2.896 2.967	65.432 g 6.377"	Ni	X	X	59.9"	
		53.80"	PGA(BAEL) G5 G9 IG	⊥ ⊥ ⊥ ⊥	4J5 4J6 4J7 4J8		2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6251-2.6253 2.6247-2.6249 2.6249-2.6250 2.6248-2.6251	2.827 2.940 2.905 2.921						
4I	16/4/5	53.80"	PGA(BAEL) G5 G9 CL	/// /// /// ///	4I1 4I2 4I3 4I4	51.9"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6245-2.6250 2.6246-2.6247 2.6256 2.6247-2.6255	2.817 2.943 2.909 2.895	65.656 g 6.377"	Co	42938	481	47.7"	
		47.43"	PGA(BAEL) G5 G9 CL	⊥ ⊥ ⊥ ⊥	4I5 4I6 4I7 4I8		2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6247-2.6248 2.6250-2.6251 2.6248-2.6251 2.6258	2.820 2.961 2.912 2.875						
4H	15/2/3	47.43"	PGA(BAEL) G5 G9 IG	/// /// /// ///	4H1 4H2 4H3 4H4	45.2"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6253-2.6256 2.6252-2.6254 2.6253-2.6255 2.6246-2.6248	2.828 2.936 2.903 2.985	64.887 g 6.382"	Ni	X	X	47.1"	
		41.05"	PGA(BAEL) G5 G9 IG	⊥ ⊥ ⊥ ⊥	4H5 4H6 4H7 4H8		2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6250-2.6254 2.6248 2.6253 2.6248-2.6249	2.823 2.945 2.898 2.919						
4G	16/2/5	41.05"	PGA(BAEL) G5 G9 CL	/// /// /// ///	4G1 4G2 4G3 4G4	39.1"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6254-2.6258 2.6250-2.6251 2.6252 2.6257-2.6258	2.837 2.989 2.891 2.909	64.981 g 6.381"	Co	42941	43R	35.0"	
		34.68"	PGA(BAEL) G5 G9 CL	⊥ ⊥ ⊥ ⊥	4G5 4G6 4G7 4G8		2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6250-2.6252 2.6248-2.6250 2.6250-2.6255 2.6259-2.6261	2.829 3.003 2.904 2.908						
4F	18/3/1	34.68"	PGA(BAEL) G5 G9 IG	/// /// /// ///	4F1 4F2 4F3 4F4	32.5"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6251-2.6253 2.6245 2.6258-2.6260 2.6247-2.6249	2.819 2.923 2.920 2.958	66.129 g 6.382"	Ni	X	X	34.4"	
		28.30"	PGA(BAEL) G5 G9 IG	⊥ ⊥ ⊥ ⊥	4F5 4F6 4F7 4F8		2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6252-2.6254 2.6250-2.6251 2.6252-2.6253 2.6246-2.6248	2.839 2.957 2.902 2.914						
4E	15/2/5	28.30"	PGA(BAEL) G5 G9 CL	/// /// /// ///	4E1 4E2 4E3 4E4	26.4"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6253-2.6255 2.6245-2.6246 2.6253-2.6255 2.6252-2.6254	2.812 2.945 2.883 2.884	66.578 g 6.382"	Co	42937	444	22.2"	
		21.93"	PGA(BAEL) G5 G9 CL	⊥ ⊥ ⊥ ⊥	4E5 4E6 4E7 4E8		2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6250-2.6252 2.6249-2.6251 2.6245 2.6255	2.815 2.943 2.883 2.938						
4D	18/2/5	21.93"	PGA(BAEL) G5 G9 IG	/// /// /// ///	4D1 4D2 4D3 4D4	19.7"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6252-2.6256 2.6252 2.6255-2.6258 2.6245-2.6250	2.845 2.922 2.874 2.895	65.592 g 6.381"	Ni	X	X	21.6"	
		15.56"	PGA(BAEL) G5 G9 IG	⊥ ⊥ ⊥ ⊥	4D5 4D6 4D7 4D8		2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6246-2.6248 2.6250 2.6250-2.6252 2.6245-2.6247	2.822 2.947 2.913 2.906						
4C	15/2/1	15.56"	PGA(BAEL) G5 G9 CL	/// /// /// ///	4C1 4C2 4C3 4C4	13.6"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6251-2.6254 2.6244-2.6246 2.6250 2.6254-2.6257	2.826 2.944 2.893 2.907	65.895 g 6.380"	Co	42932	477	9.5"	
		9.19"	PGA(BAEL) G5 G9 CL	⊥ ⊥ ⊥ ⊥	4C5 4C6 4C7 4C8		2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6249-2.6253 2.6251 2.6248-2.6252 2.6256-2.6257	2.844 2.951 2.910 2.918						
4B	16/4/5	9.19"	PGA(BAEL) G5 G9 IG	/// /// /// ///	4B1 4B2 4B3 4B4	7.0"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6251-2.6255 2.6250 2.6256-2.6259 2.6248-2.6250	2.828 2.971 2.894 2.959	64.798 g 6.380"	Ni	X	X	8.9"	
		2.82"	PGA(BAEL) G5 G9 IG	⊥ ⊥ ⊥ ⊥	4B5 4B6 4B7 4B8		2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6246-2.6249 2.6250 2.6252-2.6253 2.6250-2.6251	2.818 2.949 2.923 2.915						
4A	16/4/3	2.82" 0.00"	Solid spine of PGA(AGL), parallel, 2.82" long						-	-	36.509 g 2.820"				

Table 5
Rod No. 5

Spine number (marked on spine)	Other numbering on spine	Position of spine versus datum	Nature of specimens	Orientation of specimen axes	Identification number on specimens	Position of centre point of specimen versus datum	Nominal dimensions of specimen	Measured length of specimen before irradiation, inches	Weight of specimen before irradiation, grammes	Total weight and length of assembled spine including specimens and monitor, etc., before irradiation.	Pellet Monitors				
											Type	Identification number	Weight of metal, µg	Position versus datum	
5K	17/2/1	65.90" 60.18"	Solid spine of PGA(AGL), parallel, 5.72" long					-	-	77.568 g 5.716"					
↑ 5J	16/4/3	60.18" 53.80"	PGA(BAEL)	//	5J4.1	57.8	2.625" x 0.220"	2.6255-2.6257	2.875	66.477 g 6.381"	Fe	F537	460	59.9"	
			SP-AMT	//	B21	58.4	1.28" x 0.200"	1.2790	1.104						
			SP-AMT	//	B4.8		1.28" x 0.200"	1.2772	1.107						
			CL-3780	//	E7	57.1	1.28" x 0.200"	1.2795	1.064						
			CL-3780	//	E4.1		1.28" x 0.200"	1.2808	1.055						
			RW-KR67	//	C2	57.1	1.28" x 0.200"	1.2620	1.124						
			RW-KR67	//	C4.2		1.28" x 0.200"	1.2615	1.127						
			CL-2239	//	D14		1.28" x 0.200"	1.2810	1.182						
			CL-2239	//	D6.2		1.28" x 0.200"	1.2808	1.113						
			PCI-26	//	5J4.2	55.25	2.4" x 0.475"	2.3635	13.071						
↑ 5I	15/2/3	53.80" 47.43"	PGA(BAEL)	//	5I4.3	51.6	2.625" x 0.220"	2.6249-2.6251	2.826	64.666 g 6.380"	Fe	F546	424	53.5"	
			SP-AMT	//	B24	52.2	1.28" x 0.200"	1.2800	1.096						
			SP-AMT	//	B60		1.28" x 0.200"	1.2807	1.099						
			CL-3780	//	E10	50.9	1.28" x 0.200"	1.2810	1.048						
			CL-3780	//	E50		1.28" x 0.200"	1.2813	1.069						
			CL-2239	//	D28	50.9	1.28" x 0.200"	1.2810	1.181						
			CL-2239	//	D79		1.28" x 0.200"	1.2815	1.118						
			CL-3780	//	E13		1.28" x 0.200"	1.2798	1.037						
			CL-3780	//	E51		1.28" x 0.200"	1.2812	1.119						
			RW-KR67	//	C6	49.6	1.28" x 0.200"	1.2645	1.122						
			RW-KR67	//	C4.6		1.28" x 0.200"	1.2642	1.124						
			CL-2239	//	D18		1.28" x 0.200"	1.2810	1.180						
			CL-2239	//	D6.9		1.28" x 0.200"	1.2812	1.116						
			SP-AMT	//	B29	48.3	1.28" x 0.200"	1.2790	1.092						
			SP-AMT	//	B62		1.28" x 0.200"	1.2794	1.100						
			CL-3780	//	E23		1.28" x 0.200"	1.2807	1.062						
			CL-3780	//	E52		1.28" x 0.200"	1.2810	1.119						
			PGA(BAEL)	//	5I4.4	49.0	2.625" x 0.220"	2.6247-2.6250	2.838						
↑ 5H	18/4/5	47.43" 41.05"	PGA(BAEL)	//	5H4.5	45.2	2.625" x 0.220"	2.6249-2.6251	2.806	65.265 g 6.378"	Fe	F551	444	47.1"	
			SP-AMT	//	B33	45.8	1.28" x 0.200"	1.2795	1.098						
			SP-AMT	//	B73		1.28" x 0.200"	1.2800	1.107						
			CL-3780	//	E35	43.2	1.28" x 0.200"	1.2805	1.072						
			CL-3780	//	E75		1.28" x 0.200"	1.2812	1.114						
			{ Three unmeasured PGA spacers. }												
			RW-KR67	//	C8	43.2	1.28" x 0.200"	1.2795	1.135						
			RW-KR67	//	C4.8		1.28" x 0.200"	1.2612	1.127						
			CL-2239	//	D24		1.28" x 0.200"	1.2810	1.108						
			CL-2239	//	D76		1.28" x 0.200"	1.2810	1.113						
			SP-AMT	//	B36	41.9	1.28" x 0.200"	1.2790	1.101						
			SP-AMT	//	B75		1.28" x 0.200"	1.2785	1.100						
			CL-3780	//	E39		1.28" x 0.200"	1.2790	1.096						
			CL-3780	//	E79		1.28" x 0.200"	1.2812	1.062						
			PGA(BAEL)	//	5H4.6	42.6		2.6247-2.6248	2.822						
↑ 5G	15/2/3	41.05" 34.68"	PCI-37P3	//	5G1	38.9	3.2" x 0.475"	3.1500 g	17.230 g	72.257 g	Fe	F544	432	40.7"	
			PCI-37P3	//	5G2	36.1	2.4" x 0.475"	2.3610	12.943	6.381"					
↑ 5F	15/4/1	34.68" 28.30"	PCI-36NP	//	5F1	32.5	3.2" x 0.475"	3.1518	16.923 g	72.022 g	Fe	F536	463	34.4"	
			PCI-36NP	//	5F2	29.7	2.4" x 0.475"	2.3625	13.027 g	6.381"					
↑ 5E	15/3/1	28.30" 21.93"	PCI-37P3	//	5E1	26.2	3.2" x 0.475"	3.1512	17.363 g	73.159 g	Fe	F461	405	28.0"	
			PCI-37P3	//	5E2	23.4	2.4" x 0.475"	2.3605	12.958 g	6.382"					
↑ 5D	16/4/5	21.93" 15.56"	PCI-36NP	//	5D1	19.8	3.2" x 0.475"	3.1510	17.052 g	71.997 g	Fe	F540	456	21.6"	
			PCI-36NP	//	5D2	17.0	2.4" x 0.475"	2.3635	12.918 g	6.381"					
↑ 5C	16/4/3	15.56" 9.19"	PCI-37P3	//	5C1	13.4	3.2" x 0.475"	3.1505	17.434 g	72.597 g	Fe	F543	408	15.3"	
			PCI-37P3	//	5C2	10.6	2.4" x 0.475"	2.3625	13.041 g	6.382"					
↑ 5B	16/3/5	9.19" 2.82"	PCI-36NP	//	5B1	7.1	3.2" x 0.475"	3.1520	17.113 g	72.555 g	Fe	F467	408	8.9"	
			PCI-36NP	//	5B2	4.3	2.4" x 0.475"	2.3655	12.817 g	6.380"					
5A	15/2/5	2.82" 0.00"	Solid spine of PGA(AGL), parallel, 2.82" long					-	-	36.734 g 2.819"					


Table 6
Rod No. 6

Spine number (marked on spine)	Other numbering on spine	Position of spine versus datum	Nature of specimens	Orientation of specimen axes	Identification number on specimens	Position of centre point of specimens versus datum	Nominal dimensions of specimen	Measured length of specimen before irradiation, inches	Weight of specimen before irradiation, grammes	Total weight and length of assembled spine including specimens and monitor, etc., before irradiation.	Pellet Monitors			
											Type	Identification number	Weight of metal, µg	Position versus datum
6K	15/4/1	65.9" 60.18"	Solid spine of PGA(AGL) parallel, 5.72" long							75.454 g 5.720"				
↑ 6J	15/1/5	60.18" 53.80"	PGA(BAEL) G5 G9 IG PGA(BAEL) G5 G9 IG	/// ⊥ ⊥ ⊥ ⊥	6J1 6J2 6J3 6J4 6J5 6J6 6J7 6J8) 58.0") 55.4"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6255-2.6257 2.6251 2.6254 2.6245-2.6248 2.6249-2.6253 2.6249 2.6251-2.6256 2.6245-2.6248	2.830 2.954 2.902 2.832 2.821 2.938 2.909 2.913	65.035 g 6.383"	Fe	F541	670	59.9"
6I	16/3/5	53.80" 47.43"	PGA(BAEL) G5 G9 CL PGA(BAEL) G5 G9 CL	/// ⊥ ⊥ ⊥ ⊥	6I1 6I2 6I3 6I4 6I5 6I6 6I7 6I8) 51.6") 49.0"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6248-2.6252 2.6253-2.6255 2.6255 2.6254 2.6246-2.6247 2.6248-2.6250 2.6250 2.6260	2.834 2.959 2.913 2.955 2.835 2.939 2.932 2.931	64.984 g 6.378"	Fe	F474	558	53.5"
6H	16/3/3	47.43" 41.05"	PGA(BAEL) G5 G9 IG PGA(BAEL) G5 G9 IG	/// ⊥ ⊥ ⊥ ⊥	6H1 6H2 6H3 6H4 6H5 6H6 6H7 6H8) 45.2") 42.6"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6253-2.6255 2.6251 2.6257 2.6248-2.6250 2.6252-2.6254 2.6250 2.6252-2.6253 2.6245-2.6249	2.846 2.940 2.920 2.926 2.835 2.940 2.915 2.889	64.375 g 6.380"	Fe	F549	481	47.1"
6G	18/2/1	41.05" 34.68"	PGA(BAEL) G5 G9 CL PGA(BAEL) G5 G9 CL	/// ⊥ ⊥ ⊥ ⊥	6G1 6G2 6G3 6G4 6G5 6G6 6G7 6G8) 38.8") 36.2"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6249-2.6253 2.6248 2.6254 2.6253 2.6246-2.6248 2.6249 2.6255 2.6254-2.6255	2.843 2.961 2.871 2.894 2.822 2.953 2.906 2.946	66.376 g 6.380"	Fe	F465	401	40.7"
6F	15/2/5	34.68" 28.30"	PGA(BAEL) G5 G9 IG PGA(BAEL) G5 G9 IG	/// ⊥ ⊥ ⊥ ⊥	6F1 6F2 6F3 6F4 6F5 6F6 6F7 6F8) 32.5") 29.9"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6251-2.6254 2.6246-2.6248 2.6255 2.6249-2.6253 2.6247-2.6249 2.6250 2.6256 2.6248-2.6251	2.831 2.981 2.898 2.901 2.852 2.947 2.881 2.872	65.213 g 6.379"	Fe	F466	448	34.4"
6E	17/3/5	28.30" 21.93"	PGA(BAEL) G5 G9 CL PGA(BAEL) G5 G9 CL	/// ⊥ ⊥ ⊥ ⊥	6E1 6E2 6E3 6E4 6E5 6E6 6E7 6E8) 26.1") 23.5"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6252-2.6254 2.6247-2.6248 2.6252 2.6252-2.6253 2.6250-2.6254 2.6248-2.6249 2.6252 2.6252	2.822 2.924 2.908 2.914 2.827 2.933 2.887 2.895	66.285 g 6.380"	Fe	F542	426	28.0"
6D	15/3/5	21.93" 15.56"	PGA(BAEL) G5 G9 IG PGA(BAEL) G5 G9 IG	/// ⊥ ⊥ ⊥ ⊥	6D1 6D2 6D3 6D4 6D5 6D6 6D7 6D8) 19.7") 17.1"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6249-2.6250 2.6251-2.6252 2.6253-2.6254 2.6245-2.6250 2.6250-2.6252 2.6252-2.6253 2.6253-2.6254 2.6248-2.6252	2.834 2.977 2.868 2.874 2.825 2.964 2.901 2.898	65.223 g 6.379"	Fe	F550	435	21.6"
6C	18/4/1	15.56" 9.19"	PGA(BAEL) G5 G9 CL PGA(BAEL) G5 G9 CL	/// ⊥ ⊥ ⊥ ⊥	6C1 6C2 6C3 6C4 6C5 6C6 6C7 6C8) 13.4") 10.8"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6252-2.6254 2.6254-2.6255 2.6254 2.6256-2.6257 2.6249-2.6253 2.6251 2.6255-2.6256 2.6261	2.839 2.955 2.914 2.914 2.810 2.949 2.935 2.919	65.312 g 6.378"	Fe	F538	452	15.3"
6B	16/4/1	9.19" 2.82"	PGA(BAEL) G5 G9 IG PGA(BAEL) G5 G9 IG	/// ⊥ ⊥ ⊥ ⊥	6B1 6B2 6B3 6B4 6B5 6B6 6B7 6B8) 7.0") 4.4"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6253-2.6255 2.6251-2.6252 2.6255-2.6256 2.6245-2.6249 2.6242-2.6245 2.6246-2.6247 2.6253-2.6256 2.6250-2.6251	2.876 2.981 2.874 2.969 2.841 2.940 2.916 2.888	66.167 g 6.381"	Fe	F547	447	8.9"
6A	17/2/1	2.82" 0.00"	Solid spine of PGA(AGL), parallel, 2.82" long							37.645 g 2.813"				

Table 7
Rod No. 7

Spine number (marked on spine)	Other numbering on spine	Position of spine versus datum	Nature of specimens	Orientation of specimen axes	Identification number on specimen	Position of centre point of specimens versus datum	Nominal dimensions of specimen	Measured length of specimen before irradiation, inches	Weight of specimen before irradiation, grammes	Total weight and length of assembled spine including specimens and monitor, etc., before irradiation.	Pellet Monitors			
											Type	Identification number	Weight of metal, µg	Position versus datum
7K	16/4/3	65.90" 60.18"	Solid spine of PGA(AGL), parallel, 5.72" long, includes cap and monitor					-	-	71.000 g 5.722"	Co	42940	480	60.5"
↑ 7J	18/4/5	60.18"	PGA(BAEL) G5 G9 IG	/// /// /// ///	7J1 7J2 7J3 7J4	58.0"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6253-2.6255 2.6248-2.6249 2.6255-2.6256 2.6248-2.6251	2.828 2.948 2.903 2.950	65.389 g	Ni	X	X	59.9"
		53.80"	PGA(BAEL) G5 G9 IG	⊥ ⊥ ⊥ ⊥	7J5 7J6 7J7 7J8		2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6242-2.6245 2.6247 2.6250-2.6251 2.6246-2.6250	2.826 2.950 2.891 2.900					
7I	18/2/1	53.80"	PGA(BAEL) G5 G9 CL	/// /// /// ///	7I1 7I2 7I3 7I4	51.9"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6256-2.6258 2.6254-2.6257 2.6254 2.6252-2.6253	2.848 2.957 2.874 2.906	65.562 g				
		47.43"	PGA(BAEL) G5 G9 CL	⊥ ⊥ ⊥ ⊥	7I5 7I6 7I7 7I8		2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6253-2.6256 2.6251-2.6252 2.6252-2.6254 2.6255-2.6256	2.834 2.925 2.915 2.907					
↑ 7H	18/1/3	47.43"	PGA(BAEL) G5 G9 IG	/// /// /// ///	7H1 7H2 7H3 7H4	45.2"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6249-2.6251 2.6252-2.6254 2.6254-2.6255 2.6246-2.6252	2.832 2.953 2.894 2.893	65.163 g	Ni	X	X	47.1"
		41.05"	PGA(BAEL) G5 G9 IG	⊥ ⊥ ⊥ ⊥	7H5 7H6 7H7 7H8		2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6252-2.6255 2.6252-2.6253 2.6254-2.6255 2.6254-2.6256	2.829 2.952 2.887 2.909					
7G	15/4/3	41.05"	PGA(BAEL) G5 G9 CL	/// /// /// ///	7G1 7G2 7G3 7G4	39.1"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6251-2.6253 2.6254-2.6255 2.6254 2.6249	2.847 2.991 2.897 2.912	64.574 g				
		34.68"	PGA(BAEL) G5 G9 CL	⊥ ⊥ ⊥ ⊥	7G5 7G6 7G7 7G8		2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6250-2.6252 2.6254-2.6255 2.6252-2.6254 2.6253-2.6256	2.838 2.960 2.892 2.961					
↑ 7F	15/4/5	34.68"	PGA(BAEL) G5 G9 IG	/// /// /// ///	7F1 7F2 7F3 7F4	32.5"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6256-2.6257 2.6254-2.6255 2.6253-2.6254 2.6246-2.6250	2.847 2.937 2.884 2.870	64.511 g	Ni	X	X	34.4"
		28.30"	PGA(BAEL) G5 G9 IG	⊥ ⊥ ⊥ ⊥	7F5 7F6 7F7 7F8		2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6247-2.6249 2.6247-2.6248 2.6251 2.6250-2.6253	2.822 2.944 2.919 2.908					
7E	15/2/5	28.30"	PGA(BAEL) G5 G9 CL	/// /// /// ///	7E1 7E2 7E3 7E4	26.4"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6253-2.6255 2.6248-2.6250 2.6253-2.6254 2.6257-2.6258	2.877 2.925 2.903 2.860	66.026 g				
		21.93"	PGA(BAEL) G5 G9 CL	⊥ ⊥ ⊥ ⊥	7E5 7E6 7E7 7E8		2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6252-2.6255 2.6248-2.6250 2.6250-2.6251 2.6241-2.6242	2.840 2.960 2.912 2.942					
↑ 7D	18/1/3	21.93"	PGA(BAEL) G5 G9 IG	/// /// /// ///	7D1 7D2 7D3 7D4	19.7"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6252-2.6255 2.6249-2.6250 2.6257 2.6245-2.6247	2.848 2.930 2.875 2.933	65.179 g	Ni	X	X	21.6"
		15.56"	PGA(BAEL) G5 G9 IG	⊥ ⊥ ⊥ ⊥	7D5 7D6 7D7 7D8		2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6250-2.6252 2.6247-2.6249 2.6252 2.6242-2.6247	2.826 2.955 2.911 2.908					
7C	16/3/3	15.56"	PGA(BAEL) G5 G9 CL	/// /// /// ///	7C1 7C2 7C3 7C4	13.6"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6248-2.6250 2.6246-2.6247 2.6250-2.6251 2.6254	2.896 2.966 2.908 2.921	65.155 g				
		9.19"	PGA(BAEL) G5 G9 CL	⊥ ⊥ ⊥ ⊥	7C5 7C6 7C7 7C8		2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6249-2.6251 2.6249 2.6251-2.6252 2.6258-2.6259	2.798 2.948 2.882 2.903					
↑ 7B	16/2/5	9.19"	PGA(BAEL) G5 G9 IG	/// /// /// ///	7B1 7B2 7B3 7B4	7.0"	2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6246-2.6248 2.6250-2.6251 2.6256-2.6258 2.6245-2.6250	2.824 2.938 2.887 2.920	64.532 g	Ni	X	X	8.9"
		2.82"	PGA(BAEL) G5 G9 IG	⊥ ⊥ ⊥ ⊥	7B5 7B6 7B7 7B8		2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220" 2.625" x 0.220"	2.6253-2.6256 2.6248-2.6249 2.6254-2.6255 2.6246-2.6250	2.824 2.938 2.892 2.861					
7A		2.82" 0.00"	Solid spine of PGA(AGL), parallel, 2.82" long					-	-	37.6 2.818"				

TYPE D2
THERMOCOUPLE
ARRANGEMENT
AF (b)



POSITION NUMBER	IDENTIFICATION NUMBER OF PARTICULAR ROD USED
1	0437
2	0382
3	0460
4	0512
5	0506
6	0510
7	0142

- * METAL FLUX MONITOR STRINGERS
- ROD SURFACE THERMOCOUPLES (TOP, MIDDLE & BOTTOM)

FIG.1 PLAN OF ELEMENT 3/1 SHOWING NUMBERING OF RODS AND THEIR ORIENTATION IN THE REACTOR





FIG. 3 DISPOSITION OF THE SPECIMENS AND MONITORS WITH AN ESTIMATE OF THE TEMPERATURES AND FLUXES.



B21 to B36 inclusive	Siemens-Plania AMT //
B48 to B75 inclusive	Siemens-Plania AMT ⊥
C2 to C8 inclusive	Ringsdorff Werke KR67 //
C42 to C48 inclusive	Ringsdorff Werke KR67 ⊥
D14 to D28 inclusive	Carbone-Lorraine 2239 //
D62 to D79 inclusive	Carbone-Lorraine 2239 ⊥
E7 to E39 inclusive	Carbone-Lorraine 3780 //
E41 to E79 inclusive	Carbone-Lorraine 3780 ⊥

PCI 26 // A Pechiney graphite.

Fig. 4 DISPOSITION OF SPECIMENS IN THE TOP THREE SPINE SECTIONS OF ROD NO. 5.




Fig. 5 The Pellet Flux Monitor




Fig. 6 The Length Comparator




FIG.7 THE MEAN COEFFICIENT OF THERMAL EXPANSION OF PCA & DRAGON GRADE 9 FROM 20°C



Fig. 8 The Creep-Strain Components




Fig. 9 The Assembled Spines in Transport Box