

Using well log analysis to identify residual oil zones at Noble and Kenner West Oil Fields, Illinois

Nathan P. Grigsby Nathan D. Webb, and Scott M. Frailey

Outline

- Motivation
- Ideal Saturation Curve
- Method
- Noble Field
- Kenner Field
- Conclusions

Motivation: ROZs+CO₂EOR


- Thick naturally occurring ROZs in Permian, Big Horn, Powder River, Williston Basins
- > 140 Billion bbls oil within ROZs in Permian Basin (Kuuskraa et al., 2013)
 - 27 billion economically recoverable via CO₂EOR
 - Success at Wasson, Seminole, Salt Creek, Goldsmith, Tall Cotton Fields (and others)
 - Net carbon negative oil
 - Large storage capacity

Motivation: ILB

- Are there ROZs within the ILB that have been historically overlooked?
- Can we use existing well logs to locate/characterize them?
 - Quick, cheap preliminary screening tool
 - Validate with more established methods
 - Are neutron density logs necessary?
- Test in study areas > extend to rest of basin


Ideal Saturation Curve

- 3 intervals
 - Separated by 2 depths
 - POWC
 - Mobile oil saturation
 - OWC
 - Water saturation reaches 100%




Ideal Saturation Curve

- Irreducible water saturation is 35%
- So at POWC is 50%
 - Primary Recovery




Ideal Saturation Curve

- Irreducible water saturation is 35%
- So at POWC is 50%
 - Primary Recovery
- Residual oil saturation is 25%
 - Secondary recovery
 - (waterflood)




Ideal Saturation Curve

- Irreducible water saturation is 35%
- So at POWC is 50%
 - Primary Recovery
- Residual oil saturation is 25%
 - Secondary recovery
 - (waterflood)
- CO₂EOR



Ideal Saturation Curve

- Characterize profile by:
 - Thickness of MPZ, ROZ, oil column
 - Median oil saturation within MPZ and ROZ
 - Oil saturation at POWC



Method

- Water Saturation
 - Archie
 - Ratio
 - Dual Water
- “Proxy” curves
 - Moveable Hydrocarbon Index
 - Bulk Volume Water
 - Apparent Water Resistivity

Method

- Water Saturation

- Archie:

$$\sqrt[n]{\frac{a * R_w}{\phi^m * R_t}}$$


- Ratio:

$$\left[\frac{R_{xo}/R_t}{R_{mf}/R_w} \right]^{\frac{5}{8}}$$

- Dual Water

Extra slides

- Use Pickett Plots to estimate m



Method

- “Proxy” curves

– MHI

$$\frac{S_w}{S_{xo}} = \sqrt{\frac{R_{xo}/R_t}{R_{mf}/R_w}}$$



– BVW

$$S_w * \emptyset$$

– Rwa

$$\frac{\phi^m * R_t}{a}$$

Method



Noble Field

- Calculate and analyze curves for 94 wells
- Create maps and statistically analyze results to identify trends/outliers
- Validate with 4 pulsed neutron logs
- Use historical data to validate POWC/OWC
 - Producing perforations
 - Shows of oil on drilling records
 - Core reports

Thick Cypress Sandstone


- Detailed geologic characterization
- Thick, fairly homogenous clean sandstone
 - Good porosity and high permeability
 - Few shale breaks throughout
 - Calcite cement layers near oil water contact(s)
- Production from several formations including a thin MPZ above thick aquifer in thick Cypress

4 Example Wells


- Pulsed neutron logs on 4 previously drilled and logged wells taken in 2017

Well Name	Year Drilled	Notes
Winter #4	2007	Good behind pipe oil saturation
Winter #7	2011	
Foss #6	1994	
Foss #7	2006	Cypress Producer


Example Well Log Analysis




Example Well Log Analysis




Example Well Log Analysis




Example Well Log Analysis (zoomed in)




Example Well Log Analysis (zoomed in)




Example Well Log Analysis (zoomed in)




Pulsed Neutron Saturation




Pulsed Neutron Saturation (zoomed in)




Archie Oil Saturation by Interval




Noble: Oil saturation in MPZ




Noble: Oil saturation at POWC



Noble: Residual Oil Saturation



Noble Oil Isopach




Noble Results Overview

- Consistent results
 - Oil saturation at POWC ~40 - 45%
 - Residual oil saturation ~20 - 25%
- Reasonable trends
- Results match pulsed neutron logs
 - Same OWC, residual oil saturation
- Results match historical records
- Ratio S_w too low
 - Fails at high water saturation?


Kenner West

- “mini” Noble
 - ~20 miles west
 - Similar rock and fluid properties
- 26 40s wells
 - SP + resistivity logs
- 9 90s wells
 - N/D porosity logs




Kenner Neutron Density logs

	Noble	Kenner 90s
MPZ So	55%	45%
So at POWC	45%	40%
Residual So	25%	25%
Count	94	9




Kenner e-logs

- Can we use e-logs to identify and characterize ROZ?
 - Ratio saturation failed
 - SP or SN derived porosity can be used in Archie
- IP: 4 bbls oil, 233 bbls water per day




Kenner e-logs


	Noble	Kenner 90s	Kenner 40s
MPZ So	55%	45%	45%
So at POWC	45%	40%	40%
Residual So	25%	25%	25%
Count	94	9	26




Kenner Oil Isopach




Kenner Map all MPZ




Kenner Map 40s MPZ




Kenner Initial Condition Model



Kenner Initial Condition Model



Kenner Initial Condition Model



Conclusions

- Evidence of ROZs in the ILB
 - Within thick Cypress Sandstone at both Noble and Kenner West Fields
- Well logs can be used to find/characterize them
- Worked in this case but...
 - Important to validate with other methods
 - Because formation is homogenous and well understood?

Thank You

- Questions?

Acknowledgments

- Research herein was supported by the US Department of Energy contract number DE-FE0024431
- Through a university grant program, IHS Petra, Geovariances Isatis, and Landmark Software was used for the geologic, geocellular, and reservoir modeling, respectively.
- For project information, including reports and presentations, please visit:

<http://www.isgs.illinois.edu/research/ERD/NCO2EOR>

Pulsed Neutron Comparison

- From other wells:
- So at POWC ~45%
- ROS ~25%

	ND+Resistivity				Pulsed Neutron			
	POWC	OWC	@POWC	ROS	POWC	OWC	@POWC	ROS
Winter #4	2588	2612	46	25	2588	2610	46	18
Winter #7	2593	2613	44	28	2592	2612	44	17
Foss #6	2603	2625	49	22	2591	2620	50	1
Foss #7	2600	2625	40	28	2593	2627	23	26